

- Manuals.plus /
- › [xiaoxiao](#) /
 - › Evaporative Air Cooler User Manual

xiaoxiao YXK2001R

Evaporative Air Cooler User Manual

Model: YXK2001R

INTRODUCTION

Thank you for purchasing the xiaoxiao Evaporative Air Cooler. This 3-in-1 portable unit combines the functions of an air cooler, a personal bladeless tower fan, and a humidifier. Designed for home and office use, it features 3 wind speeds, 3 cooling modes, 360° oscillation, and a 1-8 hour timer for personalized comfort. Its bladeless design ensures safety and ease of cleaning. Please read this manual thoroughly before operation to ensure proper use, maintenance, and safety.



Image: The Evaporative Air Cooler, showcasing its sleek black design, air output, and included ice packs for enhanced cooling.

IMPORTANT SAFETY INSTRUCTIONS

To reduce the risk of fire, electric shock, or injury, always follow these basic safety precautions:

- Read all instructions before using this appliance.
- Do not operate any fan with a damaged cord or plug. Discard fan or return to an authorized service facility for examination and/or repair.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic area and where it will not be tripped over.

- Always unplug the unit before moving, cleaning, or performing maintenance.
- Do not immerse the unit in water or other liquids.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance. The bladeless design enhances safety, especially around children and pets.

AESTHETIC BLADELESS COMPACT DESIGN

Safely enjoy pleasing cool



Image: The bladeless design of the air cooler, emphasizing safety for households with children and pets.

PRODUCT OVERVIEW

Parts Identification

- Air Outlet (Bladeless Design)
- Control Panel (Touch Screen)
- Water Tank (Visible Level Indicator)
- Caster Wheels (Lockable for easy movement)
- Remote Control
- Washable Dust Filter (Rear)



PORTABLE DESIGN



Washable dust filter



Movable universal wheel

Image: A detailed view of the air cooler, illustrating its dimensions, the location of the washable dust filter, and the movable caster wheels.

SETUP

1. **Unpacking:** Carefully remove the air cooler from its packaging. Retain packaging for future storage or transport.
2. **Positioning:** Place the unit on a flat, stable surface. Ensure there is adequate space around the unit for proper airflow. The caster wheels allow for easy repositioning.

3. Filling the Water Tank:

- Pull out the water tank from the bottom rear of the unit.
- Fill the tank with clean, cool water. Do not exceed the "MAX" fill line.
- For enhanced cooling, place the included ice packs (or ice cubes) into the water tank.
- Carefully slide the water tank back into the unit until it clicks into place.

4. **Power Connection:** Plug the power cord into a standard electrical outlet.

OPERATING INSTRUCTIONS

Control Panel and Remote Control

The air cooler can be operated using the touch-sensitive control panel on top of the unit or the included remote control. The remote control offers convenience from up to 20 feet away.

**Touch screen operation
can be remotely controlled**
8 hours timed shutdown



Image: The air cooler's remote control, demonstrating its capability for remote operation.

Functions

- **Power On/Off:** Press the "ON/OFF" button to turn the unit on or off.
- **Wind Speed Adjustment:** Press the "Speed" button to cycle through Low, Medium, and High wind speeds.
- **Cooling Modes:** Press the "Mode" button to select between Normal, Natural, and Sleeping modes.
 - *Normal Mode:* Consistent airflow at selected speed.
 - *Natural Mode:* Simulates natural breeze with varying wind speeds.
 - *Sleeping Mode:* Gradually reduces fan speed for quiet operation during sleep.

NATURAL / SLEEPING / NORMAL MODES

3 Wind Speed:



Image: The control panel of the air cooler, illustrating the different wind speeds and operating modes available.

- **Oscillation:** Press the "Swing" button to activate or deactivate the 360° automatic oscillation feature, distributing cool air widely.



Image: The air cooler demonstrating its 360° rotary oscillation feature, ensuring widespread cooling.

- **Timer Function:** Press the "Timer" button to set the auto-off timer for 1, 2, 4, or 8 hours.
- **Humidification Function:** When water is in the tank, the unit automatically provides humidification along with cooling. This helps combat dry air.

Air Cooler Humidifier

Cool down the room and raise humidity Save you from the dryness of A/Cs



Image: The air cooler functioning as a humidifier, improving air quality and comfort in a room.

- **Color Night Light:** Press the "Light" button to turn the integrated color night light on or off.

MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your air cooler.

- **Cleaning the Exterior:** Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Water Tank Cleaning:**
 - Empty and rinse the water tank regularly, especially if the unit is not used for an extended period.
 - Use a mild detergent and warm water if necessary, then rinse thoroughly.
 - Allow the tank to air dry completely before reinserting.
- **Dust Filter Cleaning:**

- The unit features a washable dust filter located at the rear.
 - Gently remove the filter.
 - Rinse the filter under running water to remove dust and debris.
 - Allow the filter to air dry completely before reinserting it into the unit.
 - Clean the filter every 2-4 weeks, or more frequently depending on usage and air quality.
- **Storage:** If storing the unit for an extended period, ensure the water tank is empty and clean, and the unit is dry. Store in a cool, dry place.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Unit does not turn on.	No power supply; Power cord not properly plugged in.	Check power outlet; Ensure power cord is securely plugged in.
Weak airflow.	Dust filter is clogged; Air inlet/outlet blocked.	Clean the dust filter; Ensure no obstructions around air inlets/outlets.
No cooling effect.	Water tank is empty; No ice packs/ice added.	Fill water tank; Add ice packs or ice cubes for enhanced cooling.
Unusual noise.	Unit not on a flat surface; Foreign object inside.	Place unit on a flat, stable surface; Unplug and check for foreign objects. If noise persists, contact support.
Remote control not working.	Batteries are dead or incorrectly inserted; Obstruction between remote and unit.	Replace batteries; Ensure clear line of sight to the unit's sensor.

SPECIFICATIONS

Feature	Detail
Model Number	YXK2001R
Brand	xiaoxiao
Product Dimensions	36.5 x 27.99 x 78 cm (14.37 x 11.02 x 30.71 inches)
Item Weight	5.44 kg (11.99 lbs)
Colour	Black
Material	Plastic
Wattage	110 watts

Feature	Detail
Mounting Type	Freestanding
Special Features	Digital Display, Oscillating Fan, Timer, Humidification, Bladeless Design, Color Night Light
Included Components	Remote control, Ice packs (quantity may vary)

© 2024 xiaoxiao. All rights reserved.

For support, please refer to your purchase documentation or contact the retailer.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question