

Yueyinpu K-24-01

Yueyinpu K-24-01 Wireless Foot Pedal Page Turner Instruction Manual

Model: K-24-01 | Brand: Yueyinpu

1. INTRODUCTION

The Yueyinpu K-24-01 Wireless Foot Pedal Page Turner is designed to provide hands-free control for various digital content, including sheet music, e-books, and presentations. This device enhances convenience for musicians, presenters, and readers by allowing seamless page navigation using foot pedals.



Image: Yueyinpu K-24-01 Wireless Foot Pedal Page Turner with a tablet displaying sheet music.

2. WHAT'S IN THE BOX

- Yueyinpu K-24-01 Wireless Foot Pedal Page Turner
- USB Cable (for charging)

3. PRODUCT OVERVIEW

The K-24-01 features a compact design with two foot pedals for navigation. It includes a mode selection button, power switch, and repeat function switch. The device is equipped with anti-skid pads for stability during use.

Slope Shape-Convenient to Step on



Image: Side view of the Yueyinpu K-24-01 Wireless Foot Pedal Page Turner, showing its ergonomic sloped shape.

Rubber Anti-Skid Pad



Image: Bottom view of the Yueyinpu K-24-01 Wireless Foot Pedal Page Turner, highlighting the rubber anti-skid pads.



Image: Close-up of the control panel on the Yueyinpu K-24-01, showing the Power, Mode, and Repeat switches.

4. SETUP

4.1. Charging the Device

The K-24-01 has a built-in rechargeable lithium battery. Connect the provided USB cable to the device's Type-C charging port and to a compatible USB power source. A full charge provides approximately 60 hours of use.

60+ Hours of Battery Life & Rechargeable

Built-in large-capacity rechargeable lithium battery.



Image: Yueyinpu K-24-01 pedal showing the Type-C charging port and indicating 60+ hours of battery life.

4.2. Bluetooth Pairing

1. Ensure the page turner is powered off.
2. Press and hold the 'MODE' button for 3 seconds until the LED indicator starts flashing, indicating it's in pairing mode.
3. On your device (tablet, smartphone, PC), enable Bluetooth and search for available devices.
4. Select 'K24-01 Pedal' from the list to connect. The LED indicator will stop flashing once successfully paired.

Wide Compatibility, Support various software



Image: Diagram showing the Yueyinpu K-24-01 pedal connecting via Bluetooth to an iPad, smartphone, monitor, and laptop.




Image: Screenshot of an iPad's Bluetooth settings, showing the 'Bluetooth' toggle and a list of devices.




Image: Screenshot of an iPad's Bluetooth settings, showing 'K24-01 Pedal' as connected.

Your browser does not support the video tag.

Video: Demonstrates how to connect the Yueyinpu K-24-01 pedal to a device via Bluetooth.

5. OPERATING INSTRUCTIONS

5.1. Power On/Off

To power on the device, slide the 'POWER' switch to 'ON'. To power off, slide the 'POWER' switch to 'OFF'.

5.2. Mode Selection

The K-24-01 offers five page turning modes. Press the 'MODE' button to cycle through the modes. The active mode is indicated by the illuminated icons on the device.

5 Page Turning Modes

Mode	Pedal Left	Pedal Right
	Page Up	Page Down
	Left Arrow	Right Arrow
	Up Arrow	Down Arrow
	Left Mouse Click	Right Mouse Click
	Space	Enter



Image: Table illustrating the 5 page turning modes of the Yueyinpu K-24-01 pedal, showing corresponding pedal actions (Left/Right) for each mode.

- **Mode 1 (Up & Down Arrows):** Left pedal acts as 'Page Up', Right pedal acts as 'Page Down'.
- **Mode 2 (Left & Right Arrows):** Left pedal acts as 'Left Arrow', Right pedal acts as 'Right Arrow'.
- **Mode 3 (Up & Down Arrows):** Left pedal acts as 'Up Arrow', Right pedal acts as 'Down Arrow'.
- **Mode 4 (Left & Right Mouse Clicks):** Left pedal acts as 'Left Mouse Click', Right pedal acts as 'Right Mouse Click'.
- **Mode 5 (Space & Enter):** Left pedal acts as 'Space', Right pedal acts as 'Enter'.

5.3. Repeat Function

The 'REPEAT' switch controls continuous page turning. When 'REPEAT' is 'ON', holding down a pedal will continuously turn pages. When 'REPEAT' is 'OFF', each pedal press will turn a single page.

5.4. Device and Software Compatibility

The K-24-01 is compatible with iOS (version 11 and above), Android, and Windows operating systems. It supports various applications such as iBooks, Kindle, WPS, Foxit PDF, Adobe PDF, Piascore, and Forscore. Functionality may vary

depending on the application and its settings.

BLUETOOTH CONNECTION

Compatible with iOS, Windows and Android



Image: Yueyinpu K-24-01 pedal in use with a tablet displaying sheet music.




Image: Image showing a cellist using the page turner pedal with a tablet on a music stand, emphasizing hands-free performance.

Your browser does not support the video tag.

Video: Demonstration of the JSP-1 Bluetooth Wireless Page Turner's functionality with various devices and applications.

Your browser does not support the video tag.

Video: Demonstration of a wireless page turner pedal for iPad, smartphones, and PC.

Your browser does not support the video tag.

Video: Quick demonstration of a page turner pedal's basic functions.

6. MAINTENANCE

Keep the device clean by wiping it with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials. Store in a cool, dry place away from direct sunlight and extreme temperatures.

7. TROUBLESHOOTING

- **Device not connecting:** Ensure the device is charged and powered on. Verify that Bluetooth is enabled on your host device and that the pedal is in pairing mode (flashing LED). If issues persist, try restarting both the pedal and your host device.
- **Incorrect page turning:** Check the selected mode on the pedal. Different applications may respond to different modes (e.g., some use Page Up/Down, others use Left/Right Arrow keys). Experiment with different modes to find

the optimal setting for your application.

- **Interference:** Bluetooth connectivity can sometimes be affected by other wireless devices. Try moving away from other Bluetooth-enabled devices or turning them off temporarily to diagnose the issue.

8. SPECIFICATIONS

- **Model Name:** K-24-01
- **Product Dimensions:** 6.69 x 4.33 x 0.91 inches (17 x 11 x 2.3 cm)
- **Item Weight:** 7.1 ounces (201 grams)
- **Connectivity Technology:** Bluetooth
- **Battery:** 1 Lithium Polymer battery (included)
- **Battery Life:** Approximately 60 hours on a full charge
- **Wireless Range:** Up to 33 feet (10 meters)
- **Color:** Black



Image: Dimensions of the Yueyinpu K-24-01 Wireless Foot Pedal Page Turner.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question