

Cosco MXCSCASSCM

Cosco Car Seat MXCSCASSCM Instruction Manual

Model: MXCSCASSCM

1. INTRODUCTION

This manual provides essential instructions for the safe installation, operation, and maintenance of your Cosco Car Seat, model MXCSCASSCM. Please read this manual thoroughly before using the car seat and keep it in a safe place for future reference. Proper use ensures the safety and comfort of your child.

The Cosco Car Seat is designed for children from newborn up to 18 kg (approximately Group 0, 1, and 2), offering both rear-facing and forward-facing options.

2. SAFETY INFORMATION

WARNING: Failure to follow these instructions can result in serious injury or death to your child.

- Always secure your child in the car seat using the 5-point harness system.
- Ensure the car seat is correctly installed in your vehicle using the vehicle's seat belt system.
- Never leave your child unattended in the car seat.
- Do not use this car seat if it has been involved in a crash, even if there is no visible damage. Replace it immediately.
- Refer to your vehicle's owner's manual for specific car seat installation instructions and compatible seating positions.
- Do not modify the car seat in any way. Use only original Cosco replacement parts.
- Ensure the harness straps are snug against your child's body and not twisted.

3. SETUP AND INSTALLATION

The Cosco Car Seat supports both rear-facing and forward-facing installation, depending on your child's weight and age.

3.1 Rear-Facing Installation (Newborn to 13 kg)

For infants and smaller children (typically newborn up to 13 kg), the car seat must be installed in a rear-facing position. This provides optimal head and neck support.

1. Place the car seat on the vehicle seat, ensuring it is level.
2. Route the vehicle's lap and shoulder belt through the designated rear-facing belt path.
3. Buckle the vehicle seat belt and tighten it securely. The car seat should not move more than 1 inch (2.5 cm) side-to-side or front-to-back at the belt path.
4. Adjust the recline position to ensure the child's head does not fall forward.



AUTOASIENTO

Grupo 0, 1, y 2 (recién nacido a 18 kg)

- Seguro hasta 18 kg con cinturón de seguridad
- Arnés de 5 puntos para mayor seguridad del pequeño

Image: Cosco Car Seat highlighting adjustable height, side protection, and suitability for newborns up to 18 kg. This image illustrates key safety and comfort features.

3.2 Forward-Facing Installation (9 kg to 18 kg)

For older children (typically 9 kg to 18 kg), the car seat can be installed in a forward-facing position.

1. Position the car seat on the vehicle seat, facing forward.
2. Route the vehicle's lap and shoulder belt through the designated forward-facing belt path.
3. Buckle the vehicle seat belt and tighten it securely. The car seat should not move more than 1 inch (2.5 cm) side-to-side or front-to-back at the belt path.
4. Attach the top tether strap to the vehicle's tether anchor point and tighten it (if applicable to your vehicle and car seat model).



Image: Cosco Car Seat demonstrating the 5-point harness system and ease of installation using the vehicle's seat belt. Product dimensions (42cm width, 44cm depth, 75cm height) are also indicated.

4. OPERATING INSTRUCTIONS

4.1 Securing Your Child

1. Place your child in the car seat.
2. Bring the two buckle tongues together and insert them into the buckle until you hear a click.
3. Pull the harness adjustment strap to tighten the harness until it is snug against your child's body. Ensure you cannot pinch any excess webbing at the child's shoulder.
4. Position the chest clip at armpit level.
5. To release the harness, press the red button on the buckle.

4.2 Harness Height Adjustment

The harness straps must be at or below your child's shoulders when rear-facing, and at or above your child's shoulders when forward-facing. Adjust the harness height by re-threading the straps through the appropriate slots in the seat back.

4.3 Recline Positions

The car seat features 3 recline positions for optimal comfort and safety. Adjust the recline by lifting the recline lever (usually located at the front or bottom of the seat) and moving the seat to the desired position. Ensure the seat clicks into place.



Image: Cosco Car Seat illustrating the three available recline positions for child comfort and safety.

5. MAINTENANCE

Regular cleaning and maintenance will prolong the life of your car seat.

- **Fabric Covers:** The fabric covers are removable and machine washable. Use cold water on a delicate cycle and mild detergent. Air dry; do not bleach or iron.
- **Harness Straps:** Wipe harness straps with a damp cloth. Do not machine wash or submerge harness straps in water, as this can weaken the webbing.
- **Plastic and Metal Parts:** Wipe plastic and metal parts with a damp cloth and mild soap.
- **Buckle:** Periodically check the buckle for debris. Clean with a damp cloth.

6. TROUBLESHOOTING

- **Harness difficult to tighten:** Check that the harness straps are not twisted and are routed correctly through the seat back. Ensure no fabric is obstructing the harness path.
- **Car seat feels loose after installation:** Re-read the installation instructions carefully. Ensure the vehicle seat belt is fully tightened and locked. Apply pressure to the car seat while tightening the belt.
- **Buckle not clicking:** Check for any debris inside the buckle mechanism. Clean if necessary. Ensure both buckle tongues are inserted fully.

7. SPECIFICATIONS

Feature	Detail
Model Number	MXCSCASSCM
Minimum Weight Recommendation	2.2 kg (Newborn)
Maximum Weight Recommendation	18 kg
Harness Type	5-point harness
Product Dimensions (L x W x H)	42 x 44 x 75 cm

Product Weight	3.6 kg
Facing Positions	Rear-facing and Forward-facing
Recline Positions	3

8. WARRANTY AND SUPPORT

For warranty information, product registration, or customer support, please visit the official Cosco website or contact their customer service department. Keep your proof of purchase for any warranty claims.

Official Cosco Website: [Cosco Brand Store](#)