

Yaheetech Fabric Recliner Sofa

Yaheetech Fabric Recliner Sofa Instruction Manual

Model: Fabric Recliner Sofa

Brand: Yaheetech

1. INTRODUCTION

Thank you for choosing the Yaheetech Fabric Recliner Sofa. This manual provides essential information for the safe and efficient assembly, operation, and maintenance of your new recliner. Please read it thoroughly before use and retain it for future reference.

This adjustable recliner chair is designed for comfort and durability, featuring a strong composite wood frame, soft rayon fibers, high-density foam, quality pocket spring, and hard-wearing linen covering. It offers three relaxation modes to suit your preference.

2. SAFETY INFORMATION

WARNING:

- Do not jump or stand on this recliner.
- Maximum weight capacity: 265 pounds (120 kg).
- Ensure all parts are securely fastened before use.
- Keep children and pets away from moving parts during operation.

3. PACKAGE CONTENTS

Your Yaheetech Fabric Recliner Sofa package should contain the following components:

- Seat base with integrated footrest mechanism
- Backrest
- Four (4) protective feet
- User Manual (this document)

Please inspect all components for any damage or missing parts before proceeding with assembly. If any items are missing or damaged, please contact customer support.

4. SETUP AND ASSEMBLY

Assembly of the Yaheetech Fabric Recliner Sofa is simple and straightforward, requiring no special tools. It typically takes only a few minutes.

Assembly Steps:

1. **Attach the Feet:** Carefully turn the seat base upside down. Screw the four protective feet into the designated holes at the bottom corners of the base. Ensure they are tightened securely.
2. **Connect the Backrest:** Align the metal prongs on the backrest with the corresponding slots on the seat base. Slide the backrest down firmly until it clicks securely into place. Ensure both sides are evenly engaged.
3. **Secure the Back Flap:** If present, pull down the fabric flap at the back of the recliner and secure it using the Velcro fasteners to cover the internal mechanism.



Figure 1: Product dimensions and weight capacity. This image illustrates the overall size and maximum load of the recliner.



Figure 2: Various angles of the recliner, showcasing its compact design and overall appearance.

Assembly Video:

Your browser does not support the video tag.

Video 1: Official Yaheetech video demonstrating the assembly process and various reclining positions of the 610887 Blue Recliner.

5. OPERATING INSTRUCTIONS

The Yaheetech Fabric Recliner Sofa offers three relaxation modes, easily adjusted by leaning back with your body weight. There are no levers or buttons required.

Reclining Positions:

1. **Upright (90 degrees):** The standard sitting position, ideal for reading or conversation.
2. **Partial Recline (120 degrees):** Lean back gently to extend the footrest and achieve a comfortable position for watching TV or light relaxation.

3. **Full Recline (160 degrees):** Lean back further to fully extend the footrest and recline the backrest to an almost flat position, perfect for napping or deep relaxation.

To return to an upright position, simply push forward with your body weight while retracting the footrest.



Figure 3: Visual guide to the three reclining angles and their recommended uses.



Figure 4: Step-by-step visual demonstration of how to operate the recliner through its different positions.

6. MAINTENANCE

To ensure the longevity and appearance of your recliner, follow these simple care instructions:

- **Cleaning:** Wipe clean with a damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Spills:** Blot spills immediately with a clean, dry cloth.
- **General Care:** Periodically check all connections and fasteners to ensure they are tight. Avoid prolonged exposure to direct sunlight to prevent fading.



Figure 5: Details of the linen fabric, highlighting its durability, breathability, and soft feel.

7. TROUBLESHOOTING

If you encounter any issues with your recliner, please refer to the following common solutions:

- **Recliner not engaging/disengaging smoothly:** Ensure there are no obstructions around the footrest mechanism. Apply even pressure when leaning back or pushing forward.
- **Unstable feel:** Check that all four protective feet are securely screwed in and that the backrest is fully engaged in its slots.
- **Squeaking noises:** This may occur with new furniture. Ensure all connections are tight. If the issue persists, a small amount of silicone lubricant can be applied to moving metal parts (avoiding fabric).

For further assistance, please contact Yaheetech customer support.

8. SPECIFICATIONS

Feature	Detail
---------	--------

Brand	Yaheetech
Model Number	Fabric Recliner Sofa
Color	Blue
Material	Linen, Foam
Product Dimensions (D x W x H)	33.5"D x 26.5"W x 39.2"H
Item Weight	51 pounds
Maximum Weight Recommendation	265 Pounds
Reclining Position Count	3
Special Feature	Adjustable, Reclining
Product Care Instructions	Wipe Clean

9. WARRANTY AND SUPPORT

For information regarding product warranty, returns, or customer support, please refer to the purchase documentation or visit the official Yaheetech website. Yaheetech is committed to providing quality products and customer satisfaction.

You can also find more information and contact details on the [Yaheetech Store on Amazon](#).