

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Estink](#) /

› [Estink YYK-520 Professional Wireless Headset User Manual](#)

## Estink V5.0

# Estink YYK-520 Professional Wireless Headset

## USER MANUAL

Model: V5.0

### 1. Introduction

Thank you for purchasing the Estink YYK-520 Professional Wireless Headset. This manual provides detailed instructions on how to set up, operate, and maintain your headset to ensure optimal performance and longevity. Please read this manual carefully before using the product and keep it for future reference.

### 2. Product Overview

The YYK-520 headset is designed for professional use, offering hands-free communication with advanced Bluetooth V5.0 technology. It features a portable charging compartment, ergonomic design, and a 180-degree rotatable ear hook for versatile use.

#### 2.1 Package Contents

- 1 x Earphone
- 1 x Charging Compartment
- 2 x Ear Caps
- 1 x Charging Cable
- 1 x Instruction Manual

#### 2.2 Headset Components



Figure 2.2.1: Overview of the YYK-520 Professional Wireless Headset.



Figure 2.2.2: Control buttons and functions on the headset.



Figure 2.2.3: Ergonomic features including rotatable and extendable earhook.



Figure 2.2.4: Portable charging case and cable.

### 3. Specifications

Feature	Specification
Bluetooth Version	V5.0
Bluetooth Support	A2DP, AVRCP, HFP, HSP, EDR
Communication Distance	≥10 m / 32.8 ft
Frequency Band	2.4 GHz to 2.480 GHz
Standby Time	120 hours
Call Duration	Approx. 5 hours
Music Playback Duration	Approx. 5 hours
Earphone Battery Capacity	60 mAh polymer lithium battery
Charging Compartment Battery Capacity	500 mAh polymer lithium battery
Earphone Charging Time	Approx. 1.5 hours
Charging Compartment Charging Time	Approx. 1.5 hours
Material	ABS
Weight	149 Grams

Feature	Specification
Water Resistance Level	Waterproof
Control Type	Volume adjustment
Connectivity	Wireless Bluetooth

## 4. Setup

### 4.1 Charging the Headset and Charging Case

1. Connect the provided USB charging cable to the charging port on the charging compartment.
2. Connect the other end of the USB cable to a standard USB power adapter (5V/1A recommended) or a computer's USB port.
3. Place the earphone into the charging compartment. Ensure proper alignment for charging.
4. The indicator light on the earphone and/or charging compartment will show charging status. Refer to the indicator light section for details (if applicable, not specified in input).
5. Charging time for the earphone is approximately 1.5 hours, and for the charging compartment, it is also approximately 1.5 hours.

### 4.2 Pairing with a Bluetooth Device

1. Ensure the headset is fully charged.
2. Turn on the headset by pressing and holding the Power On/Off button until the indicator light flashes (usually blue/red alternating, indicating pairing mode).
3. On your mobile phone or Bluetooth-enabled device, go to the Bluetooth settings.
4. Search for available devices. The headset will appear as "YYK-520" or similar.
5. Select "YYK-520" from the list to connect.
6. Once successfully paired, the indicator light on the headset will typically stop flashing and remain solid blue, or turn off. A voice prompt may also confirm the connection.
7. If prompted for a password, enter "0000" (four zeros).

## 5. Operating Instructions

### 5.1 Power On/Off

- **Power On:** Press and hold the Power On/Off button for approximately 3 seconds until you hear a voice prompt or see the indicator light.
- **Power Off:** Press and hold the Power On/Off button for approximately 5 seconds until you hear a voice prompt or the indicator light turns off.

## 5.2 Call Management

- **Answer/End Call:** Press the Answer/End Call button once during an incoming call to answer. Press it again during a call to end the call.
- **Reject Call:** Press and hold the Answer/End Call button for approximately 2 seconds during an incoming call to reject it.
- **Redial Last Call:** Double-press the Redial Last Call button to redial the last dialed number.

## 5.3 Music Playback

- **Play/Pause:** Press the Play/Pause button once to play or pause music.
- **Volume Up/Previous Track:** Short press the Volume Up button to increase volume. Long press the Volume Up button to go to the previous track.
- **Volume Down/Next Track:** Short press the Volume Down button to decrease volume. Long press the Volume Down button to go to the next track.

## 5.4 180-Degree Rotation Feature

The headset features a 180-degree folding support arm, allowing it to be rotated and worn on either the left or right ear for maximum comfort and flexibility.

# 180 Degree Rotation

180-degree folding support arm rotates around the corner for both left and right ears




Figure 5.4.1: Headset's 180-degree rotation for left or right ear use.

## 6. Maintenance

### 6.1 Cleaning

- Wipe the headset and charging case with a soft, dry, lint-free cloth.
- Do not use harsh chemicals, cleaning solvents, or strong detergents.
- Ensure charging ports are free of dust and debris.

### 6.2 Storage

- When not in use, store the headset in its charging compartment to protect it from dust and damage.
- Store in a cool, dry place, away from extreme temperatures and direct sunlight.

## 7. Troubleshooting

Problem	Possible Cause	Solution
Headset does not power on.	Low battery.	Charge the headset and charging compartment fully.
Cannot pair with device.	Bluetooth not enabled on device; headset not in pairing mode; too far from device.	Ensure Bluetooth is on. Put headset in pairing mode. Keep devices within 10m. Try restarting both devices.
No sound during playback/calls.	Volume too low; headset not connected; incorrect audio output selected.	Increase volume on both headset and device. Reconnect headset. Check device's audio output settings.
Poor sound quality.	Interference; low battery; distance from device.	Move away from other wireless devices. Charge headset. Reduce distance to paired device.
Charging compartment not charging.	Faulty cable/adapter; improper connection.	Try a different USB cable and power adapter. Ensure cable is securely connected.

## 8. Warranty and Support

For any issues not covered in this manual or for warranty inquiries, please contact your retailer or the manufacturer's customer support. Please retain your proof of purchase for warranty claims.

Manufacturer: Estink