

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [DOGENI](#) /

› [DOGENI Basic Wall Clock Model WNP001RE User Manual](#)

DOGENI WNP001RE

DOGENI Basic Wall Clock User Manual

Model: WNP001RE

1. INTRODUCTION

Thank you for purchasing the DOGENI Basic Wall Clock, Model WNP001RE. This manual provides essential information for the proper setup, operation, and maintenance of your new clock. Please read these instructions carefully before use and retain them for future reference.

2. SAFETY INFORMATION

- Keep batteries out of reach of children.
- Do not mix old and new batteries, or different types of batteries.
- Remove batteries if the clock will not be used for an extended period to prevent leakage.
- Ensure the clock is securely mounted to prevent it from falling.
- Avoid exposing the clock to extreme temperatures, direct sunlight, or high humidity.

3. PACKAGE CONTENTS

Upon unpacking, please ensure all items are present:

- 1 x DOGENI Basic Wall Clock (Model WNP001RE)
- 1 x Wall Mounting Hook
- 1 x User Manual

Note: 1 AA battery is required for operation and is not included in the package.

4. PRODUCT OVERVIEW

The DOGENI Basic Wall Clock features a classic design with a clear analog display, suitable for various indoor environments. Its quartz movement ensures accurate timekeeping.

Key Features:

- 9-inch diameter with a 1.6-inch depth.
- Elegant ABS plastic frame.
- Front glass cover for clear readability.
- White dial with black Arabic numerals and minute markers.
- Accurate quartz step movement.
- Battery-powered (1 AA battery, not included).



Image 1: Front view of the DOGENI Basic Wall Clock, highlighting its red frame and clear white dial with black Arabic numerals.




Image 2: Side view of the clock, illustrating its 9-inch diameter and 1.6-inch depth.

5. SETUP

5.1. Battery Installation

1. Locate the battery compartment on the back of the clock.
2. Insert one (1) AA battery, ensuring the positive (+) and negative (-) terminals match the indicators inside the compartment.
3. Close the battery compartment cover securely.

5.2. Setting the Time

1. Locate the time setting knob on the back of the clock, usually near the battery compartment.
2. Rotate the knob clockwise or counter-clockwise until the clock hands display the correct time.
3. Avoid turning the hands directly. Always use the setting knob.



Image 3: Rear view of the clock, showing the battery compartment and time adjustment knob for setup.

5.3. Wall Mounting

1. Choose a suitable location on a wall.
2. Install the provided wall mounting hook securely into the wall. Ensure it can support the weight of the clock.
3. Hang the clock onto the hook using the hanging slot located on the back of the clock mechanism.

6. OPERATING INSTRUCTIONS

Once the battery is installed and the time is set, the clock will begin operating automatically. The quartz movement ensures accurate timekeeping. The step movement produces a soft ticking sound as the second hand advances.

7. MAINTENANCE

- **Cleaning:** Wipe the clock's surface with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Battery Replacement:** Replace the AA battery approximately once a year, or when the clock starts

losing time or stops functioning.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Clock not running	Dead or incorrectly inserted battery.	Replace the AA battery with a new one, ensuring correct polarity (+/-).
Clock losing time	Weak battery.	Replace the AA battery with a new one.
Hands are stuck	Hands are bent or obstructed.	Gently check if hands are touching each other or the clock face. Carefully adjust if necessary.

9. SPECIFICATIONS

- **Brand:** DOGENI
- **Model:** WNP001RE
- **Color:** Red
- **Display Type:** Analog
- **Movement:** Quartz, Step Movement
- **Power Source:** 1 x AA Battery (not included)
- **Dimensions (W x H x D):** 22.9 cm x 22.9 cm x 4.1 cm (9 inch diameter, 1.6 inch depth)
- **Material:** ABS Plastic frame, Glass cover
- **Indoor/Outdoor Use:** Indoor
- **Special Features:** Silent Clock (produces a soft ticking sound)
- **Weight:** 0.43 kg (0.62 kg with packing)

10. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided at the point of purchase or contact DOGENI customer service directly. Keep your purchase receipt as proof of purchase.