

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Aeitto](#) /
- › [Aeitto Slow Masticating Juicer Instruction Manual](#)

Aeitto Cold Press Juicer

Aeitto Slow Masticating Juicer Instruction Manual

Model: Cold Press Juicer

Brand: Aeitto

1. INTRODUCTION

Thank you for choosing the Aeitto Slow Masticating Juicer. This appliance is designed to efficiently extract juice from various fruits and vegetables, preserving nutrients through its cold press technology. Its quiet operation and easy-to-clean design make it a convenient addition to your kitchen. Please read this manual thoroughly before use to ensure proper operation and maintenance.



Image 1.1: Fully assembled Aertto Slow Masticating Juicer.

2. SAFETY INSTRUCTIONS

To ensure safe operation and prevent damage, please adhere to the following safety guidelines:

- Read all instructions carefully before operating the appliance.
- Keep the juicer out of reach of children.
- Always unplug the appliance from the power outlet before assembling, disassembling, or cleaning.
- Do not immerse the motor base in water or any other liquid.
- Avoid touching moving parts during operation. Ensure all parts are correctly assembled before turning on.
- Do not operate the juicer if any part is damaged or if the power cord is frayed. Contact customer support for assistance.
- The juicer is equipped with an automatic stop feature that activates after approximately 20 minutes of continuous operation to prevent overheating. Allow the unit to cool down before resuming use.

3. PRODUCT OVERVIEW & COMPONENTS

Familiarize yourself with the various parts of your Aeitto Slow Masticating Juicer:

- **Motor Base:** Contains the motor and control dial.
- **Feeding Chute:** Where fruits and vegetables are inserted.
- **Pusher:** Used to guide produce down the feeding chute.
- **Auger:** The spiral component that crushes and presses produce.
- **Filter:** Separates juice from pulp.
- **Juice Outlet:** Where extracted juice flows out.
- **Pulp Outlet:** Where dry pulp is expelled.
- **Juice Cup:** Collects the fresh juice.
- **Pulp Cup:** Collects the discarded pulp.
- **Cleaning Brush:** Aids in cleaning the filter and other parts.



Image 3.1: Exploded view of the juicer's components for easy identification.

4. SETUP (ASSEMBLY)

Follow these steps to assemble your juicer before first use:

1. Place the motor base on a stable, flat surface.
2. Insert the auger into the main body of the juicer, aligning it with the motor shaft.
3. Place the filter over the auger, ensuring it clicks securely into place.
4. Attach the feeding chute assembly to the motor base, twisting it clockwise until it locks. Ensure the silver button on the side is pressed to allow locking.
5. Position the juice cup under the juice outlet and the pulp cup under the pulp outlet.
6. Insert the pusher into the feeding chute.



Image 4.1: Visual guide for assembling the juicer components.

5. OPERATING INSTRUCTIONS

Prepare your fruits and vegetables by washing them thoroughly. Cut larger items into smaller pieces (approximately 1-inch chunks) to fit the feeding chute and prevent clogging. Remove hard pits or large seeds.

5.1 Selecting the Correct Mode

The juicer features three modes for optimal extraction:

- **SOFE MODE (85-100 RPM):** Ideal for soft fruits like oranges, watermelon, grapes, and berries.
- **HARD MODE (95-110 RPM):** Suitable for harder fruits and vegetables such as apples, pears, carrots, beets, celery, ginger, and kale.
- **REVERSE (REV) Mode:** Use this mode to clear any blockages if produce gets stuck during juicing. Hold the dial in the 'REV' position for a few seconds, then release and switch back to 'O' (Off) before selecting a juicing mode.

**Compact size,
Saving space for the kitchen.**



Image 5.1: Control dial for selecting juicing modes.

5.2 Juicing Process

1. Ensure the juicer is properly assembled and the juice and pulp cups are in place.
2. Plug the power cord into a suitable electrical outlet.
3. Turn the control dial to the desired mode (SOFE or HARD).
4. Slowly feed the prepared fruits or vegetables into the feeding chute. Use the pusher gently to guide the produce down. Do not force large quantities at once.
5. Observe the juice flowing into the juice cup and pulp collecting in the pulp cup. The pulp should be relatively dry, indicating efficient extraction.
6. Once juicing is complete, turn the control dial to 'O' (Off) and unplug the appliance.

Higher Juice Yield & Drier Pulp

Upgraded filter extracts purest juice



Image 5.2: Feeding produce into the juicer for extraction.

2 Mastigating Speeds

Suitable for different fruits and vegetables




Image 5.3: Illustration of juice and dry pulp separation.

6. MAINTENANCE & CLEANING

Regular cleaning ensures the longevity and hygiene of your juicer.

6.1 Disassembly

The juicer features a one-button disassembly design for convenience:

1. Ensure the juicer is turned off and unplugged.

2. Press the silver release button on the side of the feeding chute assembly.
3. Twist the feeding chute assembly counter-clockwise to detach it from the motor base.
4. Remove the auger and filter from the assembly.
5. Empty the juice and pulp cups.

6.2 Cleaning

All detachable parts are dishwasher safe, making cleanup simple. For manual cleaning:

- Rinse all detachable parts under running water.
- Use the provided cleaning brush to remove any stubborn pulp residue from the filter and other components.
- Wash parts with warm, soapy water.
- Rinse thoroughly and allow to air dry completely before reassembling or storing.
- Wipe the motor base with a damp cloth. Never immerse the motor base in water.




Image 6.1: Cleaning the juicer filter and highlighting dishwasher-safe components.

Your browser does not support the video tag.

Video 6.1: A short demonstration of the easy cleaning process for the juicer.

7. TROUBLESHOOTING

If you encounter any issues with your juicer, please refer to the following common solutions:

- **Juicer stops during operation:** The appliance has an automatic overheat protection feature. It will stop after approximately 20 minutes of continuous use. Unplug the juicer and allow it to cool down for at least 30 minutes before restarting.
- **Produce is stuck in the chute:** Switch the control dial to the 'REV' (Reverse) mode and hold for a few seconds. This will reverse the auger's rotation to dislodge the produce. Release the dial, switch to 'O' (Off), and then resume juicing in the appropriate mode.
- **Low juice yield or wet pulp:** Ensure you are using the correct mode (SOFE or HARD) for the type of produce. Cut produce into smaller pieces and feed them slowly to allow for thorough extraction.

8. SPECIFICATIONS

Feature	Detail
Brand	Aeitto
Model Name	Aeitto Masticating Juicer (Cold Press Juicer)
Product Dimensions	11.61"D x 10.06"W x 7.68"H
Item Weight	9.39 pounds
Maximum Power	150 Watts
Voltage	120 Volts
Number of Speeds	2 (Soft, Hard)
Special Features	Dishwasher Safe, Juice & Pulp Separation, One-button Disassembly Design, Quiet Motor, Triple Modes (SOFE+HARD+Reverse)

9. WARRANTY & SUPPORT

Aeitto offers a 12-month coverage period for this slow masticating juicer. Should you encounter any issues with your item, please do not hesitate to reach out to our customer support. We are committed to providing a resolution and ensuring your satisfaction.