

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Ibiza](#) /

> [Ibiza KARAVISION Portable Karaoke Speaker Model 10-9011 Instruction Manual](#)

Ibiza KARAVISION 10-9011

Ibiza KARAVISION Portable Karaoke Speaker

Model: 10-9011

Brand: Ibiza

IMPORTANT SAFETY INSTRUCTIONS

Please read these instructions carefully before using the device and retain them for future reference. Incorrect use may result in electric shock, fire, or other hazards.

- Do not expose this appliance to rain or moisture.
- Do not open the housing. There are no user-serviceable parts inside. Refer all servicing to qualified service personnel.
- Use only the power adapter specified by the manufacturer.
- Keep the unit away from heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- Unplug this apparatus during lightning storms or when unused for long periods of time.
- Do not place objects filled with liquids, such as vases, on the apparatus.

PRODUCT OVERVIEW

The Ibiza KARAVISION is a portable karaoke speaker designed for audio playback and vocal performance. It features an integrated screen for displaying song lyrics, two wireless VHF microphones, and multiple connectivity options for versatile use.



This image shows the front of the Ibiza KARAVISION speaker, highlighting its integrated screen. The screen is displaying the 'Ibiza Sound' logo, indicating its power-on state. The speaker has a robust, portable design with a handle at the top.

Key Features:

- Integrated screen for lyric display.
- Two wireless VHF microphones included.
- Bluetooth connectivity for wireless audio streaming.
- USB and SD card reader for local media playback.
- FM radio tuner.
- 3.5mm auxiliary line input for external audio devices.
- 6.35mm microphone input for an additional wired microphone (not supplied).
- Rechargeable lithium battery for extended portable use.
- Remote control for convenient operation.
- Screen mirroring function (compatibility may vary).

PACKAGE CONTENTS

Verify that all items are present in the package:

- Ibiza KARAVISION Portable Karaoke Speaker
- 2 x Wireless VHF Microphones
- Remote Control

- Power Adapter
- User Manual (this document)

CONTROLS AND CONNECTIONS

Familiarize yourself with the various controls and connection ports on your KARAVISION speaker.



This image displays the side panel of the Ibiza KARAVISION speaker, detailing its control interface and various input/output ports. Two wireless microphones are shown attached to the side. The panel includes buttons for mode selection, playback control, volume adjustments, and inputs for USB, SD card, AUX, and a wired microphone.

Control Panel Layout:

1. **Power Switch:** Turns the unit ON/OFF.
2. **DC IN:** Power adapter input.
3. **USB Port:** For USB flash drives.
4. **SD Card Slot:** For SD memory cards.
5. **AUX Input (3.5mm Jack):** Connect external audio devices.
6. **MIC Input (6.35mm Jack):** Connect a wired microphone.
7. **Volume Knobs:** Master Volume, Microphone Volume, Echo Level.
8. **Mode Button:** Switches between Bluetooth, USB/SD, FM, AUX modes.
9. **Playback Controls:** Play/Pause, Previous Track, Next Track.
10. **Menu/Return Buttons:** For navigating on-screen menus.
11. **TV Output:** (If present, for connecting to an external display).
12. **Antenna:** For FM radio and wireless microphone reception.

SETUP

1. Charging the Battery

- Connect the provided power adapter to the DC IN port on the speaker and plug it into a wall outlet.
- The charging indicator light will illuminate. Allow sufficient time for a full charge before first use (refer to specifications for charging time).
- The unit can be used while charging.

2. Inserting USB Drive or SD Card

- Insert a USB flash drive into the USB port or an SD card into the SD card slot. Ensure it is inserted correctly.
- The unit will automatically switch to USB/SD mode if media is detected.

3. Preparing Wireless Microphones

- Insert the required batteries (not supplied) into each wireless microphone, observing polarity.
- Turn on the microphones. They should automatically pair with the speaker.

OPERATING INSTRUCTIONS

1. Power On/Off

- To turn on the speaker, flip the Power Switch to the 'ON' position. The screen will light up.
- To turn off, flip the Power Switch to the 'OFF' position.

2. Mode Selection

- Press the **Mode** button repeatedly to cycle through available input sources: Bluetooth, USB, SD, FM Radio, AUX. The current mode will be displayed on the screen.

3. Bluetooth Pairing

- Switch the speaker to Bluetooth mode. The screen will display 'Bluetooth' or a similar indicator, and the unit will enter pairing mode.
- On your mobile device (smartphone, tablet), enable Bluetooth and search for available devices.

- Select 'KARAVISION' (or similar name) from the list to pair. A confirmation sound will indicate successful pairing.
- You can now play audio from your device through the speaker.

4. USB/SD Playback

- Ensure your USB drive or SD card contains compatible audio files (e.g., MP3).
- Insert the USB drive or SD card into its respective slot. The speaker will automatically switch to USB/SD mode and begin playback.
- Use the Play/Pause, Previous Track, and Next Track buttons to control playback.

5. FM Radio

- Switch the speaker to FM Radio mode.
- Extend the antenna for better reception.
- Press and hold the Play/Pause button to initiate an automatic scan for FM stations. The speaker will save detected stations.
- Use the Previous Track and Next Track buttons to navigate through saved stations.

6. AUX Input

- Connect an external audio device (e.g., smartphone, tablet, laptop) to the 3.5mm AUX Input port using a 3.5mm audio cable (not supplied).
- Switch the speaker to AUX mode.
- Control playback from your connected device.

7. Karaoke Function

- Ensure the wireless microphones are powered on and paired.
- Adjust the Microphone Volume and Echo Level knobs on the control panel to your preference.
- For wired microphones, connect them to the 6.35mm MIC Input and adjust their volume.
- The integrated screen can display lyrics from compatible media (e.g., CD+G files on USB/SD, or via screen mirroring).

8. Screen Mirroring Function

- The KARAVISION speaker supports a screen mirroring function. Refer to the on-screen menu for specific instructions on how to activate and connect your smartphone or tablet.
- Compatibility may vary between devices (iOS and Android). Ensure your device's screen mirroring feature is enabled and discoverable.

MAINTENANCE

1. Cleaning

- Wipe the exterior of the speaker with a soft, dry cloth.
- Do not use abrasive cleaners, waxes, or solvents as they may damage the finish.
- Ensure no liquids enter the unit.

2. Battery Care

- To prolong battery life, fully charge the speaker before first use and after long periods of inactivity.
- Avoid completely draining the battery frequently.

- Store the unit in a cool, dry place when not in use.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Battery discharged; Power adapter not connected; Power switch off.	Charge the battery; Connect the power adapter; Turn the power switch ON.
No sound	Volume too low; Incorrect mode selected; Device not connected properly.	Increase Master Volume; Select correct input mode; Reconnect audio device/microphone.
Microphone not working	Microphone off; Batteries low/incorrectly inserted; Mic Volume too low.	Turn on microphone; Check/replace batteries; Increase Microphone Volume.
Bluetooth not connecting	Speaker not in Bluetooth mode; Device too far; Device already connected to another speaker.	Switch to Bluetooth mode; Move device closer; Disconnect from other devices and try again.
USB/SD card not reading	Incorrect file format; Card/drive corrupted; Card/drive not inserted correctly.	Ensure files are MP3; Try another USB/SD card; Reinsert the card/drive.
Screen mirroring issues	Device incompatibility; Incorrect setup steps.	Consult your device's manual for screen mirroring; Ensure both devices are on the same network (if applicable); Try different devices.

SPECIFICATIONS

Feature	Detail
Brand	Ibiza
Model Number	10-9011
Connectivity Technology	Bluetooth, 3.5mm Audio Jack
Special Feature	Screen Mirroring Function
Compatible Devices	Smartphones, Tablets, Auxiliary Devices, Wired Microphones
Power Source	Battery Powered
Number of Speakers	1
Total USB Ports	1
Color	Black

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation provided with your purchase or contact your retailer. Keep your proof of purchase for any warranty claims.

