

MOMYEASY 2800

MOMYEASY Baby Food Maker Model 2800 Instruction Manual

Your comprehensive guide to preparing nutritious meals for your baby.

1. INTRODUCTION

The MOMYEASY Baby Food Maker Model 2800 is a versatile 4-in-1 appliance designed to simplify your baby's meal preparation. This device allows you to steam, blend, warm bottles, and sterilize accessories, all within a single unit. Its intuitive touch control panel and thoughtful design aim to provide convenience and efficiency for parents.

2. SAFETY INFORMATION

- Always ensure the unit is unplugged before cleaning or assembling/disassembling parts.
- Do not immerse the main unit in water.
- Keep out of reach of children.
- Use only distilled or purified water for steaming to prevent mineral buildup.
- Ensure the blending cup is properly attached before operation to avoid error codes (E1).
- Do not open the blending cup until the blades have completely stopped.
- Avoid contact with hot steam during operation.
- All food-contact parts are made with 100% BPA-free, food-grade material.

3. PRODUCT OVERVIEW AND COMPONENTS

The MOMYEASY Baby Food Maker consists of a main unit with a control panel, a blending cup with a detachable blade, a double-layer steamer basket, and a water tank.



Figure 1: MOMYEASY Baby Food Maker with various components and examples of pureed baby food.

Control Panel Functions:

Steaming + Auto/manual blend

Adjust food consistency according to baby's different eating habits



Figure 2: Detailed view of the touch control panel.

- **On/Off:** Powers the device.
- **Steam:** Initiates the steaming process. Time can be adjusted.
- **Sterilize:** For sterilizing bottles and accessories.
- **Warm:** Heats baby bottles or food.
- **Manual Blend:** Allows manual control over blending for desired consistency.
- **Auto Blend:** Automatically blends steamed food to a smooth puree.
- **+/- Buttons:** Adjust steaming or warming time.

4. SETUP

1. Unpack all components and remove any packaging materials.
2. Wash all detachable parts (blending cup, blade, steamer basket, lids) with warm soapy water or place them in the dishwasher.

3. Ensure all parts are completely dry before assembly.
4. Place the main unit on a stable, flat, and heat-resistant surface.
5. Fill the water tank located on the left side of the main unit with distilled or purified water up to the MAX line.
6. Insert the blending cup onto the right side of the main unit, ensuring it clicks securely into place.

5. OPERATING INSTRUCTIONS

5.1 Steaming Food

1. Prepare your ingredients (fruits, vegetables, meat, fish) by washing, peeling, and cutting them into small pieces (approximately 1.5 cm).
2. Place the chopped ingredients into the double-layer steamer basket.
3. Insert the steamer basket into the blending cup and secure the lid.
4. Ensure the water tank is filled.
5. Press the 'On/Off' button to power on the device.
6. Select the 'Steam' function. Adjust the steaming time using the +/- buttons based on the food type (e.g., 15-20 minutes for most items).
7. The device will automatically steam the food. Once complete, it will beep.

MOMYEASY 4-in-1 Baby Food Maker

✓ Steam & Blend ✓ Warm Bottles ✓ Sterilize



Auto blend/manual blend



Bottle warmer



Sterilize



Steam

Figure 3: Steaming function in progress.

5.2 Blending Food

After steaming, you can blend the food to your desired consistency.

1. Carefully remove the steamed food from the basket and place it directly into the blending cup.

2. Add a small amount of breast milk, formula, or distilled water to achieve the desired texture.
3. Secure the blending cup lid.
4. Choose either 'Auto Blend' for a smooth, hands-free puree or 'Manual Blend' to control the blending duration for chunkier textures.
5. Blend until the desired consistency is reached.

Effortless Meals, Happy Babies

The Smart Way to Feed Your Little Explorer



Figure 4: Blending options for various baby food consistencies.

5.3 Bottle Warming

1. Ensure the water tank is filled.
2. Place the baby bottle (without the nipple) into the water tank area.

3. Select the 'Warm' function. Adjust the warming time using the +/- buttons.
4. The device will warm the bottle. Always check the temperature of the milk or food before feeding your baby.

Why Parents Choose Us? Smarter, Safer & Healthier!

Discover the Difference That Matters for Your Baby



Deep-Penetrating Steam
→ Retains 90% Vitamins



Detachable & Residue-Free
→ 1-Minute Cleaning



Double Steamer,
→ time-saving and efficient



360° Anti-Splash Lid
→ No Mess, No Stress



Figure 5: Bottle warming in progress.

5.4 Sterilizing Accessories

1. Ensure the water tank is filled.
2. Place small accessories (e.g., bottle nipples, pacifiers) into the blending cup or steamer basket.
3. Select the 'Sterilize' function.
4. The device will sterilize the items using steam.

Your browser does not support the video tag.

Video 1: Demonstration of the 5-in-1 Baby Food Processor, including auto cooking, grinding, and steaming functions. Provided by SKYPEJAY INC.

Your browser does not support the video tag.

Video 2: An honest review of the MOMYEASY Baby Food Processor, highlighting its steaming and pureeing capabilities. Provided by Strathroy Antique Mall.

6. CLEANING AND MAINTENANCE

Regular cleaning ensures optimal performance and hygiene.

- **Daily Cleaning:** All detachable parts (cup, blade, steamer basket, lids) are dishwasher-safe. They can also be washed by hand with warm soapy water.
- **Self-Clean Function:** Add a small amount of water to the blending cup and select the 'Clean' function for quick internal cleaning.
- **Descaling:** If mineral buildup occurs in the water tank, use a citric acid solution (as provided or a commercial descaler) to clean. Follow the descaler's instructions.
- Wipe the main unit with a damp cloth. Do not immerse.

Blend Your Way Automatic or Manual Control!

Give your baby the perfect meal



Figure 6: Detachable components for easy cleaning, including dishwasher-safe parts.

7. TROUBLESHOOTING

Error Code	Issue	Solution
E1	Blending cup not properly installed.	Reposition the blending cup firmly until it clicks into place.
E2	Insufficient water level in the tank.	Refill the water tank to the marked line and restart the cycle.

For other issues, please contact MOMYEASY customer support.



Figure 7: Visual representation of E1 and E2 error codes and their solutions.

8. SPECIFICATIONS

- **Brand:** MOMYEASY
- **Model Name:** 2800e
- **Product Dimensions:** 10"D x 15"W x 10"H
- **Item Weight:** 5.52 pounds
- **Color:** Black
- **Special Feature:** 4-in-1 design (steams, blends, warms, sterilizes)
- **Blade Material:** Stainless Steel
- **Power Source:** AC
- **Is Dishwasher Safe:** Yes (detachable parts)
- **Material:** BPA-free, food-grade plastic and stainless steel

9. WARRANTY AND SUPPORT

MOMYEASY products are designed for durability and performance. For warranty information, product support, or to report any issues, please contact MOMYEASY customer service. Refer to the contact details provided in your product packaging or visit the official MOMYEASY website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Where can I find a recipe book or food preparation guides for the MOMYEASY 2800e Baby Food Processor?

While the standard instruction manual for the MOMYEASY 2800e does not include a full recipe book, it provides the following essential preparation guidelines for creating baby food:Preparation: Wash, peel, and cut ingredients (fruits, vegetables,...

[Read full answer](#)