Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LHZHENG 1

LHZHENG Emergency Rechargeable LED Light Bulb with Hook Instruction Manual

Model: 1 | Brand: LHZHENG

Introduction

Thank you for choosing the LHZHENG Emergency Rechargeable LED Light Bulb with Hook. This versatile LED bulb is designed to provide reliable illumination during power outages, for outdoor activities like camping and hiking, or as a standard energy-efficient light source in your home. Featuring a built-in rechargeable battery and multiple activation methods, it ensures you are never left in the dark.

What's in the Box

- 4x Rechargeable Light Bulb
- 4x Power Cap with Hook
- 1 x Instruction Manual

Specifications

Feature	Detail
Wattage	12W
Incandescent Equivalent	60W
Brightness	800-850 Lumens
Color Temperature	6000K Daylight White
Bulb Base	E26/E27
Battery Capacity	1500mAh
Emergency Mode Duration	Up to 14+ hours (at 10% brightness)
Dimmable	Yes (100%/50%/10% settings)
Material	Plastic

Usage	Indoor/Outdoor

Setup

1. Charging the Bulb

1. **Screw into a Fixture:** Screw the emergency bulb into any standard E26/E27 light socket in your home.
2. **Ensure Power:** Make sure the light switch for that fixture is in the 'ON' position. The bulb will automatically begin charging its internal battery.
3. **Full Charge:** Allow 6-8 hours for the bulb to achieve a full charge when connected to mains power.

2. Initial Use

Once fully charged, the bulb will function as a regular LED bulb when power is available. In the event of a power failure, the bulb will automatically switch to emergency mode if the light switch was left ON.

Operating Instructions

1. Regular Bulb Mode

When connected to a powered E26/E27 fixture, the bulb operates like a standard LED light. Use your wall switch to turn it on or off.

2. Emergency Mode (During Power Failure)

If the bulb is installed in a fixture and the power supply is interrupted, it will automatically activate its internal battery to provide light. The brightness can be adjusted using the existing light switch (if dimmable) or by using the button on the hook attachment.

3. Portable Use with Hook

1. **Attach Hook:** Screw the bulb into the provided power cap with hook.
2. **Activate:** Press the button located on the top of the hook to turn the bulb ON/OFF.
3. **Adjust Brightness:** Continue pressing the button to cycle through the three brightness settings (100%, 50%, 10%).
4. **Hang:** Use the hook to hang the bulb in tents, closets, or any area requiring portable light.



Image: Illustration showing four methods of using the emergency light bulb: as a regular bulb, with the screw-in hook, by hand touch, and using a wet tissue.

4. Manual Activation (Hand Touch / Wet Tissue)

These bulbs can be manually activated even without a fixture or hook, making them highly versatile.

- **Hand Touch:** After charging, hold the metal screw base with two fingers. Then, touch the top of the screw base with a wet fingertip. The bulb will light up.
- **Wet Tissue:** Use a wet paper towel to bridge the contacts on the metal screw base. The moisture will complete the circuit, and the bulb will illuminate.

5. Brightness Settings and Duration

The bulb offers three brightness levels to conserve battery life as needed:

- **100% Brightness:** Provides maximum light for approximately 2-3 hours.
- **50% Brightness:** Offers moderate light for about 7-8 hours.
- **10% Brightness:** Delivers low light for an extended duration of 14+ hours.



Image: Visual representation of the three adjustable brightness levels (10%, 50%, 100%) and their suggested uses (Night Light, Living Room, Camping).

Official Product Videos

Video: An overview of the LHZHENG Emergency Rechargeable Light Bulb with Hook, demonstrating its features and various uses.

Video: Demonstration of how the emergency bulbs can be used in both fixed and portable, wireless applications.

Maintenance

- **Regular Charging:** To ensure optimal performance during emergencies, keep the bulbs installed in powered fixtures so they remain fully charged.
- **Cleaning:** Wipe the exterior of the bulb with a dry, soft cloth. Do not use abrasive cleaners or immerse the bulb in water.
- **Storage:** If storing bulbs for an extended period, ensure they are fully charged before storage. Recharge them periodically (e.g., every 3-6 months) to maintain battery health and longevity.

Troubleshooting

- **Bulb does not light up in emergency mode:**
  - Ensure the bulb was fully charged (allow 6-8 hours for a complete charge).
  - Verify the light switch was in the 'ON' position when the power failed.
  - Check if the bulb is securely screwed into the fixture or hook attachment.
- **Bulb does not charge:**
  - Confirm the fixture has active power and the light switch is ON.
  - Ensure the bulb is correctly and firmly screwed into the E26/E27 base.
- **Light is dim or battery life is short:**
  - The bulb may not be fully charged. Allow for a complete 6-8 hour charging cycle.
  - Consider using a lower brightness setting (50% or 10%) for extended battery life during emergencies.

Warranty & Support

LHZHENG offers a **90-day refund policy and a lifetime warranty** for this product. We are committed to providing our customers with high-quality products and superior service. If you are dissatisfied with your purchase, we can offer you a new one or a 100% money-back guarantee.
For any support inquiries, please refer to the contact information provided with your purchase or visit the official LHZHENG Store on Amazon: LHZHENG Store.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B094N4V1ZH

More documents and user manuals: **https://manuals.plus/**