

AVV WLM250-WLA-8W-01

AVV Wall Sconces WLM250-WLA-8W-01 Instruction Manual

Model: WLM250-WLA-8W-01

INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your AVV Wall Sconces. These plug-in wall lamps feature a 3-way dimmable function with selectable color temperatures (2700K, 4000K, 5000K) and are designed for various indoor spaces such as bedrooms, living rooms, and hallways. Please read this manual thoroughly before installation and use.

WHAT'S IN THE BOX

Verify that all components are present before beginning installation:

- 2 x AVV Wall Sconces (with fabric linen shades)
- 2 x 8W LED A19 Bulbs (E26 base)
- Mounting Hardware (screws, wall anchors, mounting brackets)
- Instruction Manual

SETUP AND INSTALLATION

The AVV Wall Sconces are designed for easy, no-wiring installation. Follow these steps to set up your new wall lamps:

1. **Assemble the Lamp Shade:** Unroll the fabric shade. Insert the metal frames into the top and bottom edges of the fabric, securing them in place. Ensure the fabric is taut and the Velcro seam is aligned.
2. **Install the Bulb Socket:** Push the bulb socket assembly through the designated opening in the bottom metal frame of the shade. Secure it by screwing the plastic ring onto the top of the socket from inside the shade.
3. **Insert the LED Bulb:** Carefully screw the provided 8W LED A19 bulb into the E26 base socket.
4. **Mount the Sconce to the Wall:**

- Choose a desired location on the wall.
- Using the provided mounting hardware, attach the metal mounting bracket to the wall. Ensure it is level and secure.
- Align the keyhole slots on the back of the assembled scone with the screws on the wall bracket. Slide the scone down to lock it into place.

5. **Connect to Power:** Plug the 5.2-foot power cord into a standard 120V AC wall outlet.



Figure 1: Assembling the fabric lamp shade by inserting metal frames.



Figure 2: Installing the LED bulb into the E26 base socket.



Figure 3: Securing the mounting bracket to the wall.



Figure 4: Hanging the assembled scone onto the wall bracket.

Installation Video Guide

Your browser does not support the video tag.

Video 1: Official AVV installation guide demonstrating the assembly and mounting process for the wall lamp.

Your AVV Wall Sconce features a convenient in-line on/off switch that also controls the 3-way dimmable function.

1. **Turning On/Off:** Press the switch once to turn the lamp on. Press it again to turn it off.
2. **Changing Color Temperature:** When the lamp is on, repeatedly press the switch to cycle through the three available color temperatures: 2700K (Warm White), 4000K (Natural White), and 5000K (Cool White). The lamp will remember the last selected setting when turned off and on again.




Figure 5: Demonstrating the three selectable color temperatures of the sconce.



Figure 6: The in-line push button switch for controlling power and color temperature.

MAINTENANCE

To ensure the longevity and optimal performance of your AVV Wall Sconces, follow these simple maintenance guidelines:

- **Cleaning:** Disconnect the lamp from the power source before cleaning. Wipe the fabric shade and metal components with a soft, dry cloth. Avoid using abrasive cleaners or solvents.
- **Bulb Replacement:** The included LED bulb has an average life of 50,000 hours. If replacement is needed, ensure the lamp is unplugged. Use an 8W LED A19 bulb with an E26 base.

TROUBLESHOOTING

If you encounter any issues with your AVV Wall Sconces, refer to the following common troubleshooting steps:

- **Lamp Not Turning On:**

- Ensure the power cord is securely plugged into a working electrical outlet.
 - Check if the in-line switch is in the 'On' position.
 - Verify that the LED bulb is properly screwed into the socket.
 - Test the outlet with another device to confirm it has power.
- **Light Flickering or Dim:**
 - Ensure the bulb is fully tightened.
 - Try cycling through the color temperature settings to see if the issue persists across all modes.

If the problem persists after attempting these steps, please contact customer service for further assistance.

SPECIFICATIONS

Feature	Specification
Brand	AVV
Model Name	Wall Sconces
Model Number	WLM250-WLA-8W-01
Color	Beige
Material	Metal, Cotton, Linen
Style	Round
Product Dimensions	9.8"L x 5.1"W x 6.7"H
Power Source	Corded Electric
Installation Type	Plug-in
Special Feature	Dimmable, Wall Lamp Plug in
Light Source Type	LED
Shade Material	Linen
Voltage	120 Volts (AC)
Light Color	2700K/4000K/5000K Selectable
Wattage	8 watts
Bulb Base	E26
Controller Type	Push Button
Switch Type	Push Button
Brightness	810 Lumen

Feature	Specification
Mounting Type	Wall Mount
Assembly Required	Yes
Average Life	50,000 Hours

WARRANTY & SUPPORT

Your AVV Wall Sconces come with a **2-Year Warranty** from the date of purchase, covering defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.

Our dedicated customer support team is available to assist you with any questions, suggestions, or issues you may have regarding your AVV Wall Sconces. We are committed to providing prompt and helpful service.

For support, please refer to the contact information provided with your product packaging or visit the official AVV website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question