Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Zippo /
- > Zippo Windproof Lighter (Taurus #Z506) Instruction Manual

Zippo Z506

Zippo Windproof Lighter (Taurus #Z506) Instruction Manual

INTRODUCTION

This manual provides comprehensive instructions for the safe and effective use and maintenance of your Zippo Windproof Lighter, model Taurus #Z506. Please read all instructions carefully before initial use.

Product Overview




Image: Front view of the Zippo Windproof Lighter featuring a Taurus zodiac sign design.



Image: The Zippo lighter is packaged in a black gift box with the Zippo logo.



Image: Zippo logo with the text "Made in U.S.A." indicating its origin.



Image: Rear view of the Zippo Windproof Lighter, showing its smooth metal finish.



Image: A visual representation highlighting the Zippo lighter's metal case construction, refillable design, and the genuine bottom stamp for authenticity.



Image: Key features of the Zippo Windproof Lighter, including its windproof design, manufacturing location in Bradford, PA, USA, lifetime guarantee, and refillable nature with Zippo lighter fuel.

Important Safety Information

- · WARNING: Keep out of the reach of children.
- The lighter is not child resistant.
- Ignite lighter away from face and clothing.
- All new Zippo Windproof Lighters are empty and must be filled before use.
- When filled, it will contain flammable fluid.
- Never expose to heat above 122°F (50°C) or to prolonged sunlight.
- Never puncture or put in fire.
- Be sure flame is out after use. This lighter does not self-extinguish; close the cover to put it out.
- Fuel is a skin irritant; avoid overfilling.

For detailed safety information, refer to the instruction manual included in the packaging.

Your browser does not support the video tag.

Video: "Zippo Lighter-Getting Started" - This video provides an overview of the Zippo lighter's components, initial setup, and important safety tips for new users.

SETUP: FILLING YOUR ZIPPO LIGHTER

Your Zippo lighter is shipped without fuel for safety reasons. It must be filled with Zippo lighter fluid before use. Always use genuine Zippo fluid, flints, and wicks for optimal performance and safety.

- 1. Hold the lighter in one hand. Use the other hand to remove the lighter insert (the inner unit).
- 2. Lift the felt pad on the bottom of the insert to reveal the packing material in the fuel chamber.
- 3. Slowly saturate the packing material with Zippo lighter fluid. Stop filling when the fuel reaches the top of the packing material. Do not overfill.
- 4. Wipe any spilled fluid from the lighter and your hands before igniting. Return the lighter insert into the case.

5. Ensure the fuel can is closed and there is no spilled fuel in the vicinity before igniting.

If fuel gets on skin, wash the affected area. If irritation persists or worsens, consult a doctor.

NOTE :Zippo Lighter doesnt come pre filled with fluid.Lighter fluid sold separately. Please find and read User Manual under top box before use your new lighter.

To fill your Zippo lighter

- Fill only with Zippo fluid.
- Hold lighter in one hand. Use the other hand to remove lighter insert (1).
- Fill slowly, never overfill. Lift felt pad to reveal the packing material in the fuel chamber (2). Saturate the packing with Zippo lighter fluid. Stop filling when fuel reaches top of packing. If overfilled it can leak fuel. Fuel is a skin irritant.
- Wipe lighter and hands dry before igniting. Return lighter insert into case. If overfilled, do not put in pocket or next to skin. If fuel gets on skin, wash the affected area. If irritation persists or worsens, see a Doctor.
- Be sure fuel can is closed and there is no spilled fuel in vicinity before igniting. This is flammable fluid.


To re-flint your Zippo lighter


Remove screw (3) and attached spring at end of fuel chamber. Be sure old flint is removed from tube. Place new flint in tube and replace spring, screw lightly. Be sure screw is turned as far as it will go; if not, cover will not close properly. If wheel binds after new flint is inserted, turn wheel backwards a few times.

Wick Maintenance

When wick becomes black from carbon, pull it up with tweezers until clean wick appears (approx. 1 cm), then trim the end making it even with the chimney height. Perform this maintenance 1 or 2 times a year. It will be necessary to replace the wick after it has been trimmed more than 2 or 3 times. For more information visit the website listed.

Always use genuine Zippo fluid, flints and wicks. Zippo lighter fluid is specially formulated for Zippo windproof lighters. It is clean burning, quick lighting, and long lasting.







TIP: Keep extra flint supply under felt pad (4).

Image: Detailed instructions and diagrams illustrating the process of filling a Zippo lighter with fluid, including removing the insert and saturating the packing material.

OPERATING YOUR ZIPPO LIGHTER

Once your Zippo lighter is properly fueled, it is ready for use.

- 1. Open the lighter's lid.
- 2. With your thumb, firmly strike the flint wheel downwards to create a spark.
- 3. The spark will ignite the wick, producing a flame.
- 4. To extinguish the flame, simply close the lid. The Zippo lighter does not self-extinguish.

Always ensure the flame is completely extinguished before storing the lighter.

MAINTENANCE

Wick Maintenance

When the wick becomes black from carbon, pull it up with tweezers until clean wick appears (approximately 1 cm). Trim the end, making sure it is even with the chimney height. Perform this maintenance once or twice a year. It will be necessary to replace the wick after it has been trimmed two or three times.

Flint Replacement

1. Remove the lighter insert from the case.
2. Unscrew the flint spring from the bottom of the insert.
3. Remove the old flint and insert a new Zippo flint.
4. Replace the flint spring and screw. Ensure the screw is turned as far as it will go; if not, the cover will not close
properly. If the wheel binds after the new flint is inserted, turn the wheel backwards a few times to free it.




Image: An exploded view diagram illustrating the various components of a Zippo Windproof Lighter, including the wick, flint wheel, fuel chamber, and flint spring.

TROUBLESHOOTING

- **Lighter not igniting:** Ensure the lighter is filled with Zippo lighter fluid and that the flint is not worn down. Replace flint if necessary.
- Weak flame: Check the wick. If it's black or too short, trim or replace it. Ensure the lighter is adequately fueled.
- Lid not closing properly: Check for any obstructions or ensure the flint spring is fully screwed in.

SPECIFICATIONS

Feature	Detail
Brand	Zippo
Model	Taurus #Z506
Color	Multicolor (Taurus design)
Material	Metal
Item Weight	1 Ounces
Product Dimensions	2.25"L x 1.5"W x 0.5"Th
UPC	191693086041



Image: The Zippo gift box with its dimensions clearly marked.

WARRANTY

Your Zippo Windproof Lighter is backed by the world-famous Zippo Guarantee: "It works or we fix it free." Any Zippo pocket lighter, when returned to the factory, will be put in first-class mechanical condition free of charge, regardless of age or condition. The finish, however, is not guaranteed.

This guarantee provides specific legal rights, and you may also have other rights which vary by state. Other Zippo products carry their own specific warranties.



Image: The official Zippo Guarantee statement, detailing the lifetime repair policy for mechanical issues.

SUPPORT

For further assistance, product registration, or to purchase genuine Zippo accessories (fluid, flints, wicks), please visit the official Zippo website or contact their customer service department.

Zippo Manufacturing Company

33 Barbour Street

Bradford, PA 16701 U.S.A.

You can also visit the Zippo Store on Amazon for more products and information.

© 2025 Zippo Manufacturing Company. All rights reserved.

Related Documents - Z506



Zippo Arc Lighter Insert User Manual and Safety Guide

Comprehensive user manual and safety instructions for the Zippo Arc Lighter Insert, Double Beam model #Z8C23. Includes operating, ignition, recharging, compatibility, and safe battery disposal information.

	Zippo Flex Neck Utility Lighter XL: Instructions and Safety Guide Comprehensive instructions for refilling, operating, and adjusting the Zippo Flex Neck Utility Lighter XL, along with essential safety warnings and guidelines.
	Zippo Windproof Lighter: User Manual and Safety Guide Detailed instructions for operating, filling, replacing flints, and adjusting the wick of your Zippo windproof lighter, along with essential safety warnings and maintenance tips.
	Zippo Windproof Lighter Instructions and Care Comprehensive guide to using and maintaining your Zippo windproof lighter, including safety precautions and warranty information.
LIDED TO THE	Zippo Windproof Lighter: Instructions, Maintenance & Guarantee Learn how to properly fill, re-flint, and maintain your Zippo Windproof Lighter with this comprehensive instruction manual. Includes important safety warnings and details on the Zippo Lifetime Guarantee.
	Zippo Pipe Lighter Insert Instructions and Safety Guide Comprehensive instructions for installing, using, and maintaining the Zippo Pipe Lighter Insert, including essential safety warnings and tips for optimal performance.