

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Peg Perego](#) /

› [John Deere Mini Tractor 6 Volt Ride-On Instruction Manual](#)

Peg Perego IGED1142

John Deere Mini Tractor 6 Volt Ride-On Instruction Manual

Brand: Peg Perego | Model: IGED1142

1. PRODUCT OVERVIEW

The Peg Perego John Deere Mini Tractor is designed to provide endless excitement for young children. This 6-volt ride-on vehicle features working lights and sounds, an easy-to-use foot pedal accelerator, and is suitable for both indoor and outdoor play. It's built for heavy-duty adventure and comes complete with a rechargeable battery and charger.

Key Features:

- Drives at 1.5 mph with a responsive foot pedal accelerator.
- Equipped with working lights and realistic sounds for an immersive play experience.
- Recommended for ages 1.5 to 3 years, with a maximum weight capacity of 44 lbs.
- Versatile for use both indoors (rides well on carpet) and outdoors.
- Includes the Mini Tractor, a 6-volt rechargeable battery, and a recharger.



Figure 1.1: A young child enjoying the John Deere Mini Tractor.

2. SETUP AND ASSEMBLY

Adult assembly is required for the John Deere Mini Tractor. Please follow the instructions carefully to ensure proper and safe setup.

2.1. Initial Battery Charge

Before first use, the 6-volt rechargeable battery must be fully charged. The charger is included with the tractor. The charging port is located under the seat.

1. Locate the battery compartment, typically under the seat.
2. Connect the charger to the battery and then plug the charger into a standard wall outlet.
3. Allow the battery to charge for the recommended time (refer to the specific charging instructions in the included manual for exact duration, usually 18 hours for the first charge).
4. Once fully charged, disconnect the charger and secure the battery compartment.



Figure 2.1: Control panel showing battery indicator lights.



Figure 2.2: Rear view of the tractor, highlighting the anti-tip bar and potential hitch point for accessories.

3. OPERATING INSTRUCTIONS

Operating the John Deere Mini Tractor is straightforward, designed for young children to easily control.

3.1. Starting and Driving

1. Ensure the tractor is fully charged and the battery compartment is securely closed.
2. Press the red "START" button on the control panel to power on the tractor.
3. To move forward, press the foot pedal located on the right side of the tractor. The tractor will move at a speed of 1.5 mph.
4. To stop, simply release the foot pedal.
5. Steer the tractor using the steering wheel to change direction.

3.2. Lights and Sounds

- The tractor features working headlights that illuminate when the tractor is powered on.
- Press the yellow buttons on the control panel to activate various sounds and music.



Figure 3.1: The foot pedal for acceleration.



Figure 3.2: Front view showcasing the working headlights.

Video 3.1: Demonstration of the John Deere Mini Tractor's features and operation.

4. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your John Deere Mini Tractor.

- **Battery Care:** Recharge the battery after each use. For optimal battery life, avoid completely draining the battery. If storing the tractor for an extended period, charge the battery fully every 3 months.
- **Cleaning:** Wipe down the tractor with a damp cloth to remove dirt and debris. Avoid using harsh chemicals or

abrasive cleaners.

- **Storage:** Store the tractor in a dry, cool place away from direct sunlight and moisture.
- **Inspection:** Periodically check all screws, nuts, and bolts to ensure they are tight. Inspect wheels and axles for any signs of wear or damage.

5. TROUBLESHOOTING

If you encounter any issues with your John Deere Mini Tractor, refer to the common problems and solutions below:

Problem	Possible Cause	Solution
Tractor does not move.	Battery is low or not connected.	Charge the battery fully. Ensure battery connections are secure.
Lights or sounds not working.	Battery low, loose wiring, or damaged components.	Check battery charge. Inspect wiring connections. If components are damaged, contact customer support.
Tractor moves slowly.	Low battery, overloaded, or rough terrain.	Recharge battery. Ensure weight limit (44 lbs) is not exceeded. Move to smoother terrain.

If the problem persists after attempting these solutions, please contact Peg Perego customer support.

6. SPECIFICATIONS

Feature	Detail
Product Dimensions	24.25 x 16.25 x 17.5 inches (L x W x H)
Item Weight	12 pounds
Recommended Age	18 months - 3 years
Weight Capacity	44 lbs
Speed	1.5 mph
Battery	6-volt rechargeable
Model Number	IGED1142
Manufacturer	Peg Perego
Country of Origin	China



Figure 6.1: Product dimensions for the John Deere Mini Tractor.

7. SAFETY INFORMATION

Your child's safety is paramount. Please adhere to the following safety guidelines:

- **Adult Supervision:** Always ensure an adult is supervising the child during operation of the tractor.
- **Assembly:** Adult assembly is required. Ensure all parts are correctly assembled and secured before use.
- **Riding Environment:** Use the tractor in safe, open areas away from traffic, steep inclines, swimming pools, or other bodies of water.
- **Protective Gear:** Consider using appropriate protective gear, such as a helmet, especially when riding outdoors.
- **Weight Limit:** Do not exceed the maximum weight capacity of 44 lbs.
- **One Rider Only:** This tractor is designed for one rider at a time.


8. WARRANTY AND SUPPORT


For warranty information, product registration, or technical support, please visit the official Peg Perego website or contact their customer service department. Keep your purchase receipt for warranty claims.

Peg Perego Official Website: www.pegperego.com

Customer Service: Refer to the contact information provided in your product packaging or on the official website.

Related Documents - IGED1142

 <p>John Deere MINI TRACTOR</p> <p>Peg Perego</p> <p>John Deere</p> <p>ERIC</p> <p>CE</p>	<p>John Deere MINI TRACTOR - Instruction Manual</p> <p>Comprehensive instruction manual for the John Deere MINI TRACTOR (model IGED I176) by Peg Perego, covering assembly, operation, safety, maintenance, and troubleshooting.</p>
 <p>John Deere GROUND FORCE</p> <p>Peg Perego</p> <p>John Deere</p> <p>ERIC</p> <p>CE</p>	<p>John Deere Ground Force 12 Volt Ride-On Toy Manual</p> <p>Comprehensive manual for the John Deere Ground Force 12 Volt ride-on toy by Peg Perego. Includes assembly instructions, safety guidelines, operating instructions, and maintenance tips.</p>
 <p>John Deere GROUND FORCE</p> <p>Peg Perego</p> <p>John Deere</p> <p>ERIC</p> <p>CE</p>	<p>John Deere Ground Force Ride-On Toy User Manual</p> <p>Comprehensive user and assembly manual for the Peg Perego John Deere Ground Force ride-on toy, model IGOR0047. Includes safety guidelines, maintenance, and operating instructions.</p>
 <p>John Deere GROUND LOADER</p> <p>Peg Perego</p> <p>John Deere</p> <p>ERIC</p>	<p>John Deere Ground Loader 12 Volt User Manual</p> <p>Comprehensive user manual for the John Deere Ground Loader 12 Volt ride-on toy by Peg Perego. Includes assembly instructions, safety guidelines, operating instructions, and maintenance information.</p>
 <p>GAUCHO XP</p> <p>Peg Perego</p> <p>John Deere</p> <p>ERIC</p>	<p>Peg Perego Gaucho XP Ride-On Toy: Assembly & User Manual</p> <p>Official instruction manual for the Peg Perego Gaucho XP (model IGOD0555). Learn how to assemble, safely operate, and maintain this children's electric ride-on vehicle. Includes detailed guides and safety information.</p>



[Manuale di Istruzioni Peg Perego Polaris RZR 900 XP IGOD0554](#)

Scopri il manuale di istruzioni completo per il veicolo giocattolo Peg Perego Polaris RZR 900 XP (IGOD0554). Include guide dettagliate per l'assemblaggio, l'uso sicuro, la manutenzione e la risoluzione dei problemi, garantendo un'esperienza divertente e sicura per i giovani conducenti. Il veicolo è un prodotto con licenza ufficiale Polaris.