

[Manuals.plus](#) /

› [Birchlitland](#) /

› Birchlitland 4FT LED Birch Tree with 200 Warm White Fairy Lights Instruction Manual

Birchlitland 4FT 200L Warm White

Birchlitland 4FT LED Birch Tree with 200 Warm White Fairy Lights Instruction Manual

Model: 4FT 200L Warm White

INTRODUCTION

Thank you for choosing the Birchlitland 4FT LED Birch Tree. This product is designed to provide a warm and inviting glow for various indoor and outdoor settings. Featuring 200 warm white micro LED bulbs and a realistic birch-inspired finish, this tree offers flexible branches for easy shaping and decoration. Please read this manual thoroughly before assembly and use to ensure proper function and safety.



Image: The Birchlitland 4FT LED Birch Tree with 200 warm white lights, providing ambient lighting in a room.

SAFETY INFORMATION

- This product operates on a 3.5V low voltage system and is CE, ROSH certified for safety.
- Ensure the power adapter is connected to a suitable power outlet.
- Do not attempt to modify or repair the product yourself. Contact customer support if issues arise.
- Keep the power cord away from heat sources, sharp edges, and moving parts.
- For outdoor use, ensure all connections are secure and protected from excessive moisture. The product is IP44 waterproof, suitable for splashes but not submersion.
- Always unplug the tree from the power source before cleaning or when not in use for extended periods.

PACKAGE CONTENTS

Please verify that all components are present before beginning assembly:

- LED Birch Tree (4FT)
- Power Transformer (1 unit)

- Ground Stakes (4 units, for outdoor stability)
- Instruction Manual (this document)

Image: A visual representation of the accessories included with the Birchlitland LED Birch Tree, such as the transformer, ground stakes, and manual.

SETUP INSTRUCTIONS

Follow these steps to assemble your LED Birch Tree:

1. **Unpack Components:** Carefully remove all parts from the packaging.
2. **Assemble the Trunk:** The tree typically comes in two sections. Align the top section with the bottom section and insert it into the buckle, ensuring a secure fit.
3. **Attach to Base:** Secure the assembled trunk into the provided stand base.
4. **Shape the Branches:** The branches are flexible. Gently bend and spread them to achieve your desired tree shape. This also helps to evenly distribute the LED lights.
5. **Connect Power:** Plug the tree's power cord into the transformer, then plug the transformer into a standard electrical outlet.
6. **Outdoor Installation (Optional):** If using outdoors, place the tree in your desired location and use the four included ground stakes to secure the base firmly into the ground for stability.

Image: A diagram illustrating the simple assembly process of the LED Birch Tree, including connecting the trunk and securing it to the base.



Image: A detailed view of the tree's flexible branches, highlighting the integrated warm white LED lights that can be shaped as desired.

OPERATING INSTRUCTIONS

Once assembled and plugged in, the Birchlitland LED Birch Tree will illuminate. This model features 200 warm white LED bulbs that provide a consistent, subtle glow.

- **Power On/Off:** The tree is typically controlled by plugging and unplugging the power adapter from the electrical outlet.
- **Light Mode:** This specific model provides a steady warm white light. There are no adjustable light modes for this version.
- **Branch Shaping:** The branches are designed to be sturdy yet bendable. You can gently adjust them to create different looks or to hang lightweight ornaments for various occasions like Easter, Thanksgiving, or Christmas.

Your browser does not support the video tag.

Video: An official seller video showcasing the Birchlitland LED Birch Tree in various settings, demonstrating its illuminated appearance and decorative potential.

MAINTENANCE

To ensure the longevity and appearance of your LED Birch Tree, follow these maintenance guidelines:

- **Cleaning:** Dust the tree regularly with a soft, dry cloth. For stubborn dirt, lightly dampen the cloth with water and wipe gently. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** When not in use, especially during off-seasons, disassemble the tree and store it in its original packaging or a protective bag in a cool, dry place away from direct sunlight.
- **Branch Care:** While branches are flexible, avoid excessive or forceful bending to prevent damage to the internal wiring or structure.

TROUBLESHOOTING

If you encounter any issues with your Birchlitland LED Birch Tree, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Lights do not turn on.	No power, loose connection, faulty adapter.	Ensure the power adapter is securely plugged into both the tree and the wall outlet. Test the outlet with another device. Check for any visible damage to the cord or adapter.
Tree is unstable.	Improper assembly, uneven surface, insufficient anchoring (outdoor).	Verify that the trunk sections are fully engaged and the tree is firmly seated in its base. Place on a flat, stable surface. For outdoor use, ensure ground stakes are fully inserted.
Some LEDs are not lit.	Individual LED failure (rare), wiring issue.	LEDs are generally long-lasting. If a few individual lights are out, it typically does not affect the rest of the string. If a large section is out, contact customer support.

If these solutions do not resolve the issue, please contact Birchlitland customer support for further

assistance.

SPECIFICATIONS

Feature	Detail
Brand	Birchlitland
Model	4FT 200L Warm White
Product Dimensions (D x W x H)	7"D x 2"W x 35"H (approximate, assembled)
Color	Birch (tree), Warm White (lights)
Material	Metal
Item Weight	1.27 Kilograms
LED Count	200 micro LED bulbs
Voltage	3.5V Low Voltage
Waterproof Rating	IP44 (suitable for outdoor use, splash-proof)
Included Components	LED Light, Stake
Base Type	Stand
UPC	727536368786

WARRANTY INFORMATION

Birchlitland products are manufactured with quality and customer satisfaction in mind. While specific warranty details are not provided in this manual, please retain your proof of purchase. For any manufacturing defects or issues arising from normal use, contact Birchlitland customer service for assistance. Warranty terms typically cover defects in materials and workmanship for a limited period from the date of purchase.

CUSTOMER SUPPORT

For further assistance, questions, or to report any issues with your Birchlitland LED Birch Tree, please contact our customer support team. We are committed to providing exceptional service and will respond to your inquiries promptly.

- **Online Support:** Visit the official Birchlitland store on Amazon or their website for FAQs and contact forms.
- **Email:** Refer to your product packaging or purchase confirmation for the most current customer service email address.

