Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bajaj 830419-Pk3

Bajaj B22 12-Watt LED Bulb User Manual

Model: 830419-Pk3

1. Introduction

Thank you for choosing the Bajaj B22 12-Watt LED Bulb. This manual provides essential information for the safe installation, operation, and maintenance of your LED bulbs. Please read these instructions carefully before use and retain them for future reference.



Image: Bajaj B22 12-Watt LED Bulb with its packaging, showcasing the product design and key features on the box.

2. Safety Information

Always follow basic safety precautions when using electrical products to reduce the risk of fire, electric shock, and personal injury.

- **Disconnect Power:** Always ensure the power supply is switched off before installing or removing the bulb.
- **Correct Base:** Use only in fixtures designed for a B22 bulb base.
- **Indoor Use:** This bulb is designed for indoor use in dry locations. Do not expose to water or moisture.
- **Operating Voltage:** Ensure the operating voltage of your fixture matches the bulb's requirement (220-240 volts AC).
- **Do Not Disassemble:** Do not attempt to disassemble or modify the bulb. There are no user-serviceable parts inside.
- **Disposal:** Dispose of used bulbs according to local regulations.

3. Package Contents

The package contains the following items:

- 3 x Bajaj B22 12-Watt LED Bulbs

4. Setup and Installation

Follow these steps to safely install your Bajaj B22 12-Watt LED Bulb:

1. **Turn off Power:** Before installation, ensure the power supply to the light fixture is completely switched off at the main circuit breaker or wall switch.
2. **Remove Old Bulb (if applicable):** If replacing an existing bulb, allow it to cool down before carefully unscrewing it counter-clockwise from the fixture.
3. **Insert New Bulb:** Gently insert the Bajaj B22 LED bulb into the B22 bulb holder. Push it in and twist clockwise until it is securely seated. Do not overtighten.
4. **Restore Power:** Once the bulb is securely installed, restore power to the fixture.
5. **Test:** Turn on the light switch to confirm the bulb is working correctly.

5. Operating Instructions

The Bajaj B22 12-Watt LED Bulb operates like a standard light bulb.

- **Switch On/Off:** Use the standard wall switch connected to your light fixture to turn the bulb on or off.
- **Instant Brightness:** The LED bulb provides instant full brightness upon switching on, with no warm-up time.
- **Cool Day Light:** Emits a cool daylight color temperature (6500 Kelvin) suitable for various indoor environments.

6. Maintenance

The Bajaj B22 12-Watt LED Bulb requires minimal maintenance.

- **Cleaning:** Ensure the power is off and the bulb is cool before cleaning. Wipe the bulb gently with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **No User Serviceable Parts:** Do not attempt to open or repair the bulb.

7. Troubleshooting

If your LED bulb is not functioning as expected, refer to the following common issues and solutions:

Problem	Possible Cause	Solution
Bulb does not light up.	◦ No power to the fixture. ◦ Bulb not properly seated. ◦ Faulty bulb.	◦ Check the wall switch and circuit breaker. ◦ Ensure the bulb is securely twisted into the socket. ◦ Replace the bulb with a new one to test the fixture.
Bulb flickers.	◦ Loose connection. ◦ Incompatible dimmer switch (this bulb is not specified as dimmable).	◦ Turn off power, then re-seat the bulb firmly. ◦ Ensure the bulb is not used with an incompatible dimmer.

8. Specifications

Model Number	830419-Pk3
Brand	Bajaj

Light Type	LED
Wattage	12 Watts
Bulb Base	B22D
Light Colour	Cool Daylight
Colour Temperature	6500 Kelvin
Brightness	1050 Lumens
Operating Voltage	220-240 Volts (AC)
Average Life	25,000 Hours
Material	Polycarbonate (PC)
Net Quantity	3 Count
Item Weight	110 Grams
Dimensions (LxWxH)	10 x 5 x 5 Centimeters

9. Warranty Information

This Bajaj B22 12-Watt LED Bulb comes with a**2-year warranty** on the product from the date of purchase.
The warranty covers manufacturing defects under normal use. It does not cover damage resulting from improper installation, misuse, accidents, unauthorized repairs, or natural disasters. Please retain your purchase receipt as proof of purchase for warranty claims.

10. Customer Support

For any queries, assistance, or warranty claims, please contact Bajaj customer support.

- **Manufacturer:** Bajaj Electricals Ltd.
- **Website:** www.bajajelectricals.com (Please refer to the official website for the most current contact information.)
- **General Inquiries:** Refer to the contact section on the official Bajaj Electricals website for phone numbers or email support.

© 2023 Bajaj Electricals Ltd. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B094R9TRY1

More documents and user manuals: **https://manuals.plus/**