

[Manuals.plus](#) /

› [Pem](#) /

› Pem Edream Portable Fan User Manual

Pem AF-V913-BLACK

Pem Edream Portable Fan User Manual

Model: AF-V913-BLACK

INTRODUCTION

Thank you for choosing the Pem Edream Portable Fan. This user manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new fan. Designed for portability and long-lasting performance, this fan features an impressive 24-hour battery life and an adjustable height, making it suitable for various environments, from a desktop to a standing fan.

PRODUCT OVERVIEW

Key Features:

- **Extended Battery Life:** Up to 24 hours of cordless operation on a single charge.
- **Quick Charging:** Fully recharges in approximately 4.5 hours.
- **Adjustable Height:** Easily switch between a compact 9.3 cm (3.66 inches) and an extended 97.5 cm (38.39 inches) for versatile use as a table or standing fan.
- **Multiple Speed Settings:** Four adjustable fan speeds to suit your cooling needs.
- **Quiet Operation:** Operates at a low noise level of only 40 dB at maximum power.
- **Portable Design:** Lightweight and easy to transport for indoor and outdoor use.

Components:

The Pem Edream Portable Fan includes the main fan unit and a USB charging cable. Please ensure all components are present upon unboxing.

- Main Fan Unit (with integrated battery and adjustable stand)
- USB Charging Cable



Image: The Pem Edream Portable Fan shown in its compact table fan configuration, featuring the fan head, adjustable stand, and circular base.

SETUP

1. **Unboxing:** Carefully remove the fan and all accessories from the packaging.
2. **Initial Charge:** Before first use, fully charge the fan. Connect the USB charging cable to the fan's charging port and plug the other end into a compatible USB power adapter (not included) or a computer USB port. The charging indicator light will show the charging status. A full charge takes approximately 4.5 hours.
3. **Adjusting Height:**
 - To extend the fan, gently pull the fan head upwards from the base. The telescopic pole will extend.
 - To retract, push the fan head downwards until it reaches the desired height or is fully collapsed.
4. **Adjusting Angle:** The fan head can be manually tilted up or down to direct airflow.





Image: The Pem Edream Portable Fan shown fully extended to its maximum height, functioning as a standing fan.

OPERATING INSTRUCTIONS

1. **Power On/Off:** Locate the power button on the fan's base (often a touch-sensitive control). Press once to turn the fan on. Press and hold for a few seconds to turn it off.
2. **Adjusting Fan Speed:** While the fan is on, repeatedly press the power/speed button to cycle through the four available speed settings (Low, Medium, High, Turbo). The fan will indicate the current speed, possibly with LED indicators.
3. **Battery Status:** The fan may have indicator lights to show the remaining battery life. Refer to these lights to know when recharging is necessary.
4. **Charging During Use:** The fan can be used while it is charging, though it is recommended to fully charge it for optimal battery longevity.



Image: The Pem Edream Portable Fan with its head tilted upwards, demonstrating its adjustable angle feature.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your fan.

- **Cleaning:**
 - Always ensure the fan is turned off and unplugged before cleaning.
 - Use a soft, dry cloth to wipe down the exterior surfaces of the fan.
 - For dust accumulation on the fan blades or grille, use a soft brush or a vacuum cleaner with a brush attachment. Do not use water or harsh chemicals.
- **Storage:** When not in use for extended periods, collapse the fan to its most compact size and store it in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Battery Care:** To maintain battery health, avoid completely draining the battery frequently. If storing for a long time, charge the battery to about 50% every few months.



Image: The Pem Edream Portable Fan shown in its fully collapsed, compact form, ideal for storage or transport.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Fan does not turn on.	Battery is depleted. Power button not pressed correctly.	Charge the fan for at least 30 minutes. Press and hold the power button firmly for a few seconds.
Weak airflow.	Fan speed is too low. Grille or blades are dusty.	Increase the fan speed setting. Clean the fan grille and blades as per maintenance instructions.
Unusual noise during operation.	Fan is not on a stable surface. Obstruction in the fan blades.	Place the fan on a flat, stable surface. Turn off and unplug the fan, then check for any foreign objects obstructing the blades.
Fan does not charge.	Charging cable or adapter is faulty. Charging port is dirty.	Try a different USB cable and power adapter. Gently clean the charging port with a dry, soft brush.

SPECIFICATIONS

Attribute	Detail
Brand	Pem
Model Number	AF-V913-BLACK
Color	Black
Material	Plastic
Number of Speeds	4
Features	Adjustable Height
Item Weight	1.3 Kilograms
Electric Fan Design	Table Fan (convertible to standing fan)
Power Source	Battery Powered
Controller Type	Touchpad Control
Adjustable Height Range	9.3 cm to 97.5 cm (approx. 3.66 in to 38.39 in)
Noise Level (Max)	40 dB
Battery Life (Max)	24 Hours
Charging Time	Approx. 4.5 Hours

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the product packaging or contact the manufacturer directly. Keep your purchase receipt as proof of purchase.

Manufacturer: Pem

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B094RGRVJ4>

More documents and user manuals: <https://manuals.plus/>