## Orbegozo HOT 606

# Orbegozo HOT 606 Convection Oven

User Manual

## 1. Introduction

Thank you for choosing the Orbegozo HOT 606 Convection Oven. This appliance is designed to provide efficient and versatile cooking for a variety of dishes. With its 60-liter capacity, 2000W power, and multiple operating positions, it offers optimal performance for your culinary needs. Please read this manual carefully before using the oven for the first time to ensure safe and proper operation.




Figure 1: Orbegozo HOT 606 Convection Oven, front view.

## 2. Important Safety Instructions

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury.

- Read all instructions before operating the oven.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.

## 3. Product Overview

The Orbegozo HOT 606 oven features a robust design with intuitive controls for ease of use. It includes essential accessories for various cooking tasks.




Figure 2: Close-up of the control panel, showing temperature, function, and timer knobs.

## Components:

- **Temperature Control Knob:** Adjusts temperature up to 230°C.
- **Function Selector Knob:** Selects one of 6 operating positions (heating elements configuration).
- **Timer Knob:** Sets cooking time up to 90 minutes with an audible signal.
- **Power Indicator Light:** Illuminates when the oven is operating.
- **Oven Door:** Abatible door with double glass for heat retention.
- **Interior Light:** For monitoring cooking progress.
- **Baking Tray:** For collecting drips or baking.
- **Wire Rack:** For placing dishes or food.
- **Tray Handle:** For safe removal of hot trays and racks.



Figure 3: Included accessories: wire rack, baking tray, and tray handle.

## 4. Setup

Before first use, ensure the oven is properly set up.

1. **Unpacking:** Remove all packaging materials, including any internal packing and accessories.
2. **Placement:** Place the oven on a stable, heat-resistant, and flat surface. Ensure there is adequate ventilation space (at least 10 cm) around all sides of the oven for proper air circulation. Do not place it near flammable materials or heat sources.
3. **Initial Cleaning:** Wipe the interior and exterior of the oven with a damp cloth. Wash the baking tray, wire rack, and tray handle with warm, soapy water. Dry thoroughly.
4. **First Use Burn-off:** It is recommended to run the oven empty for about 15 minutes at the maximum temperature (230°C) with the convection function on. This will burn off any manufacturing residues and odors. A slight smoke or odor is normal during this process. Ensure the area is well-ventilated.

## 5. Operating Instructions

The Orbegozo HOT 606 offers versatile cooking options with its intuitive controls.



Figure 4: Oven interior with door open, illustrating space for cooking.

## Basic Operation:

1. **Prepare Food:** Place your food on the baking tray or wire rack. Insert the tray/rack into the desired slot inside the oven.
2. **Set Temperature:** Turn the **Temperature Control Knob** (top knob) to your desired cooking temperature, up to 230°C.
3. **Select Function:** Turn the **Function Selector Knob** (middle knob) to choose one of the 6 operating positions. These positions control which heating elements are active (top, bottom, or both) and whether the convection fan is on. The convection function ensures homogeneous heat distribution for optimal cooking.
4. **Set Timer:** Turn the **Timer Knob** (bottom knob) to your desired cooking time, up to 90 minutes. The oven will start heating, and the power indicator light will illuminate. The oven will automatically turn off and sound a bell when the set time has elapsed.
5. **Monitoring:** Use the interior light to monitor cooking progress without opening the door.
6. **Completion:** Once cooking is complete, carefully remove the food using oven mitts and the provided tray handle.

## Cooking Functions:

The 6 operating positions allow for various cooking methods:

- **Upper Heating:** Ideal for grilling or browning the top of dishes.
- **Lower Heating:** Suitable for baking bases or slow cooking.
- **Upper and Lower Heating:** Standard baking for most dishes.
- **Upper Heating + Convection:** For faster browning with even heat.
- **Lower Heating + Convection:** For even cooking of bases with air circulation.
- **Upper and Lower Heating + Convection:** Recommended for most baking and roasting, ensuring uniform cooking throughout.




Figure 5: Illustration of the convection cooking system, ensuring even heat distribution.

## 6. Maintenance and Cleaning

Regular cleaning and maintenance will prolong the life of your oven and ensure optimal performance.

1. **Before Cleaning:** Always unplug the oven from the power outlet and allow it to cool completely before cleaning.
2. **Interior Cleaning:** Wipe the interior surfaces with a damp cloth and mild detergent. For stubborn stains, use a non-abrasive oven cleaner designed for conventional ovens. Do not use abrasive pads or harsh chemicals that could damage the interior coating.
3. **Exterior Cleaning:** Clean the exterior with a soft, damp cloth. Do not use abrasive cleaners or scourers.
4. **Accessories:** The baking tray, wire rack, and tray handle can be washed in warm, soapy water. Rinse thoroughly and dry completely before storing or re-inserting into the oven.
5. **Door Cleaning:** Clean the glass door with a glass cleaner or a damp cloth. Avoid spraying cleaner directly onto the door seals.
6. **Storage:** When not in use for extended periods, ensure the oven is clean and dry. Store it in a cool, dry place.

## 7. Troubleshooting

If you encounter any issues with your Orbegozo HOT 606 oven, refer to the following common problems and solutions:

| Problem | Possible Cause | Solution |
|---|---|---|
| Oven does not turn on. | Not plugged in; power outage; timer not set. | Ensure the oven is securely plugged into a working outlet. Check your household's circuit breaker. Turn the timer knob to the desired cooking time. |
| Oven not heating properly. | Incorrect temperature or function setting; door not closed properly. | Verify temperature and function settings. Ensure the oven door is fully closed. |
| Excessive smoke during first use. | Manufacturing residues burning off. | This is normal. Ensure adequate ventilation. It should subside after the initial burn-off. |

| Problem | Possible Cause | Solution |
|---|---|---|
| Food cooking unevenly. | Incorrect function setting; overcrowding the oven. | Ensure the correct function (e.g., convection) is selected for even cooking. Avoid overcrowding the oven to allow proper air circulation. |

If the problem persists after trying these solutions, please contact customer support.

## 8. Specifications

| Feature | Specification |
|---|---|
| Brand | Orbegozo |
| Model Number | 01205555 (HOT 606) |
| Color | Multicolor (typically black) |
| Dimensions (L x W x H) | 80 x 60 x 80 cm (approximate external) |
| Weight | 10.9 kg |
| Power | 2000 W |
| Capacity | 60 Liters |
| Temperature Range | Up to 230°C |
| Timer | Up to 90 minutes |
| Special Features | Adjustable Thermostat, Convection Function, Interior Light, 6 Operating Positions |
| Included Components | Oven racks, crumb tray/baking tray, tray handle |

## 9. Warranty and Support

Your Orbegozo HOT 606 Convection Oven comes with a standard manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions, including the warranty period and coverage details.
For technical assistance, spare parts, or warranty claims, please contact Orbegozo customer support. You can find contact information on the official Orbegozo website or on your product packaging.
It is recommended to keep your purchase receipt as proof of purchase for warranty purposes.

© 2024 Orbegozo. All rights reserved.