

Manuals.plus /

› APEX GARDEN /

› APEX GARDEN Gazebo Mosquito Netting Instruction Manual for Allen + roth Model GF-18S112B

APEX GARDEN GF-18S112B

APEX GARDEN Gazebo Mosquito Netting Instruction Manual

For Allen + roth Gazebo Model GF-18S112B

1. PRODUCT OVERVIEW

This document provides instructions for the APEX GARDEN Replacement Mosquito Netting, specifically designed to provide insect protection for your compatible Allen + roth Gazebo. This product is the screen net only and requires the existing steel slide rails of your gazebo for installation.




Image 1.1: The APEX GARDEN Mosquito Netting installed on an Allen + roth gazebo, providing an enclosed space.

2. COMPATIBILITY

This replacement mosquito netting is exclusively designed for use with the **Allen + roth Wood Looking Hand Paint Metal Square Semi-Gazebo, Model #GF-18S112B (also known as #0875051)**. It is essential to verify your gazebo's model number to ensure proper fit and function. This netting requires the existing steel slide rail system of the specified gazebo model for installation.



Image 2.1: The mosquito netting installed on a gazebo. This image clarifies that only the screen net is included; the triangle net, slide rail, and metal structure are not part of this product.

3. SAFETY GUIDELINES

- Ensure the gazebo structure is securely anchored to prevent tipping over, especially in windy conditions.
- Avoid overloading the gazebo structure with additional items or excessive weight.
- Exercise caution during the assembly and disassembly of the netting to prevent injury.
- Follow all handling instructions for the netting components.
- Maintain a safe distance from open flames. Although the fabric is CPAI-84 US Standard fire-retardant, it is not fireproof.

4. PACKAGE CONTENTS

Please verify that all items listed below are present in your package:

- 1x APEX GARDEN Mosquito Netting (Black)
- Plastic J-shape hooks (pre-attached or included separately)

5. SETUP AND INSTALLATION

Prerequisites: Ensure your Allen + roth Gazebo Model #GF-18S112B is fully assembled and has the necessary steel slide rails installed. This netting requires these rails for proper attachment.

1. **Unpack:** Carefully remove the mosquito netting and J-shape hooks from the packaging.
2. **Identify Panels:** The netting consists of multiple panels designed to fit each side of your gazebo. Orient the panels correctly.
3. **Attach Hooks:** If not pre-attached, insert the plastic J-shape hooks into the grommets located along the top edge of each netting panel.
4. **Hang Netting:** Starting from one corner, slide the J-shape hooks into the steel slide rails of your gazebo. Ensure the netting hangs evenly and smoothly around the perimeter.
5. **Secure Sides:** Zip the panels together where they meet at the gazebo posts to create a continuous, enclosed space.

6. **Adjust:** Adjust the netting to ensure it reaches the ground and provides full coverage, minimizing any gaps.



Image 5.1: A close-up view demonstrating how the mosquito netting attaches to the gazebo's steel slide rail using the integrated hooks. This image confirms the netting is designed for Model GF-18S112B ONLY.



Image 5.2: An additional perspective of the mosquito netting fully installed, showcasing its fit and coverage around the gazebo structure.

6. OPERATING INSTRUCTIONS

- **Insect Protection:** To effectively deter insects, ensure all netting panels are zipped closed, creating a complete enclosure.
- **Access:** Utilize the zippered openings on the netting for convenient entry and exit from the gazebo.
- **Tying Back:** When an open-air environment is desired, or when the netting is not needed, gather the panels and secure them to the gazebo posts using the integrated fabric ties.







Image 6.1: A close-up view illustrating how the mosquito netting can be neatly tied back to a gazebo post when not in use, allowing for an open space.

7. CARE AND MAINTENANCE

- **Cleaning:** Clean the netting periodically with a mild soap solution and water. Rinse thoroughly with clean water and allow it to air dry completely before storing or re-installing. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** When not in use for extended periods, such as during off-season or severe weather, remove the netting, clean it, and store it in a dry, protected area away from direct sunlight and extreme temperatures to prolong its lifespan.
- **Inspection:** Regularly inspect the netting fabric, zippers, and hooks for any signs of wear, tears, or damage. Replace damaged components as needed to maintain effectiveness.

8. TROUBLESHOOTING

- **Netting Does Not Fit:**
 - Verify your gazebo model number. This netting is specifically designed for Allen + roth Model #GF-18S112B / #0875051.
 - Ensure you have the required steel slide rails installed on your gazebo, as this netting attaches to them.
- **Gaps at Bottom / Bugs Getting Under:**
 - Ensure the netting is properly installed and stretched to its full extent around the gazebo perimeter.
 - Check for any obstructions preventing the netting from hanging straight to the ground.
 - Consider adding weights to the bottom hem or securing the bottom edge if necessary (user modification).
- **Zipper Issues:**
 - Ensure zipper teeth are aligned before attempting to zip.
 - Avoid forcing zippers if they snag. Gently work them free to prevent damage.

9. PRODUCT SPECIFICATIONS

Brand	APEX GARDEN
Model Compatibility	Allen + roth Gazebo Model #GF-18S112B / #0875051
Material	100% Polyester
Color	Black
Features	Weather-resistant, CPAI-84 US Standard fire-retardant fabric
Item Weight	7.2 Pounds (approximate)
Assembly Required	Yes (for installation)

10. WARRANTY AND CUSTOMER SUPPORT

For specific warranty information regarding your APEX GARDEN Mosquito Netting, please refer to the documentation included with your purchase or contact APEX GARDEN directly. Keep your proof of purchase, such as a receipt or order confirmation, as it may be required for any warranty claims or customer support inquiries.

You can typically find contact information for APEX GARDEN on their official website or through the retailer from whom you purchased the product.