Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- EverBrite /
- > EverBrite 3-Pack Wireless LED Puck Lights with 12 RGB Colors and Remote Control Instruction Manual

EverBrite E007069

EverBrite 3-Pack Wireless LED Puck Lights with 12 RGB Colors and Remote Control Instruction Manual

Brand: EverBrite | Model: E007069

1. Introduction

This manual provides detailed instructions for the EverBrite 3-Pack Wireless LED Puck Lights. These versatile lights offer 12 RGB color options, remote and touch control, and timing functions, making them suitable for various indoor lighting needs.

2. WHAT'S INCLUDED

- 3 x EverBrite Wireless LED Puck Lights
- 1 x Remote Control
- 9 x AAA Batteries (3 per light)
- 3 x Double-Sided Adhesive Tapes



Image: Contents of the EverBrite 3-Pack Wireless LED Puck Lights package, including three puck lights, a remote control, nine AAA batteries, and three adhesive tapes.

3. SETUP AND INSTALLATION

3.1. Battery Installation

- 1. Gently twist the back cover of each puck light counter-clockwise to open the battery compartment.
- 2. Insert 3 AAA batteries into each light, ensuring correct polarity (+/-).
- 3. Replace the back cover by aligning the notches and twisting clockwise until secure.

Image: Step-by-step illustration of opening the battery cover and inserting AAA batteries into the puck light.

3.2. Mounting the Lights

- 1. Clean the surface where you intend to mount the light. Ensure it is dry and free of dust.
- 2. Peel off one side of the double-sided adhesive tape and apply it firmly to the back of the puck light.

3. Peel off the other side of the adhesive tape and press the light firmly onto the desired surface for at least 30 seconds.

Image: Illustration showing the application of double-sided adhesive tape to the back of the puck light for mounting.

4. OPERATING INSTRUCTIONS

4.1. Touch Control

Press the center of the light to turn it ON/OFF. Repeated presses will cycle through preset colors (White, Red, Green, Blue) and then OFF.



Image: Demonstrates the touch control feature of the puck light, cycling through white, red, green, and blue colors.

4.2. Remote Control

The included remote control allows for comprehensive management of the puck lights from up to 20 feet away. Point

the remote directly at the lights for optimal response.

Image: A detailed view of the remote control, highlighting buttons for ON/OFF, color selection, brightness adjustment, and timing functions.

- ON/OFF: Press the "ON" button to turn on all connected lights. Press "OFF" to turn them off.
- Color Selection: Choose from 12 RGB colors using the color palette buttons.
- White Light: Press the "W" button for a pure white light.
- Brightness Adjustment: Use the brightness up/down buttons to increase or decrease the light intensity.
- Flash Mode: Press "FLASH" to activate a mode where 7 colors flash gradually.
- Fade Mode: Press "FADE" to activate a mode where 7 colors dimmable gradually.
- Timer Functions: Set the lights to automatically turn off after 30 minutes ("30 min") or 60 minutes ("60 min").

Your browser does not support the video tag.

Video: Demonstration of the EverBrite 3-Pack Tap Lights, showcasing battery installation, adhesive mounting, and remote control functions including color changes, brightness adjustment, and timer settings.

5. MAINTENANCE

5.1. Battery Replacement

When the lights dim or stop responding, it's time to replace the AAA batteries. Follow the battery installation steps in Section 3.1. For optimal performance, replace all three batteries in a puck light at the same time.

5.2. Cleaning

Wipe the lights with a soft, dry cloth. Do not use abrasive cleaners or immerse the lights in water.

6. TROUBLESHOOTING

- **Lights not turning on:** Ensure batteries are correctly installed and not depleted. Check if the remote control battery is functional.
- **Remote not responding:** Point the remote directly at the lights. Ensure there are no obstructions. Replace the remote's battery if necessary.
- **Lights falling off:** Ensure the mounting surface is clean and dry before applying adhesive. For heavy-duty applications or rough surfaces, consider additional mounting solutions.
- Short battery life: Continuous use of color-changing modes (Flash/Fade) or high brightness settings can deplete batteries faster. Using timer functions can help conserve battery life.

7. SPECIFICATIONS

Feature	Detail
Model Name	E007069
Brand	EverBrite
Style	Round Tap Light
Light Source Type	LED
Brightness	80 Lumens
Number of Colors	12 RGB Colors + White
Control Method	Remote, Touch
Power Source	Battery Powered (3 AAA per light)
Product Dimensions	2.4"D x 2.4"W x 1.22"H
Item Weight	9.91 ounces (total for 3-pack)
Material	Plastic (Acrylonitrile Butadiene Styrene)
Special Features	12 RGB Colors, Flash/Fade Mode, Remote Control, Timing Function, Touch Control
Indoor/Outdoor Usage	Indoor
Water Resistance Level	Not Water Resistant

8. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact EverBrite customer service directly. Contact details are typically available on the manufacturer's website or through your retailer.

© 2023 EverBrite. All rights reserved.

Related Documents - E007069



EverBrite E011179A UV and White Light Flashlight User Manual

Comprehensive user manual for the EverBrite E011179A UV and White Light Flashlight, detailing features, operation, battery installation, safety warnings, and maintenance. Includes product specifications and EC declaration of conformity.



EverBrite 4-Pack Mini LED Aluminum Flashlight - User Manual & Features

Comprehensive user manual for the EverBrite 4-Pack Mini LED Aluminum Flashlight (E000015). Learn about features, specifications, usage, and safety warnings for this versatile portable LED torch.



EverBrite Mini LED Flashlight User Manual

Official user manual for the EverBrite Mini LED Flashlight. Learn about its features, specifications, usage instructions, safety warnings, and environmental guidelines for this lightweight and portable torch.



EverBrite Rechargeable Headlamp with Motion Sensor User Manual

User manual for the EverBrite Rechargeable Headlamp with Motion Sensor (Models E021042AUK, E021043AUK, E021044AUK), detailing features, specifications, operating instructions, and safety guidelines.



EverBrite 2-Piece Magnetic Pick Up Tool Set User Manual

User manual for the EverBrite 2-Piece Magnetic Pick Up Tool Set (Model E007068). Provides details on product specifications, instructions for use, safety warnings, and environmental disposal information.



EverBrite 80LM Aluminum LED Flashlight User Manual

Comprehensive user manual for the EverBrite 80LM Aluminum LED Flashlight. Includes sections on package contents, battery installation, operating instructions (modes, focus adjustment), technical specifications, usage and maintenance advice, safety warnings, and environmental disposal guidelines.