

OUTON MF18812

OUTON LED Floor Lamp MF18812 User Manual

Model: MF18812

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your OUTON LED Floor Lamp, Model MF18812. This lamp features a 27W main torchiere light and a 7W adjustable reading light, both with dimmable brightness and four color temperature settings. Control is available via both touch and remote.

INCLUDED COMPONENTS

Please check the package contents to ensure all items are present:

- Floor Lamp (multiple sections)
- Remote Control
- User Manual (this document)

SETUP AND ASSEMBLY

The OUTON LED Floor Lamp is designed for easy assembly without the need for additional tools. Follow these steps:

1. Carefully unpack all components from the box.
2. Screw each section of the lamp pole together clockwise until secure. Ensure the power cord passes freely through the pole sections.
3. Attach the lamp base to the bottom pole section by screwing it clockwise until firm.
4. Connect the power adapter to the lamp's power input and then plug it into a standard electrical outlet.

27W 2400LM + 7W 400LM LED Floor Lamp & Reading Lamp

Illuminate the entire room and care for your eyes.



Energy
Saving



No
Overheat



Eyes
Caring



Long
Lifespan



Image: Lamp dimensions and adjustable components. The main lamp head can rotate 350 degrees and adjust 85 degrees up/down. The side reading lamp can bend 90 degrees. Total height is 70.5 inches, base diameter is 9.8 inches, and the lamp weighs 6.06 lbs.

OPERATING INSTRUCTIONS

Your OUTON LED Floor Lamp can be controlled using either the integrated touch controls on the lamp pole or the included remote control. Both methods allow independent control of the main torchiere lamp and the reading lamp.

Touch Control

The touch panel is located on the lamp pole. It provides direct access to power, brightness, and color temperature settings for both lamps.

- **Reading Lamp On/Off:** Touch the dedicated button for the reading lamp.
- **Adjust Brightness:** Use the '+' and '-' buttons to increase or decrease the brightness level (5% to 100%).
- **Change Color Temperature (CCT):** Cycle through 4 color temperatures (3000K Warm, 4000K Warm White, 5000K Cool White, 6000K Daylight White) using the CCT button.
- **Main Lamp On/Off:** Touch the dedicated button for the main torchiere lamp.

4 Color Temperatures



Image: Detailed view of the touch control panel on the lamp pole and the remote control. The touch controls include separate on/off buttons for the reading and main lamps, brightness adjustment buttons (+/-), and a color temperature (CCT) button. The remote control also offers similar functions and is magnetic for convenient storage.

Remote Control

The magnetic remote control allows you to operate the lamp from a distance of up to 32.8 feet. It can be conveniently attached to the lamp pole or other metal surfaces.

- **Power On/Off:** Separate buttons for main and reading lamps.
- **Brightness Adjustment:** Dedicated buttons to increase or decrease brightness.
- **Color Temperature Adjustment:** Buttons to cycle through the 4 color temperature settings.
- **Memory Function:** The lamp remembers your last brightness and color temperature settings when turned back on.
- **1-Hour Timer:** Activate a 1-hour automatic shut-off timer by long-pressing the on/off touch button.

Your browser does not support the video tag.


Video: Demonstration of the OUTON LED Floor Lamp with Adjustable Reading Lamp, showcasing its features and controls.

Your browser does not support the video tag.

Video: A brief overview of the OUTON LED floor lamp with its reading light, demonstrating its functionality.

KEY FEATURES

- **Dual Control System:** Operate the lamp conveniently with either the integrated touch controls or the magnetic remote control. Both lamps can be controlled independently.
- **Adjustable Brightness and Color Temperature:** Both the main 27W/2400LM torchiere lamp and the 7W/400LM reading lamp offer stepless dimming from 5% to 100% and four color temperature options (3000K, 4000K, 5000K, 6000K).
- **Memory Function:** The lamp retains your last used brightness and color temperature settings when powered off and on.
- **1-Hour Timer:** Activate a 1-hour automatic shut-off timer by long-pressing the on/off touch button.
- **Long Lifespan:** Equipped with LEDs designed for over 50,000 hours of operation, reducing the need for frequent bulb replacement.
- **Stable and Safe Design:** Features a wide (9.8 inch diameter) and weighted base (6.06 lbs) to ensure stability and prevent accidental tipping. The lamp's slender design allows it to fit into narrow spaces.
- **Adjustable Lamp Heads:** The main lamp head can rotate up to 350 degrees and adjust 85 degrees vertically. The side reading lamp features a flexible gooseneck that can bend up to 90 degrees for precise illumination.



**1 Hour Timer &
Memory Function**



Image: Visual representation of the four available color temperatures (Warm, Warm White, Cool White, Daylight) and the stepless dimming capability from 5% to 100% brightness.



Image: Illustration of the 1-hour timer and memory function, indicating how the lamp retains settings and can be set to turn off automatically.

MAINTENANCE

To ensure the longevity and optimal performance of your OUTON LED Floor Lamp, follow these simple maintenance guidelines:

- **Cleaning:** Disconnect the lamp from the power source before cleaning. Use a soft, dry cloth to wipe down the lamp pole and light heads. Avoid abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish or electronic components.
- **Bulb Replacement:** The integrated LED lights are designed for a long lifespan (50,000+ hours) and are not user-replaceable. Do not attempt to disassemble the light heads.
- **Cord Care:** Regularly inspect the power cord for any signs of damage, fraying, or kinks. If damage is found, discontinue use and contact customer support.
- **Remote Control:** Replace the AAA batteries in the remote control when its range or responsiveness decreases. Ensure correct polarity when inserting new batteries.

TROUBLESHOOTING

If you encounter any issues with your OUTON LED Floor Lamp, please refer to the following

troubleshooting tips:

Problem	Possible Cause	Solution
Lamp does not turn on.	• Power cord not properly plugged in. • Power outlet is not active. • Remote control batteries are dead or incorrectly inserted.	• Ensure the power cord is securely plugged into both the lamp and the wall outlet. • Test the outlet with another device to confirm it is working. • Replace remote control batteries, ensuring correct polarity. Try using touch control.
Remote control is unresponsive.	• Batteries are low or dead. • Remote is too far from the lamp. • Obstruction between remote and lamp.	• Replace batteries. • Ensure you are within the 32.8 ft operating range. • Remove any objects blocking the line of sight between the remote and the lamp.
Brightness or color temperature cannot be adjusted.	• Incorrect button pressed. • Temporary electronic glitch.	• Refer to the "Operating Instructions" section for correct button usage. • Unplug the lamp for 30 seconds, then plug it back in to reset.

SPECIFICATIONS

Feature	Detail
Model Number	MF18812
Main Lamp Wattage	27W
Main Lamp Lumens	2400LM
Reading Lamp Wattage	7W
Reading Lamp Lumens	400LM
Light Source Type	LED
Color Temperatures	3000K, 4000K, 5000K, 6000K
Dimming Range	5% - 100% Stepless
Control Method	Remote Control, Touch Control
Remote Range	Up to 32.8 feet
Lifespan	50,000+ Hours
Product Dimensions (D x W x H)	9.9"D x 9.9"W x 70.5"H
Base Diameter	9.8 Inches

Feature	Detail
Item Weight	2.75 Kilograms (6.06 lbs)
Cable Length	7.3 Feet
Power Source	Corded Electric
Voltage	110 Volts
Material	Metal (Base), Plastic (Shade)
Indoor/Outdoor Usage	Indoor

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official OUTON website. Keep your purchase receipt as proof of purchase for any warranty claims.

Manufacturer: OUTON