JBL Tune 760NC Blue

JBL Tune 760NC Wireless Over-Ear Noise Cancelling Headphones User Manual

Model: Tune 760NC Blue | Brand: JBL

Introduction

This manual provides comprehensive instructions for the operation, maintenance, and troubleshooting of your JBL Tune 760NC Wireless Over-Ear Noise Cancelling Headphones. Please read this manual thoroughly before using your headphones to ensure proper function and longevity of the device. The JBL Tune 760NC headphones are designed to deliver high-quality audio with active noise cancellation, providing an immersive listening experience.

What's in the Box

Upon unboxing your JBL Tune 760NC headphones, please verify that all components listed below are present:

- JBL Tune 760NC Headphones
- USB-C Charging Cable
- Detachable Audio Cable (3.5mm)
- Quick Start Guide (separate document)
- Safety Sheet (separate document)
- Warranty Card (separate document)

Image: The JBL Tune 760NC headphones shown with their included USB-C charging cable and detachable 3.5mm audio cable.

Controls and Connections

Familiarize yourself with the physical controls and connection ports on your JBL Tune 760NC headphones:

- **Power Button:** Located on the right earcup, used for powering on/off and initiating Bluetooth pairing.
- **Volume Up/Down Buttons:** Adjusts audio playback volume.
- **Multi-function Button:** Controls playback (play/pause), track skipping (next/previous), and call management (answer/end calls).
- **ANC Button:** Activates or deactivates Active Noise Cancelling.

- **USB-C Port:** For charging the headphones.
- **3.5mm Audio Jack:** For wired connection using the detachable audio cable.
- **Microphone:** Integrated for hands-free calls and voice assistant commands.
- **LED Indicator:** Provides status updates for power, battery, and Bluetooth connection.



Image: A detailed view of the right earcup, highlighting the power, volume, multi-function, and ANC buttons, along with the USB-C charging port and 3.5mm audio jack.

Setup

Powering On/Off

- To **Power On**: Press and hold the Power button for 2 seconds. The LED indicator will light up.
- To **Power Off**: Press and hold the Power button for 2 seconds. The LED indicator will turn off.

Bluetooth Pairing

The JBL Tune 760NC headphones support Google Fast Pair for Android devices and multi-point connection for seamless switching between devices.

1. Ensure the headphones are powered off.
2. Press and hold the Power button for 5 seconds until the LED indicator flashes blue rapidly, indicating pairing mode.
3. On your device (smartphone, tablet, laptop), enable Bluetooth and search for "JBL Tune 760NC" in the list of available devices.
4. Select "JBL Tune 760NC" to connect. The LED indicator will turn solid blue once connected.
5. For **Google Fast Pair**: If you have an Android device, simply power on the headphones near your device. A pop-up notification will appear on your screen, prompting you to connect. Tap to pair.
6. For **Multi-Point Connection**: After pairing with the first device, repeat steps 2-4 to pair with a second device. The headphones will automatically switch between the two connected devices based on audio input.

Wired Connection

You can use the included detachable 3.5mm audio cable for a wired connection, which is useful when battery is low or for devices without Bluetooth.

1. Plug one end of the 3.5mm audio cable into the audio jack on the left earcup of the headphones.
2. Plug the other end into the 3.5mm audio output of your audio source (e.g., smartphone, laptop, MP3 player).
3. Note: Active Noise Cancelling and some button functionalities may still work in wired mode, depending on the headphone's power status.

Operating Instructions

Active Noise Cancelling (ANC)

The Active Noise Cancelling feature reduces ambient noise, allowing for a more focused listening experience.

- To **Activate/Deactivate ANC**: Press the dedicated ANC button on the left earcup. An audible prompt will confirm the status change.

Image: A user wearing the JBL Tune 760NC headphones, demonstrating the active noise cancelling capability in a focused environment.

Hands-Free Calls & Voice Control

Manage your calls and interact with your device's voice assistant directly from your headphones.

- **Answer/End Call:** Press the Multi-function button once.
- **Reject Call:** Press and hold the Multi-function button for 2 seconds.
- **Activate Voice Assistant:** Double-press the Multi-function button.

Charging

To charge your JBL Tune 760NC headphones:

1. Connect the USB-C charging cable to the USB-C port on the headphones.
2. Connect the other end of the USB-C cable to a power source (e.g., USB wall adapter, computer USB port).
3. The LED indicator will show charging status. A full charge takes approximately 2 hours.

Battery Life

Your JBL Tune 760NC headphones offer extended battery life:

- Up to 35 hours of playback with Bluetooth and Active Noise Cancelling enabled.
- Up to 50 hours of playback with Active Noise Cancelling turned off.
- A quick 5-minute charge provides an additional 2 hours of playback.

Image: A user enjoying music outdoors with the JBL Tune 760NC headphones, highlighting the impressive 50-hour battery life when Active Noise Cancelling is off.

Image: A serene scene of a person listening to music with JBL Tune 760NC headphones by the water, illustrating the rich JBL Pure Bass Sound experience.

Maintenance

Cleaning

To maintain the condition and hygiene of your headphones:

- Wipe the earcups and headband with a soft, dry cloth.
- Do not use abrasive cleaners, alcohol, or chemical solvents, as these may damage the surface.
- Avoid getting moisture into any openings.

Storage

The JBL Tune 760NC headphones feature a lightweight and foldable design for easy storage and portability.

- Fold the earcups inwards towards the headband to minimize their footprint.
- Store the headphones in a cool, dry place, away from direct sunlight and extreme temperatures.
- Avoid placing heavy objects on top of the headphones when stored.

Image: The JBL Tune 760NC headphones in their standard, unfolded position, ready for use or compact storage.

Troubleshooting

If you encounter issues with your JBL Tune 760NC headphones, refer to the table below for common problems and their solutions:

Problem	Possible Cause	Solution
Headphones do not power on.	Low or no battery.	Charge the headphones fully using the USB-C cable.
Cannot pair via Bluetooth.	Headphones not in pairing mode; device Bluetooth off; interference.	Ensure headphones are in pairing mode (rapid blue flashing LED). Turn off and on Bluetooth on your device. Move closer to the device and away from other wireless signals.
No sound or low volume.	Volume too low; incorrect audio source selected; headphones not connected.	Increase volume on both headphones and connected device. Verify Bluetooth connection or wired cable is securely plugged in.
Active Noise Cancelling not effective.	ANC feature is off; improper fit.	Press the ANC button to activate. Adjust headphones for a snug fit over your ears.
Headphones frequently disconnect.	Out of Bluetooth range; interference; low battery.	Move closer to your device. Avoid strong Wi-Fi signals or other Bluetooth devices. Charge the headphones.

Specifications

Detailed technical specifications for the JBL Tune 760NC headphones:

Feature	Detail
Model Name	JBL Tune 760NC Blue
Noise Control	Active Noise Cancellation
Connectivity Technology	Wireless (Bluetooth 5.0)
Audio Driver Size	40 Millimeters
Earpiece Shape	Over Ear
Frequency Range	20 Hz - 20,000 Hz
Impedance	32 Ohm
Battery Life (ANC Off)	Up to 50 Hours
Battery Life (BT+NC)	Up to 35 Hours
Charging Time	2 Hours
Item Weight	220 Grams (7.8 ounces)
Product Dimensions	8.07 x 2.44 x 8.78 inches
Cable Feature	Detachable
Control Type	Voice Control, Button Control

Feature	Detail
Special Features	Google Fast Pair, Multi-Point Connection, Foldable Design

Warranty and Support

JBL products are manufactured to the highest quality standards. For detailed warranty information, please refer to the warranty card included in your product packaging or visit the official JBL website. For technical support, product registration, or further assistance, please contact JBL customer service through their official channels.
Keep your proof of purchase for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question