Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- > CONBOLA /
- > CONBOLA Bladeless Desk Fan User Manual

CONBOLA

CONBOLA Bladeless Desk Fan

USER MANUAL - MODEL: BF006

1. Introduction

Thank you for choosing the CONBOLA Bladeless Desk Fan. This portable and quiet fan is designed to provide a comfortable and serene cooling experience in various settings, including your bedroom, office, or home. Its innovative bladeless design ensures safety and easy maintenance, while the touch control offers convenient operation. Please read this manual thoroughly before using the product to ensure proper function and longevity.



Figure 1: CONBOLA Bladeless Desk Fan and accessories.

2. Product Features

- **Bladeless Design:** Features innovative turbine technology for powerful airflow without exposed blades, ensuring safety for children and pets.
- **Portable & Rechargeable:** Equipped with a 4400mAh battery, offering 4.5-12 hours of operation. Charges conveniently via a Type-C USB cord, allowing use anywhere.
- **Quiet Operation:** Designed with a high-performance motor and unique air-duct system for minimal noise, ideal for quiet environments like bedrooms and offices.
- Touch Control with 3 Speeds: Easily adjust between low, medium, and high wind speeds with a single smart touch button to suit your cooling needs.
- **Durable & Easy to Clean:** Constructed from ABS + PC material, making it robust and simple to wipe clean.



Figure 2: The fan's portable design allows for comfortable use in various settings, such as a home office.

Smart Touch Button

3 wind speeds (high,Medium,low) can be adjusted, and you just need lightly touch the button.



Figure 3: The fan features a smart touch button for easy control and has a compact design, measuring 11.8 inches in height.



Figure 4: The bladeless design provides a safe environment, especially around children.




Figure 5: Enjoy a serene environment with the fan's low-noise operation.

Quiet but Strong TurboSilent technology instantly refreshes your mind and blows away the noise and annoyance. Ideal for working at office or studying at home.

Figure 6: The fan utilizes TurboSilent technology for strong yet quiet airflow.



Figure 7: The versatile design makes it suitable for various rooms and activities.

3. Package Contents

Please check the package for the following items:

- CONBOLA Bladeless Desk Fan
- USB Type-C Charging Cable
- User Manual (this document)

4. Setup

- 1. **Unpack:** Carefully remove the fan and all accessories from the packaging.
- 2. **Initial Charge:** Before first use, fully charge the fan. Connect the provided USB Type-C cable to the fan's charging port and plug the other end into a compatible USB power source (e.g., computer, laptop, power bank, or wall adapter). The indicator light will show charging status.
- 3. **Placement:** Place the fan on a stable, flat surface. Ensure the four rubber feet on the base are securely in contact with the surface to reduce vibration and prevent slipping.

5. Operating Instructions

The CONBOLA Bladeless Desk Fan features intuitive touch controls.

- 1. **Power On/Off:** Lightly touch the power button (usually indicated by a power symbol) on the front panel to turn the fan on or off.
- 2. **Adjust Fan Speed:** After turning on, repeatedly touch the speed control button (often indicated by a fan icon or '+' symbol) to cycle through the 3 available wind speeds: Low, Medium, and High. The indicator lights will change to reflect the current speed setting.
- 3. **Battery Life:** The fan's 4400mAh battery provides approximately 4.5 to 12 hours of operation, depending on the selected speed level.

Video 1: An overview of the CONBOLA Desk Fan, highlighting its quiet operation and bladeless design.

6. Maintenance

Regular cleaning ensures optimal performance and extends the lifespan of your fan.

- Cleaning the Exterior: Use a soft, dry cloth to wipe the exterior of the fan. For stubborn marks, a slightly damp cloth can be used, followed by a dry one.
- Internal Cleaning: Due to its bladeless design, internal dust accumulation is minimized. If necessary, use a soft brush or compressed air to clear any dust from the air intake vents. Do not attempt to disassemble the fan for cleaning.
- **Storage:** When not in use for extended periods, store the fan in a cool, dry place, away from direct sunlight and extreme temperatures.

7. Troubleshooting

Problem	Possible Cause	Solution
Fan does not turn on.	Low battery or not charged.	Connect the fan to a power source using the USB Type-C cable and allow it to charge.
Fan stops working unexpectedly.	Battery depleted or power interruption.	Recharge the fan. If plugged in, check the power connection.
Fan does not respond to touch controls.	Temporary software glitch.	Unplug the fan (if charging), wait a few seconds, then plug it back in or attempt to power cycle it.
Airflow is weak.	Fan speed set to low or vents obstructed.	Increase the fan speed. Ensure air intake and output vents are clear of obstructions. Note that this is a personal desk fan, not designed for large room cooling.
Fan makes unusual noise.	Dust accumulation or internal obstruction.	Clean the air intake vents. If the noise persists, contact customer support.

8. Specifications

Feature	Detail
Brand	CONBOLA
Model Name	CONBOLA (BF006)
Product Dimensions	5.7"D x 5.9"W x 11.8"H
Item Weight	1.83 pounds
Power Source	Battery Powered
Battery Type	2 Lithium Polymer batteries required (4400mAh total)
Speeds	3 RPM (Low, Medium, High)
Control Method	Touch
Connector Type	USB Type C
Material	ABS + PC Plastic
Indoor/Outdoor Usage	Outdoor, Indoor
Special Features	Battery Operated, Bladeless, Portable, Touch Control

9. Warranty and Support

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official CONBOLA website. Protection plans may be available for purchase separately.

© 2024 CONBOLA. All rights reserved.