

[Manuals.plus](#) /

> [Le Creuset](#) /

> Le Creuset Stoneware Mini Round Cocotte User Manual

Le Creuset PG1160T-1467

Le Creuset Stoneware Mini Round Cocotte User Manual

Brand: Le Creuset

Model: PG1160T-1467

PRODUCT OVERVIEW

The Le Creuset Stoneware Mini Round Cocotte is designed for individual servings, offering an elegant presentation for dishes like cobblers, gratins, and pot pies. Its smaller size allows for faster baking, making it ideal for serving multiple guests. This versatile cocotte can also be used for prepping and storing ingredients, or simply as a decorative piece to add a touch of Le Creuset style and color to your kitchen.



Image: A single Le Creuset Stoneware Mini Round Cocotte in a vibrant Cerise (cherry red) color, shown with its matching lid. The cocotte features small loop handles on either side.

KEY FEATURES

- Crafted from durable stoneware with a vibrant enamel finish.
- Equipped with loop side handles for a secure and comfortable grip during transport.
- Features a secure-fitting stoneware lid with a round knob, designed to effectively trap heat and moisture within the cocotte.
- Dishwasher-safe for easy cleaning.
- Oven-safe up to 500 degrees Fahrenheit (260 degrees Celsius).

SETUP AND FIRST USE

Before using your Le Creuset Mini Round Cocotte for the first time, remove all packaging and labels. Wash the cocotte and lid thoroughly with warm, soapy water, then rinse and dry completely. This prepares the stoneware for optimal performance and ensures cleanliness.



Image: Two Le Creuset Mini Cocottes on a white surface. One cocotte in Cerise is open and filled with fresh strawberries, while another in white is stacked with its lid on, demonstrating their compact size and versatility for food preparation or serving.

OPERATING INSTRUCTIONS

Baking and Cooking

- The cocotte is safe for use in ovens up to 500°F (260°C).
- Always place the cocotte in a cold oven and allow it to heat up gradually with the oven to prevent thermal shock.
- Use oven mitts or pot holders when handling the hot cocotte, as the stoneware retains heat efficiently.
- Ideal for individual portions of baked desserts, savory gratins, or small casseroles.

Serving and Storage

- The cocotte's elegant design makes it suitable for direct table-to-oven serving.
- Can be used for storing small amounts of ingredients or leftovers in the refrigerator.



Image: A Le Creuset Mini Round Cocotte in Cerise, placed on a wooden kitchen counter, suggesting its readiness for cooking or serving. The background shows a kitchen setting with other kitchenware.

MAINTENANCE AND CARE

Cleaning

- The cocotte is dishwasher-safe. For best results, allow it to cool completely before placing it in the dishwasher.
- For hand washing, use warm, soapy water and a soft sponge or nylon scrub brush.
- Avoid using abrasive cleaners, steel wool, or metal scouring pads, as these can damage the enamel finish.
- For stubborn food residue, fill the cocotte with warm water and a small amount of dish soap, let it soak for 15-20 minutes, then clean as usual.

Storage

- Store the cocotte in a dry place.
- To prevent chipping or scratching, avoid stacking other heavy items directly on top of the cocotte or its lid.

TROUBLESHOOTING

Food Sticking

- Ensure adequate oil or butter is used when cooking to prevent food from sticking.
- Allow the cocotte to preheat properly before adding ingredients.

Discoloration

- Minor discoloration over time is normal with regular use.
- For persistent stains, a paste of baking soda and water can be applied and left for a few hours before scrubbing gently.

SPECIFICATIONS

Material	Stoneware
Brand	Le Creuset
Capacity	14 ounces
Color	Cerise
Finish Type	Enameled
Shape	Round
Product Care Instructions	Dishwasher Safe
With Lid	Yes
Is Oven Safe	Yes
Lid Material	Stoneware
Is Dishwasher Safe	Yes
Temperature Rating	500 Degrees Fahrenheit (260 Degrees Celsius)
Manufacturer	Le Creuset
UPC	843251168354
Product Dimensions	5.51 x 5.51 x 3.54 inches
Item Weight	1.57 pounds
ASIN	B0953ZPP46
Item Model Number	PG1160T-1467



Image: An overhead view of multiple Le Creuset Mini Round Cocottes in a variety of colors, including red, blue, green, and white, arranged artistically among plants and flowers, showcasing the range of available colors.

WARRANTY AND SUPPORT

Le Creuset stoneware products, including the Mini Round Cocotte, typically come with a 10-year limited warranty. This warranty covers defects in material and workmanship under normal household use. For detailed warranty information, claims, or product support, please refer to the official Le Creuset website or contact their customer service directly.

For further assistance, visit the [Le Creuset Store on Amazon](#) or their official brand website.

