

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [HP](#) /
- › [HP M22f FHD Monitor User Manual](#)

## HP M22f

# HP M22f FHD Monitor User Manual

Model: M22f

## 1. INTRODUCTION

This manual provides essential information for setting up, operating, and maintaining your HP M22f FHD Monitor. Designed for clarity and performance, this monitor offers a vibrant visual experience with features aimed at enhancing user comfort and productivity.



Figure 1.1: Front view of the HP M22f FHD Monitor, showcasing its sleek design and narrow bezels.

## 2. KEY FEATURES

---

- **IPS Technology:** Experience clear, vivid images from virtually any angle with consistent color and image clarity across ultra-wide 178-degree horizontal and vertical viewing angles.
- **HP Eye Ease with Eyesafe Certification:** An always-on blue light filter designed to keep your eyes comfortable during extended use, without compromising color accuracy.
- **Highly Accurate Color:** With 99% sRGB color space, this display provides excellent color reproduction, ideal for various creative and professional tasks.
- **AMD FreeSync Technology:** Enjoy fluid and responsive gameplay by synchronizing the monitor's refresh rate with your GPU, reducing display stutter, input lag, and screen tearing.
- **Full HD Resolution:** Delivers crisp and detailed visuals for an immersive viewing experience.

## 3. SETUP GUIDE

---

### 3.1 Unpacking the Monitor

Carefully remove all components from the packaging. Ensure all parts listed in the packing slip are present. Retain the packaging for future transport or storage.

### 3.2 Assembling the Stand

1. Place the monitor face down on a soft, clean surface to prevent scratches.
2. Attach the stand neck to the back of the monitor until it clicks into place.
3. Secure the base to the stand neck using the provided screw.



*Figure 3.1: Assembled HP M22f FHD Monitor, ready for connection.*

### **3.3 Connecting the Cables**

The HP M22f monitor supports both HDMI and VGA connections. Choose the appropriate cable for your device.

- **Power Cable:** Connect the power cable to the monitor's power input and then to a wall outlet.
- **HDMI Cable:** Connect one end of the HDMI cable to the HDMI port on the monitor and the other end to the HDMI port on your computer or device.
- **VGA Cable:** If using VGA, connect one end of the VGA cable to the VGA port on the monitor and the other end to the VGA port on your computer or device.



Figure 3.2: Rear view of the monitor, highlighting the HDMI and VGA input ports for connectivity.

## 4. OPERATING THE MONITOR

### 4.1 Powering On/Off

Locate the power button on the bottom right bezel of the monitor. Press it to turn the monitor on or off.





*Figure 4.1: Side profile of the monitor, illustrating its slim design and the ability to tilt for optimal viewing angles.*

## **4.2 Adjusting Display Settings**

The monitor features an On-Screen Display (OSD) menu for adjusting various settings. Use the buttons located near the power button to navigate the OSD menu.

- **Brightness/Contrast:** Adjust these settings to suit your viewing environment.
- **Color Control:** Fine-tune color temperature, sRGB, or custom color settings.
- **Input Selection:** Manually switch between HDMI and VGA inputs if auto-switch is not desired.
- **HP Eye Ease:** Enable or disable the blue light filter for eye comfort.

## 5. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your HP M22f FHD Monitor.

- **Cleaning the Screen:** Use a soft, lint-free cloth slightly dampened with water or a non-abrasive screen cleaner. Avoid spraying liquid directly onto the screen.
- **Cleaning the Casing:** Wipe the monitor casing with a soft, dry cloth.
- **Ventilation:** Ensure the ventilation openings on the monitor are not blocked to prevent overheating.
- **Storage:** If storing the monitor, use the original packaging to protect it from dust and damage.

## 6. TROUBLESHOOTING

Problem	Possible Solution
No image on screen	<p>Ensure power cable is securely connected.</p> <p>Verify video cable (HDMI/VGA) is properly connected to both monitor and computer.</p> <p>Press the power button to ensure the monitor is on.</p> <p>Check the input source in the OSD menu.</p>
Image is blurry or distorted	<p>Adjust the resolution settings on your computer to the monitor's native resolution (1920x1080).</p> <p>Check video cable for damage or loose connections.</p> <p>Perform an auto-adjustment via the OSD menu (if available for VGA).</p>
Colors appear incorrect	<p>Reset color settings to factory defaults via the OSD menu.</p> <p>Ensure the HP Eye Ease feature is not causing unintended color shifts if not desired.</p>

## 7. SPECIFICATIONS

Feature	Detail
Brand	HP
Model	M22f
Standing Screen Display Size	22 Inches
Screen Resolution	1920x1080 (Full HD)
Max Screen Resolution	1920 x 1080
Series	M22f FHD

Feature	Detail
Item Weight	4.8 pounds
Product Dimensions (LxWxH)	1.25 x 19.11 x 11.3 inches
Color	White
Voltage	240 Volts
Manufacturer	HP
Date First Available	May 18, 2021
Aspect Ratio	16:9
Screen Surface Description	Glossy

## 8. WARRANTY AND SUPPORT

For detailed warranty information and technical support, please refer to the official HP website or contact HP customer service. Keep your purchase receipt and product serial number handy when seeking support.

**Online Support:** [support.hp.com](https://support.hp.com)

