

[Manuals.plus](#) /

› [YIYIBYUS](#) /

› YIYIBYUS Adjustable Rolling Clothes Hanger Instruction Manual

YIYIBYUS B0957D2LK9

Instruction Manual

YIYIBYUS ADJUSTABLE ROLLING CLOTHES HANGER

Model: B0957D2LK9

1. Introduction

This manual provides instructions for the assembly, operation, and maintenance of your YIYIBYUS Adjustable Rolling Clothes Hanger. This versatile rack is designed for storing and drying clothes and towels in various indoor and outdoor environments. Please read this manual carefully before use and retain it for future reference.



Image 1.1: The YIYIBYUS Adjustable Rolling Clothes Hanger, fully assembled and in use.

2. Product Features

- **Adjustable Design:** The hanger features an all-round three-dimensional ventilation design, allowing for efficient drying of multiple clothing items. The height can be adjusted from 90cm to 158cm (35 to 62 inches) to suit various needs.
- **Durable Construction:** Constructed with thickened composite steel pipes, ensuring strength and durability for long-term use.
- **High Load-Bearing Capacity:** Engineered with a robust mechanical structure, providing a maximum load-bearing capacity of 10kg (22 lbs).
- **Secure Connections:** High-quality PP material is used for fasteners, with nuts designed to interlock tightly, preventing breakage and ensuring stability.
- **Mobility with Brakes:** Equipped with rollers that include brakes, allowing the rack to be easily moved and securely positioned as needed.

3. Package Contents

Upon opening the package, please verify that all components are present and undamaged:

- 1 x Clothes Hanger (unassembled components)

Note: If any parts are missing or damaged, please contact customer support.

4. Specifications

Parameter	Detail
Product Name	Retractable Floor Drying Rack
Material	Composite Steel Pipe + PP (Alloy Steel, Plastic)
Adjustable Length	90 ~ 158 cm (35 ~ 62 inches)
Width	80 cm (31 inches)
Mounting Type	Floor Mount, Freestanding
Maximum Load Capacity	10 kg (22 lbs)
Recommended Use	Storage, Drying Clothes/Towels
Use Environment	Indoor, Outdoor
Package Weight	1.4 kg (3 lbs)
Model Number (ASIN)	B0957D2LK9
UPC/GTIN	712004663098





Image 4.1: Dimensions of the Adjustable Rolling Clothes Hanger.

5. Safety Information

- Ensure all connections are securely tightened before placing items on the rack.
- Do not exceed the maximum load capacity of 10 kg (22 lbs) to prevent tipping or damage.
- Distribute weight evenly across the hanging bar to maintain stability.
- Keep children and pets away from the rack during assembly and when in use to prevent accidents.
- Use the wheel brakes when the rack needs to remain stationary.
- Avoid placing the rack on uneven surfaces.

6. Assembly Instructions

Follow these steps to assemble your rolling clothes hanger:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface. Identify the base, vertical poles, horizontal hanging bar, and wheels.
2. **Attach Wheels to Base:** Insert the four wheels into the designated slots on the base frame. Ensure they click into place securely. If your wheels have brakes, ensure they are in the unlocked position during assembly.
3. **Connect Vertical Poles:** Insert the bottom ends of the two vertical poles into the corresponding openings on the base frame. Push firmly until they are fully seated.
4. **Attach Horizontal Bar:** Place the horizontal hanging bar onto the top ends of the vertical poles. Ensure the connection points are aligned and secure. Tighten any locking mechanisms or knobs if present to secure the bar.
5. **Adjust Height (Optional):** If desired, adjust the height of the vertical poles by loosening the adjustment knobs, extending the poles to the desired height, and then tightening the knobs firmly.
6. **Final Check:** Gently shake the assembled rack to ensure all connections are stable and secure.



Image 6.1: Detail of connection points and a caster wheel, illustrating assembly components.



Image 6.2: The base structure of the clothes hanger with its wheels.

7. Operating Instructions

- **Adjusting Height:** To adjust the height, locate the adjustment knobs on the vertical poles. Turn them counter-clockwise to loosen, extend or retract the poles to your desired height (between 90cm and 158cm), and then turn the knobs clockwise to tighten firmly.
- **Moving the Rack:** To move the rack, ensure the wheel brakes are disengaged. Gently push or pull the rack to its desired location.
- **Locking the Wheels:** To keep the rack stationary, push down on the brake levers located on the wheels. Ensure all four brakes are engaged for maximum stability. To unlock, lift the levers.
- **Hanging Clothes:** Hang clothes evenly across the horizontal bar to maintain balance and prevent the rack from tipping.





Image 7.1: The clothes hanger in use, demonstrating its adjustable height.



Image 7.2: Detail of a caster wheel with its integrated brake for stability.

8. Maintenance and Care

- **Cleaning:** Wipe the rack with a soft, damp cloth to remove dust and dirt. Avoid using abrasive cleaners or harsh chemicals, as they may damage the finish.
- **Inspection:** Periodically check all connections, screws, and adjustment knobs to ensure they remain tight. Re-tighten if necessary.
- **Storage:** When not in use for extended periods, the rack can be disassembled for compact storage. Store in a dry

place away from direct sunlight.

9. Troubleshooting

- **Rack is unstable:**
 - Ensure all assembly connections are fully tightened.
 - Verify that the rack is placed on a flat, level surface.
 - Check that weight is distributed evenly on the hanging bar.
- **Wheels not rolling smoothly:**
 - Check if the wheel brakes are engaged. Disengage them if necessary.
 - Clean any debris or hair that may be caught in the wheels.
- **Height adjustment is difficult:**
 - Ensure the adjustment knobs are fully loosened before attempting to change height.
 - Check for any obstructions or damage to the telescopic poles.

10. Warranty and Support

This product comes with a standard manufacturer's warranty. For specific warranty details, please refer to the product packaging or contact your retailer. For technical support, missing parts, or any other inquiries, please contact the customer service department of your place of purchase.

Please have your model number (B0957D2LK9) and purchase date available when contacting support.

© 2026 YIYIBYUS. All rights reserved. Information in this manual is subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question