

Manuals.plus /

> KERDOM /

> KERDOM Office Chair, Ergonomic Desk Chair, Breathable Mesh Computer Chair, Comfy Swivel Task Chair with Flip-up Armrests and Adjustable Height Black 933-C

KERDOM KD933

KERDOM Office Chair Instruction Manual

Model: KD933 | Brand: KERDOM

PRODUCT OVERVIEW

The KERDOM Office Chair (Model KD933) is an ergonomic desk chair designed for comfort and functionality. It features a breathable mesh back and seat, flip-up armrests for space-saving, and adjustable height to suit various user needs. Its design is suitable for various environments including home offices, meeting rooms, and study areas.



Figure 1: Front view of the KERDOM Office Chair.

SETUP AND INSTALLATION

Assembling your KERDOM Office Chair is a straightforward process, typically taking about 30 minutes. The necessary Allen key tool is included with the chair. For detailed visual instructions, please refer to the official installation manual PDF. The assembly primarily involves attaching the main components using the provided screws. This includes securing the backrest to the seat, attaching the armrests, and connecting the chair's base to the seat mechanism. The base, including the legs and casters, is constructed from metal for stability, while the chair frame and backrest support are made of durable plastic.

For a comprehensive guide, please download the [Installation Manual \(PDF\)](#).



Figure 2: Exploded view of chair components for assembly.

OPERATING INSTRUCTIONS

Your KERDOM Office Chair is designed with several adjustable features to enhance your comfort and adapt to your workspace.



Figure 3: User demonstrating the chair in an office setting.

Height Adjustment

The seat height can be easily adjusted to your preferred level. Locate the lever beneath the seat on the right side. To raise the seat, lift the lever while taking your weight off the chair. To lower the seat, lift the lever while remaining seated. Adjust until your feet are flat on the floor and your knees are at a 90-degree angle.



/BREATHABLE/

KEEP OUR BACK COOL
AND COMFORTABLE



/FLEXIBLE/

NOT EASY TO DEFORM





Figure 4: Adjusting the seat cushion height by 8cm.

Flip-Up Armrests

The armrests are designed to flip up 90 degrees, allowing you to push the chair further under your desk when not in use, saving valuable space. Simply grasp the armrest and rotate it upwards until it locks into the vertical position. To return it to the horizontal position, rotate it back down.

FLIP-UP ARMRESTS

Curved 90°
rotating armrest



Foldable armrest
saving your room
space

Figure 5: The 90-degree flip-up armrests for space saving.

Rocking Function

The chair features a rocking mode for relaxation. To activate or deactivate the rocking function, pull the lever located beneath the seat on the left side outwards. This allows the chair to recline and rock gently. Push the lever inwards to lock the chair in an upright position.

Full Comfortable Design



Figure 6: Illustration of the rocking function and lumbar support.

Ergonomic Support

The chair provides three key support points for your back, hips, and hands, along with appropriate waist support. The breathable mesh material used for the back and cushion promotes airflow, keeping you cool and comfortable during extended periods of use. The mesh is designed to be steady, well-shaped, and elastic, ensuring durability and comfort.

Adjust Cushion 8cm Height

When you need to adjust
the height of the cushion
just lift the button up



Figure 7: Detail of the breathable and flexible mesh material.



Figure 8: Ergonomic back design with lumbar support for proper posture.

MAINTENANCE

To maintain the longevity and appearance of your KERDOM Office Chair, regular cleaning is recommended. Simply wipe clean with a damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these may damage the mesh fabric or plastic components.

TROUBLESHOOTING

If you encounter any issues with your KERDOM Office Chair, please review the following common solutions:

- **Chair not adjusting height:** Ensure the height adjustment lever is fully engaged or disengaged as required. Check for any obstructions beneath the seat mechanism.
- **Armrests not flipping smoothly:** Inspect the pivot points of the armrests for any debris or obstructions. A small amount of silicone spray can be applied to the pivot points if needed, but avoid overspray on fabric.

- **Casters not rolling smoothly:** Check the casters for accumulated hair, dust, or debris. Clean them regularly to ensure smooth movement.
- **Squeaking noises:** Tighten all assembly screws. If the noise persists, it may indicate an issue with the gas lift cylinder or rocking mechanism.

For issues not covered here, please contact KERDOM customer support for assistance.

SPECIFICATIONS

Feature	Detail
Brand	KERDOM
Model Name	KD933-C
Color	Black
Product Dimensions	21.3"D x 20.9"W x 8.9"H
Seat Height	18.9 Inches
Seat Depth	18.5 inches
Chair Backrest Width	17.7 Inches
Back Style	Mesh
Cushion Style	Breathable Mesh
Special Feature	Arm Rest (Flip-up)
Maximum Weight Recommendation	250 Pounds
Furniture Base Movement	Swivel
Tilting	Yes
Product Care Instructions	Wipe Clean
Included Components	Chair Body, Tripod, Wheels

OFFICE CHAIR DIMENSION



Figure 9: Dimensions of the KERDOM Office Chair.

WARRANTY AND SUPPORT

For any questions, concerns, or to inquire about warranty information, please contact the KERDOM customer service team. A professional after-sales service team is available to provide satisfactory solutions.

You can typically find contact information on the official KERDOM website or through your purchase platform.

© 2023 KERDOM. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0957N9LN6>

More documents and user manuals: <https://manuals.plus/>