Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- LuFun /
- > LuFun Flush Mount Ceiling Light Instruction Manual

LuFun AMZ0036

LuFun Flush Mount Ceiling Light Instruction Manual

Model: AMZ0036

1. Introduction

Thank you for purchasing the LuFun Flush Mount Ceiling Light. This modern LED fixture offers dimmable lighting with adjustable color temperatures (3000K-6500K) and convenient remote control operation. Designed for easy installation and energy efficiency, it provides versatile lighting for various indoor spaces.



Figure 1.1: LuFun Flush Mount Ceiling Light and its adjustable color temperatures.

2. SAFETY INFORMATION

- Always turn off the power at the circuit breaker before installation, cleaning, or servicing.
- This product is designed for indoor use only. Do not expose to moisture or extreme temperatures.
- Ensure all electrical connections are secure and comply with local electrical codes. If unsure, consult a qualified electrician.
- Do not attempt to modify the light fixture. Any modifications may void the warranty and pose a safety risk.
- · Keep the remote control and small parts out of reach of children.

3. PACKAGE CONTENTS

- LuFun Flush Mount Ceiling Light Fixture (1)
- Remote Control (1)

- Mounting Hardware Kit (screws, wire nuts)
- Instruction Manual (this document)

4. Installation

The LuFun Flush Mount Ceiling Light is designed for quick and easy installation. Please follow these steps carefully:

- 1. **Prepare for Installation:** Turn off power at the main circuit breaker. Ensure the mounting surface is clean and stable.
- 2. **Attach Mounting Bracket:** Secure the mounting bracket to the junction box in your ceiling using the provided screws.
- 3. **Connect Wiring:** Connect the household electrical wires to the fixture's wires using the wire nuts. Typically, black to black (live), white to white (neutral), and green/bare copper to green/bare copper (ground).
- 4. **Mount the Fixture:** Carefully align the light fixture with the mounting bracket and secure it with the provided screws. Ensure the fixture is flush against the ceiling.
- 5. **Restore Power:** Once the fixture is securely installed, turn the power back on at the circuit breaker.



Figure 4.1: Lamp body dimensions.



Figure 4.2: Internal LED lens and wiring.

For a visual guide on installation and features, please watch the official product video:

Your browser does not support the video tag.

Video 4.1: Overview of the LuFun Flush Mount Ceiling Light in a room setting, demonstrating its modern design and illumination.

5. OPERATING INSTRUCTIONS

The LuFun Ceiling Light can be controlled via a standard wall switch or the included remote control. The remote allows for advanced functions.

5.1. Wall Switch Operation

The light has a memory function. If controlled by a normal wall switch, it will cycle through three color temperatures (Cool White 6000K, Natural Light 4000K, Warm White 3000K) with each toggle of the switch.

5.2. Remote Control Functions

The remote control provides full control over the light's features:



Figure 5.1: Remote Control Functions.

- ON/OFF: Turns the light on or off.
- Delay Timer: Sets the light to turn off after 5, 30, or 60 minutes.
- Nightlight Mode: Activates a low-brightness setting.
- Color Temperature Adjustment: Gradually changes the color temperature from warm white (3000K) to cool white (6500K).
- Brightness Adjustment: Adjusts brightness from 10% to 100%.
- **Light Transform:** Cycles through preset light modes.
- Match: Used for pairing the remote with the light fixture (see Troubleshooting for details).



Figure 5.2: Color Temperature Adjustment Options.

6. MAINTENANCE

To ensure the longevity and optimal performance of your LuFun Ceiling Light, follow these simple maintenance guidelines:

- **Cleaning:** Before cleaning, ensure the power is turned off. Use a soft, dry cloth to wipe the surface of the fixture. Do not use abrasive cleaners, solvents, or polishes as they may damage the finish or acrylic shade.
- **Inspection:** Periodically check the fixture for any loose connections or signs of damage. If any issues are found, turn off the power and consult a qualified electrician.
- LED Lifespan: The integrated LED light source is designed for long-term use and does not require bulb replacement.

7. TROUBLESHOOTING

7.1. Remote Control Not Working / Pairing

If the remote control does not work or needs to be re-paired with the light fixture, follow these steps:

- 1. Ensure the remote control has working batteries (this product does not include batteries).
- 2. Turn off the light switch on the wall.
- 3. Turn the wall switch ON, and within 3 seconds, press and hold the "1" button (bottom left) on the remote control.
- 4. Hold the button for about 3-5 seconds until the light flashes once.
- 5. Release the "1" button to complete the pairing process.

To reset (clear the memory) the remote, remove the batteries for 2 minutes, then re-install them. To clear the light fixture's memory, turn off the wall switch for 15 seconds.

7.2. Light Not Turning On

- Check if the power is on at the circuit breaker.
- · Verify all electrical connections are secure.
- Ensure the wall switch is in the ON position.

7.3. Light Flickers or Dims Unexpectedly

- Ensure the light is not connected to an incompatible dimmer switch. This fixture is dimmable via its remote control, not necessarily all external dimmers.
- Check for loose wiring connections.

8. SPECIFICATIONS

Feature	Specification
Brand	LuFun
Model Name	LuFun Ceiling Light
Item Model Number	AMZ0036
Color	Black/Round/Dimmable
Material	Acrylic, Metal, Wood
Product Dimensions	15.75"L x 15.75"W x 1.97"H (Ø40*5 CM)
Light Source Type	LED
Wattage	30 watts
Brightness	2400 Lumen
Voltage	110 Volts (AC)
Color Temperature	3000K - 6500K (Dimmable)
Control Method	Remote Control
Installation Type	Flush Mount

Indoor/Outdoor Usage	Indoor Use Only
Item Weight	3.3 pounds (1.5 Kilograms)

9. WARRANTY AND SUPPORT

This LuFun Flush Mount Ceiling Light comes with a **1-year warranty** from the date of purchase, covering manufacturing defects. Please retain your proof of purchase for warranty claims.

For technical support, troubleshooting assistance, or warranty inquiries, please contact our customer service team:

- Email: support@lufunlighting.com (example email)
- Phone: 1-800-XXX-XXXX (example phone number)
- Website: www.lufunlighting.com (example website)

Our support team is available Monday to Friday, 9:00 AM to 5:00 PM (EST).

© 2025 LuFun. All rights reserved.

Documents - LuFun – AMZ0036 no relevant documents