Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

EMMA + OLIVER EOH-OBOD-563684

EMMA + OLIVER EOH-OBOD-563684 L-Shaped Home Office Desk User Manual

Model: EOH-OBOD-563684

1. Introduction

Thank you for choosing the EMMA + OLIVER L-Shaped Home Office Desk. This desk is designed to provide a versatile and spacious workspace for your home office, gaming setup, or remote learning needs. Its contemporary design features a white textured MDF top and a durable black powder-coated metal frame. This manual provides essential information for safe assembly, proper use, and maintenance of your new desk.

Safety Information

Important: Always ensure the desk is properly assembled and anchored to the floor for stability. Do not use the desk until it is fully assembled and securely anchored. Keep small parts away from children. Use caution when handling tools during assembly.

Your browser does not support the video tag.

Video: Overview of the L-Shaped Computer Gaming Desk. This video demonstrates the desk's features and potential setup configurations, providing a visual guide to its design and functionality.

2. Parts List

Before beginning assembly, ensure all components are present and undamaged. If any parts are missing or damaged, please contact customer support.

- L-Shaped Desktop Panels (2 main sections, 1 corner connector)
- Metal Frame Components (legs, support bars)
- Raised Monitor Platform (top panel, support posts)
- Assembly Hardware (screws, bolts, washers, Allen wrench)
- Self-Leveling Floor Glides



Image: Top-down view of the L-shaped desk components, including the two main desk sections and the curved corner connector. This image helps visualize the primary desktop pieces before assembly.

3. Assembly Instructions

Assembly typically takes 60 minutes or less. Follow these steps carefully.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches. Verify all parts from the list are present.
2. **Assemble Frame Sections:** Attach the metal frame components to the underside of each main desktop panel. Ensure all screws are tightened securely but do not overtighten.
3. **Connect Desk Sections:** Join the two main desk sections using the corner connector and appropriate hardware. Ensure the L-shape is correctly aligned.
4. **Install Monitor Platform:** The raised monitor platform can be installed on either side of the desk. Attach the support posts to the desired desk section, then secure the monitor platform panel to the posts.
5. **Attach Floor Glides:** Screw the self-leveling floor glides into the bottom of each leg. These glides help stabilize the desk on uneven surfaces.
6. **Final Tightening and Placement:** Once fully assembled, gently lift and move the desk to its desired location. Double-check all connections for tightness. Adjust the floor glides as needed to ensure the desk is stable and level.



Image: An assembled EMMA + OLIVER L-shaped desk, showcasing the monitor stand on one side. This image provides a visual reference for the completed assembly.



Image: A close-up view of the raised monitor platform, showing its placement and design. This detail is helpful for understanding the monitor stand's installation and function.

4. Operating Instructions

Desk Usage

The L-shaped design offers ample surface area for multiple monitors, keyboards, mice, and other accessories. The desk is designed to support up to 175 lbs (static weight capacity).

- **Monitor Placement:** Utilize the raised monitor platform for ergonomic screen positioning. This platform helps elevate your monitor to a comfortable viewing height, reducing neck strain.
- **Space Optimization:** The L-shape allows the desk to tuck into corners, maximizing floor space in smaller rooms. In larger areas, it can be centered to provide multi-directional access.
- **Cable Management:** While not explicitly included, consider using adhesive cable clips or ties (not provided) to manage cables neatly under the desk, maintaining a tidy workspace.




Image: A frontal view of the EMMA + OLIVER L-shaped desk, showing its overall dimensions and the integrated monitor stand. This perspective highlights the desk's spacious design.

5. Maintenance

Proper care will extend the life and appearance of your desk.

- **Cleaning:** Wipe the desk surfaces with a dry cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Regular Checks:** Periodically check all screws and bolts to ensure they remain tight. Loose connections can affect the desk's stability.

- **Avoid Excessive Weight:** Do not exceed the maximum weight capacity of 175 lbs to prevent damage to the desk structure.
- **Protect Surfaces:** Use coasters for drinks and pads under hot items to protect the desk surface from stains and heat damage.

6. Troubleshooting

Common Issues and Solutions

- **Desk is Unstable/Wobbly:**
  - Ensure all assembly screws and bolts are securely tightened.
  - Adjust the self-leveling floor glides on each leg until the desk is stable on uneven surfaces.
- **Parts Do Not Align During Assembly:**
  - Review the assembly instructions carefully to ensure each part is oriented correctly.
  - Loosen screws slightly on connected parts, adjust alignment, then retighten.



Image: A close-up view of a self-leveling floor glide on the desk leg. These glides can be adjusted to ensure desk stability on uneven floors.

7. Specifications

Brand	EMMA + OLIVER
Model Number	EOH-OBOD-563684
Shape	L-Shaped
Overall Dimensions (W x D x H)	71.5" x 50.75" x 29" - 36.5"
Side Desks (2)	31.5"W x 17.25"D x 0.5"H
Corner Connector	27.25"W x 19.125"D x 0.5"H

Raised Monitor Platform	19"W x 8"D x 6.875"H
Weight Capacity	175 lbs (Static)
Material	Particleboard (Top), Alloy Steel (Frame)
Color	White/Black
Assembly Required	Yes
Item Weight	39 Pounds

8. Warranty and Support

Warranty Information

This EMMA + OLIVER desk comes with a **5-year limited warranty** on non-moving metal parts and a **2-year warranty** on other parts. This warranty covers manufacturing defects under normal use. Please retain your proof of purchase for warranty claims.

Customer Support

For any questions regarding assembly, missing parts, or warranty claims, please contact EMMA + OLIVER customer support. Refer to your purchase documentation for specific contact details.

© 2026 EMMA + OLIVER. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09583YPHJ

More documents and user manuals: **https://manuals.plus/**