

## ALLIMITY RC1994925

# ALLIMITY RC1994925 Remote Control User Manual

For Thomson and TCL Televisions

## 1. INTRODUCTION

This manual provides instructions for the ALLIMITY RC1994925 replacement remote control. This remote is designed to function as a direct replacement for your original Thomson or TCL TV remote, offering full functionality without the need for complex programming. Simply insert batteries, and it is ready for use.

## 2. SETUP: BATTERY INSTALLATION

The ALLIMITY RC1994925 remote control requires two AAA batteries (not included) for operation.

- 1. Open the Battery Compartment:** Locate the battery compartment cover on the back of the remote control. Slide the cover downwards or press the latch and lift to open.
- 2. Insert Batteries:** Insert two new AAA batteries, ensuring that the positive (+) and negative (-) terminals align correctly with the markings inside the compartment. Incorrect insertion can prevent the remote from functioning.
- 3. Close the Compartment:** Replace the battery compartment cover by sliding it back into place until it clicks securely.

Once batteries are installed, the remote control is ready to operate your compatible Thomson or TCL TV.





Figure 2.1: Angled view of the ALLIMITY RC1994925 remote control, highlighting its button layout and ergonomic design.

### 3. OPERATING INSTRUCTIONS

The ALLIMITY RC1994925 remote control is designed to replicate the functions of your original TV remote. Point the remote directly at your television's infrared receiver for optimal performance.



Figure 3.1: Front view of the ALLIMITY RC1994925 remote control, displaying all functional buttons.

### Key Functions:

- **Power Button (U):** Turns the TV on or off.
- **Source/Input:** Selects the input source (e.g., HDMI 1, AV, TV).
- **Number Buttons (0-9):** Directly select TV channels.
- **Volume Up/Down (+/-):** Adjusts the audio volume.
- **Channel Up/Down (PR +/-):** Changes TV channels sequentially.
- **Mute:** Silences the TV audio.
- **Navigation Pad (Up, Down, Left, Right, OK):** Navigates through menus and confirms selections.
- **Menu:** Accesses the TV's main menu.
- **Exit:** Exits the current menu or function.
- **Return:** Goes back to the previous screen or channel.
- **Guide/Info:** Displays program guide or information about the current program.
- **Color Buttons (Red, Green, Yellow, Blue):** Used for specific functions within interactive TV services or

menus, as indicated on screen.

- **Media Playback Controls (Play, Pause, Stop, Rewind, Fast Forward):** Controls media playback on compatible devices or TV functions.

## 4. COMPATIBLE TV MODELS

This ALLIMITY RC1994925 remote control is compatible with a wide range of Thomson and TCL TV models. No programming is required; it works immediately with the following models:

- 22B33H, 32A33H, 32C35H
- RC1994925-04TCLTEL0203, JY-T04901-003, VM-RC1994925
- 40FS6646, 32FR6634, 42FR6634, 40FR5634, 40FR8634, 46FR6634
- RC1994920, 26HE8234B, 26HR3022, 26HR5234, 19HR5234, 22HR5234
- 32FR5234, 46FR8634, 26HE8022, 32HR3022, 26HR3234, 22HR5434
- 32HE8022, 19HR3234, 32HR3234, 22HR3234, 52FE9234B, 40FR5234
- 32HE8234B, 19HR5434



Figure 4.1: Side view of the remote control, illustrating its ergonomic shape.

## 5. SPECIFICATIONS

<b>Brand</b>	ALLIMITY
<b>Model Name</b>	RC1994925
<b>Color</b>	Black
<b>Connectivity Technology</b>	Infrared
<b>Special Feature</b>	Universal (for specified models)
<b>Maximum Range</b>	10 Meters
<b>Number of Supported Devices</b>	10 (referring to the number of compatible models, not simultaneous control)



Figure 5.1: Top-down angled view of the remote control, providing a clear perspective of the button layout.

## 6. TROUBLESHOOTING

If your ALLIMITY RC1994925 remote control is not functioning as expected, please follow these troubleshooting steps:

1. **Check Batteries:** Ensure that the batteries are inserted correctly with the correct polarity (+/-). Replace old

batteries with new AAA alkaline batteries.

2. **Line of Sight:** Make sure there is a clear line of sight between the remote control and the TV's infrared receiver. Obstructions can block the signal.
3. **Remote Control Distance:** Operate the remote within the effective range (approximately 10 meters) of the TV.
4. **TV Compatibility:** Verify that your TV model is listed in the "Compatible TV Models" section of this manual. This remote is designed for specific Thomson and TCL models.
5. **Infrared Interference:** Bright sunlight or strong artificial light sources can sometimes interfere with infrared signals. Try operating the remote in a different lighting condition.
6. **Test Remote:** You can test if the remote is emitting an IR signal using a smartphone camera. Point the remote's IR emitter at your phone's camera and press a button. You should see a small light flashing on your phone screen (not visible to the naked eye). If no light is visible, the remote may be faulty or batteries are completely drained.

## 7. MAINTENANCE

---

To ensure the longevity and proper functioning of your remote control, follow these maintenance guidelines:

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, abrasive pads, or chemical solvents, as these can damage the surface or internal components.
- **Avoid Moisture:** Keep the remote control away from water, humidity, and other liquids.
- **Temperature:** Do not expose the remote control to extreme temperatures (hot or cold) or direct sunlight for extended periods.
- **Dropping:** Avoid dropping the remote control, as this can cause internal damage.
- **Battery Removal:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage.

## 8. WARRANTY AND SUPPORT

---

Specific warranty information and direct customer support details for the ALLIMITY RC1994925 remote control are not available in this document. Please refer to the retailer or your purchase documentation for any warranty claims or support inquiries.