

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

### TomTom TomTom GO Discover 7"

## TomTom GO Discover 7" GPS Navigation Device User Manual

Brand: TomTom | Model: TomTom GO Discover 7"

### INTRODUCTION

The TomTom GO Discover 7" GPS Navigation Device is designed to provide powerful, reliable, and effortless navigation. Equipped with TomTom's advanced technology, it offers real-time traffic updates, world maps, and a suite of services including fuel pricing, parking availability, and speed camera alerts. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your device to ensure a smooth and comfortable driving experience.



Image: The TomTom GO Discover 7" GPS device displaying a navigation route.


### WHAT'S IN THE BOX

Before you begin, ensure all components are present:

- Batteries
- TomTom GO Discover 7" GPS Device

- Click-and-Drive Mount
- USB Cable
- Car Charger

# What's in the box



*Image: All items included in the TomTom GO Discover package.*

## SETUP

### Mounting the Device

The TomTom GO Discover 7" comes with a Click-and-Drive mount for easy installation. This mount can be used on your dashboard or windshield.

1. Assemble the Click-and-Drive mount by connecting the device cradle to the suction cup base.
2. Choose a suitable location on your windshield or dashboard that does not obstruct your view of the road.
3. Press the suction cup firmly against the chosen surface and engage the lever to secure it.
4. Slide your TomTom GO Discover device onto the mount until it clicks into place.



17.78 cm (7")  
HD Touch Screen

On / Off

Click-and-Drive  
Mount

Micro USB Port

High-quality  
speaker

*Image: Rear view of the TomTom GO Discover showing the Click-and-Drive mount, Micro USB Port, On/Off button, and High-quality speaker.*

## Powering On and Initial Setup

- Connect the USB cable to the device and the car charger, then plug the charger into your vehicle's 12V power outlet.
- The device will automatically power on. Follow the on-screen instructions to select your language, region, and accept the terms and conditions.
- Connect to a Wi-Fi network for map updates and live services.

## OPERATING INSTRUCTIONS

### Navigation Basics

The TomTom GO Discover features a highly responsive 7-inch HD touchscreen for intuitive interaction.

- **Entering a Destination:** Tap the search icon on the main map view and enter an address, point of interest, or coordinates.
- **Map Interaction:** Use pinch-to-zoom and swipe gestures to explore the map.
- **Route Guidance:** Once a destination is set, the device will calculate the optimal route and provide clear turn-by-turn voice instructions and visual cues.



## Highly responsive screen and intuitive user interface

Simple and distortion-free menu navigation.



*Image: A hand demonstrating the highly responsive touchscreen for smooth swiping and zooming on the TomTom GO Discover.*

### Real-time Services

Your TomTom GO Discover provides access to various real-time services via Wi-Fi connectivity:

- **TomTom Traffic:** Receive live traffic congestion information and efficient re-routing suggestions to avoid delays.
- **Speed Camera Alerts:** Get timely warnings about fixed and mobile speed cameras.
- **Fuel Prices:** View real-time fuel prices at nearby gas stations.
- **Parking Availability:** Find available parking spots and information on parking facilities.



## **Live off-street parking and fuel prices info**

Find convenient parking spots  
and fuel prices along your route.



*Image: The TomTom GO Discover displaying live off-street parking and fuel prices information along a route.*





## TomTom Traffic

Efficient (re)routing around traffic, accurate ETAs and speed camera warnings.



*Image: The TomTom GO Discover displaying TomTom Traffic information, including efficient re-routing and speed camera warnings.*

### Map Updates via Wi-Fi

Keep your maps up-to-date with 3x faster map updates via Wi-Fi. Connect your device to a stable Wi-Fi network to download the latest maps and software updates.

- Navigate to the "Settings" menu on your device.
- Select "Maps & Updates" or a similar option.
- Choose the maps you wish to update or add new regions.
- Ensure your device remains connected to power during the update process.

### Voice Control

For enhanced focus and safety, the TomTom GO Discover supports voice control. Simply say "Hello TomTom" followed by your command, such as "Go home" or "Find a gas station."

### MAINTENANCE

- **Cleaning:** Use a soft, lint-free cloth to clean the screen and device exterior. Avoid abrasive cleaners or solvents.
- **Storage:** When not in use, store the device in a cool, dry place away from direct sunlight and extreme temperatures.

- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the device regularly.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Device not turning on	Low battery; Power cable not connected properly.	Charge the device for at least 30 minutes. Ensure the power cable is securely connected to both the device and the car charger.
No GPS signal	Device is indoors; Obstructed view of the sky.	Move the device to an open area with a clear view of the sky. Ensure no metallic objects are blocking the signal.
Touchscreen unresponsive	Temporary software glitch.	Perform a soft reset by holding the power button for 15-20 seconds until the device restarts.
Map updates are slow or fail	Weak Wi-Fi signal; Insufficient storage space.	Ensure a strong Wi-Fi connection. Check available storage and delete unnecessary maps if needed.

## SPECIFICATIONS

Feature	Detail
Product Dimensions	7.48 x 0.79 x 4.72 inches
Item Weight	14.1 ounces
Item Model Number	TomTom GO Discover 7"
Batteries	1 Lithium Ion batteries required (included)
Operating System	Android
Wireless Communication Technologies	Bluetooth, Wi-Fi
Connectivity Technologies	Bluetooth, USB, Wi-Fi
Human Interface Input	Touchscreen
Scanner Resolution	480 x 272
Color	Black
Manufacturer	TomTom
Screen Size	7 Inches
Map Type	Worldwide
Audio Output Mode	Speaker
Mounting Type	Dashboard Mount, Windshield Mount

## WARRANTY AND SUPPORT

For detailed warranty information and technical support, please refer to the official TomTom website or contact TomTom customer service. Keep your proof of purchase for warranty claims.

You can visit the official TomTom Store for more information: [TomTom Store](#)

© 2023 TomTom. All rights reserved.

This product can expose you to chemicals including Bisphenol A and lead content, which are known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov).