

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Real Flame](#) /
- › [Real Flame Riverside 58" Oval Propane Fire Pit Bowl Instruction Manual](#)

Real Flame 592LP-SHL

Real Flame Riverside 58" Oval Propane Fire Pit Bowl Instruction Manual

Model: 592LP-SHL | Brand: Real Flame

1. INTRODUCTION

This manual provides essential information for the safe assembly, operation, and maintenance of your Real Flame Riverside 58" Oval Propane Fire Pit Bowl. Please read all instructions carefully before use and retain this manual for future reference.



Image: The Real Flame Riverside 58" Oval Propane Fire Pit Bowl, showcasing its design and flame.

2. SAFETY INFORMATION

Your safety and the safety of others are paramount. Always follow all safety warnings and instructions provided. This product is CSA certified, ensuring it meets recognized safety standards.

- **Proposition 65 Warning:** This product can expose you to chemicals including carbon monoxide, which is known to the State of California to cause birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.
- Ensure proper ventilation when operating.
- Keep children and pets away from the fire pit during operation.
- Do not use in enclosed spaces.

With Your Safety In Mind



CSA Certified



One-Year
Limited Warranty



Safe For Use On
A Wood Deck



Weather Resistant
MGO

Image: Visual representation of key safety features and certifications.

3. WHAT'S INCLUDED

Carefully unpack all components and ensure you have received the following items:

- Fire bowl with leveling feet
- 28" linear stainless steel burner
- Gray pumice stone
- Tank seat
- 10' LP hose with regulator
- Vinyl storage cover
- Battery for ignition

What's Included



Vinyl Storage Cover
(style may vary)



Gray Pumice Stone



Propane Tank Seat



Battery Included

Image: An illustration detailing all parts included with the fire pit.

4. SETUP AND ASSEMBLY

Basic assembly is required for this fire pit. Please follow the detailed instructions provided in the full product manual for step-by-step guidance. Ensure all connections are secure before use.



Image: Dimensions of the fire pit, crucial for planning placement and assembly.

5. OPERATING INSTRUCTIONS

To operate your Real Flame Riverside Fire Pit Bowl:

1. Connect the 10' LP hose with regulator to a 20 lb LP tank.
2. Place the tank on the provided tank seat.
3. Ensure the battery for the push-button ignition is correctly installed.
4. Turn on the gas supply at the LP tank.
5. Press and hold the push-button ignition while turning the control knob to the 'ON' position.
6. Adjust the flame height using the control knob to achieve your desired heat output (up to 50,000 BTUs).

A 20 lb LP tank provides approximately 8 hours of burn time on a high setting and up to 26 hours on a low setting.

**Stainless Steel
Burner**



**Push Button
Ignition**



**Gray Pumice
Stone**



**50,000
BTU Output**



Feature Highlights

Image: Key operational components including the burner and ignition system.

For visual guidance on operation, please refer to the official product videos or the complete manual.

6. MAINTENANCE

To ensure the longevity and optimal performance of your fire pit:

- The fire pit is crafted from durable MGO and is weather and UV resistant.
- Use the included vinyl storage cover to protect the fire pit from the elements when not in use.
- Regularly inspect the hose and connections for any signs of wear or damage.
- Clean the exterior with a soft cloth and mild detergent as needed.

7. TROUBLESHOOTING

If you encounter any issues with your fire pit, please consult the comprehensive troubleshooting section in the full product manual. Common issues and their solutions are typically covered there.

8. SPECIFICATIONS

Feature	Detail
Model Number	592LP-SHL
Material	Metal (MGO)
Product Dimensions	32.25"D x 57.99"W x 17.25"H
Item Weight	105 Pounds
Fuel Type	Liquefied Petroleum Gas (LP)
Heat Output	50,000 BTUs
Burner Size	28" linear stainless steel
Burn Area Dimensions	52"L x 26"W x 3.25"D
Ignition Type	Battery operated push button
Conversion Option	Can be converted to natural gas with Real Flame conversion kit G0002-11 (not included), by a certified gas technician.
Certifications	CSA certified

9. WARRANTY AND SUPPORT

This Real Flame product comes with a **1-year limited warranty**. For warranty claims, technical assistance, or any other inquiries, please contact Real Flame Customer Support. Refer to the original product packaging or the Real Flame website for specific contact details.

Online Resources: For additional information, FAQs, and support, visit the official Real Flame website.