

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Glow Guards](#) /
- › [Glow Guards Unicorn Stuffed Animal Instruction Manual](#)

Glow Guards Unicorn Stuffed Animal

Glow Guards Unicorn Stuffed Animal Instruction Manual

Model: Unicorn Stuffed Animal

INTRODUCTION

Thank you for choosing the Glow Guards Unicorn Stuffed Animal. This plush toy features a beautiful rainbow design, soft materials, and interactive elements including colorful LED lights and soothing music. This manual provides essential information for safe and optimal use of your new unicorn toy.



Image: The Glow Guards Unicorn Stuffed Animal, illuminated with various colors, showcasing its soft plush texture and friendly expression.

SAFETY INFORMATION

- Children under 3 years old should use this product under adult supervision.
- Do not machine wash the toy. Refer to the maintenance section for cleaning instructions.
- Ensure batteries are installed correctly and securely.
- Remove batteries if the toy will not be used for an extended period.

PACKAGE CONTENTS

Your package should contain the following items:

- 1 x Glow Guards Unicorn Stuffed Animal (13 inches)
- 1 x Best Wishes Card (optional, for gifting)



Image: The unicorn toy displaying its approximate 13-inch height and 7-inch width, alongside CE, CPSC, and ASTM safety certifications.

SETUP: BATTERY INSTALLATION

To activate the light and music functions, batteries must be installed.

1. Locate the Velcro closure on the back of the unicorn toy.
2. Open the Velcro to access the battery compartment.
3. Open the battery box cover.
4. Insert 3 AAA batteries (not included) into the battery box, ensuring correct polarity (+/-).
5. Close the battery box cover securely.

6. Turn the small black switch on the battery box to the 'ON' position.
7. Place the battery box back inside the toy and close the Velcro closure.




Image: A detailed view of the battery compartment located on the back of the unicorn, indicating where to insert batteries.

OPERATING INSTRUCTIONS

Once batteries are installed and the power switch is ON, you can operate the unicorn's functions:

Music Function:

- Press the '♪' button located on the left foot of the unicorn to start playing a song.
- Press the '♪' button again to pause the current song.
- Press the '♪' button a third time to switch to the next song in the playlist.
- The toy contains 10 nursery rhymes, including:
 - Mary Had a Little Lamb
 - Rain Rain Go Away
 - Twinkle Twinkle Little Star
 - Five Little Monkeys
 - Hickory Dickory Dock
 - Wheels on the Bus
 - Do Another Mi
 - Fish and Fish
 - If You Are Happy and You Know It

Light Function:

- Press the light button (often integrated with the music button or a separate button on the foot) to activate the colorful

LED lights.

- The lights will glow and cycle through various colors.
- A 15-minute auto-off timer is installed for the lights, promoting energy saving and a gentle sleep environment.

Try Me

15MIN AUTO-OFF TIMER 

More energy-saving and healthier for your kids

FRONT

SIDE

BACK

COLORFUL LIGHTING

Image: The unicorn plush toy highlighting the "Try Me" button on its left foot, which controls both lights and music, and an icon indicating the 15-minute auto-off timer.

Demonstration Video:

Your browser does not support the video tag.

Video: A demonstration of the Glow Guards Unicorn Stuffed Animal's light and music functions, showing how to activate them by pressing the foot button.

PRODUCT FEATURES

- **Beautiful Appearance:** Features a rainbow gradient body, pink horn, and soft tail and mane, designed to be visually appealing.
- **Glow at Night:** Integrated LED lights provide a colorful glow, creating a soothing sensory experience.

- **Musical Lullabies:** Plays 10 popular nursery rhymes with clear singing voices.
- **15-Minute Auto-Off Timer:** Lights automatically turn off after 15 minutes to conserve battery life and aid sleep.
- **High-Quality Materials:** Made from soft plush materials and filled with PP cotton, ensuring a delicate feel and safety.

More Details

We are willing to do more to keep our children safe

Vivid Features

Skin-friendly fabric

Furry tail

Image: Close-up views highlighting the unicorn's vivid features, the soft, skin-friendly fabric, and its furry tail, emphasizing material quality.



SOOTHING MUSIC

10 Famous Songs Among Children

- ✓ Rain Rain Go Away
- ✓ Twinkle Twinkle Little Star
- ✓ Five Little Monkeys
- ✓ Baby Shark
- ✓ If You are Happy and You Know It
-

Try Me



DREAM LIGHT

15min Auto-Off Timer

- ✓ More energy-saving
- ✓ Healthier for your kids

Try Me

Image: The unicorn toy illustrating its soothing music capabilities with 10 songs and the "Dream Light" function, which includes a 15-minute auto-off timer.

MAINTENANCE

Proper care will extend the life of your Glow Guards Unicorn Stuffed Animal.

- **Cleaning:** We recommend hand washing or wiping dirty areas with a wet cloth. Machine washing is not advised as it may damage the toy's softness and internal electronic components.
- **Storage:** Store the toy in a dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** Remove batteries if the toy is not used for an extended period to prevent leakage.

TROUBLESHOOTING

If you encounter any issues, please refer to the following common problems and solutions:

Problem	Solution
---------	----------

Problem	Solution
Lights or music do not work.	<p>Ensure 3 AAA batteries are correctly installed with proper polarity.</p> <p>Check if the small black switch on the battery box is in the 'ON' position.</p> <p>Replace old batteries with new ones.</p> <p>Ensure the 'J' button or light button on the foot is pressed firmly.</p>
Music stops unexpectedly.	This may be due to the 15-minute auto-off timer for lights. Press the music button again to restart. Check battery level.
Lights are dim or flickering.	Replace batteries with new ones.



Image: A graphic addressing common questions, including potential color differences between images and the actual product, and confirming hand washing for cleaning.

SPECIFICATIONS

Feature	Detail
Product Dimensions	10 x 4 x 2 inches (approx. 13 inches tall)
Item Weight	9.3 ounces
Power Source	3 x AAA Batteries (not included)
Recommended Age	0 months and up (with adult supervision for young children)
Material	High-quality plush, PP cotton filling

Feature	Detail
Light Feature	Colorful LED lights with 15-minute auto-off timer
Music Feature	10 built-in nursery rhymes

WARRANTY AND SUPPORT

Glow Guards is committed to providing high-quality products. For any questions or concerns regarding your product, please contact us via Amazon News. The Glow Guards team will reply and assist you as soon as possible. Please retain your proof of purchase for any warranty claims, though specific warranty terms are not detailed here. Your satisfaction is our priority.

