

[Manuals.plus](#) /

› [chuangquan](#) /

› chuangquan E-YOOSO Z-66 Mechanical Gaming Keyboard User Manual

chuangquan Z-66

E-YOOSO Z-66 Mechanical Gaming Keyboard User Manual

Model: Z-66

INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, maintenance, and troubleshooting of your chuangquan E-YOOSO Z-66 Mechanical Gaming Keyboard. The Z-66 is an 87-key Tenkeyless (TKL) mechanical keyboard featuring tactile brown switches, customizable LED backlighting, and a detachable Type-C USB cable for enhanced portability and convenience.



Image: The E-YOOSO Z-66 Mechanical Gaming Keyboard connected and in use, showcasing its compact design and backlighting.

PACKAGE CONTENTS

Please verify that all items are present in the package:

- E-YOOSO Z-66 Mechanical Gaming Keyboard
- USB Cable (Type-C to Type-A)

SETUP INSTRUCTIONS


1. **Connect the USB Cable:** Locate the Type-C port on the back of the keyboard. Insert the Type-C end of the provided USB cable into the keyboard port.
2. **Connect to Computer:** Insert the Type-A end of the USB cable into an available USB port on your computer.
3. **Driver Installation:** The keyboard is plug-and-play and typically does not require additional driver installation for basic functionality on Windows 10, 8, 7, XP, and Mac operating systems.
4. **Placement:** Position the keyboard comfortably on your desk. The keyboard features rubber holders and pads on the underside for stability.



Rubber holder



Rubber pad



Drain hole



anti-interference
electromagnetic loop



Gold plated
USB connector

Image: The underside of the E-YOOSO Z-66 keyboard, highlighting the detachable Type-C USB connector, rubber holders, rubber pads, and drain holes for splash resistance.

OPERATING INSTRUCTIONS

Key Features

- **Brown Mechanical Switches:** The keyboard is equipped with brown mechanical switches, offering a tactile feedback with a slight click and a moderate actuation force. This design provides a balance between typing comfort and gaming responsiveness.
- **87-Key Anti-Ghosting:** The compact 87-key layout features full anti-ghosting, ensuring that all key presses are registered accurately, even during rapid, simultaneous inputs, which is crucial for gaming and fast typing.
- **Detachable Type-C Cable:** The Type-C USB cable is detachable, enhancing portability and making cable management easier.



Image: A close-up view of the Outemu Brown Switches on the E-YOOSO Z-66 keyboard, illustrating their tactile feedback mechanism.

Backlight Control

The Z-66 keyboard features customizable LED backlighting with multiple modes and adjustments:

- **Change Lighting Mode:** Press **FN + INS** to cycle through 9 different lighting modes.
- **Adjust Brightness:** Use dedicated function key combinations (not specified in product details, typically **FN + Up/Down** arrow or similar) to adjust the 5 levels of brightness.
- **Adjust Lighting Speed:** Use dedicated function key combinations (not specified in product details, typically **FN + Left/Right** arrow or similar) to adjust the 5 levels of lighting speed.
- **Turn Lights On/Off:** Use a dedicated function key combination (not specified in product details) to toggle the backlighting on or off.

More rainbow Backlit Modes




9 Lighting
Modes



5 Adjustable
Brightness



5 Adjustable
Lighting Speed



Lights
On/Off

Image: The E-YOOSO Z-66 keyboard showcasing its multiple rainbow backlit modes, indicating 9 lighting modes, 5 adjustable brightness levels, 5 adjustable lighting speeds, and an on/off function.

Multimedia Keys

Access multimedia functions by pressing the **FN** key in combination with the **F1** through **F11** keys. Specific functions for each F-key are typically indicated by icons printed on the keycaps.

MAINTENANCE

- **Cleaning:** The keyboard features a sweat and corrosion-resistant alloy plate surface, making it easy to clean. Use a soft, dry cloth to wipe down the keycaps and surface. For deeper cleaning, you may use a slightly damp cloth, ensuring no liquid enters the keyboard.
- **Water Resistance:** The keyboard has a splash-proof design with drain holes on the underside. While it offers some protection against accidental spills, it is not fully waterproof. Avoid submerging the keyboard in liquid.
- **Storage:** The detachable Type-C cable allows for convenient storage and transport of the keyboard.

TROUBLESHOOTING

- **Keyboard Not Responding:**
 - Ensure the USB cable is securely connected to both the keyboard and the computer.
 - Try connecting the keyboard to a different USB port on your computer.
 - Test the keyboard on another computer to rule out system-specific issues.
- **Keys Not Registering / Ghosting:** The Z-66 features 87-key anti-ghosting, which prevents most key registration issues. If specific keys are not working, ensure no debris is lodged under the keycap.
- **Backlight Not Working:**
 - Ensure the backlight is not turned off (refer to Backlight Control section).
 - Adjust brightness levels to ensure it's not set to the lowest setting.

SPECIFICATIONS

Brand	chuangquan
Model	Z-66
Product Dimensions	35.5 x 12.4 x 2.8 cm
Item Weight	712 g
Operating System Compatibility	Windows, Mac
Hardware Interface	USB
Compatible Devices	PC
Special Features	Backlit, Ergonomic, Water Resistant
Connector Type	USB-C
Hand Orientation	Ambidextrous

Colour	Brown Switch
Date First Available	17 July 2021

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided with your purchase or contact the retailer/manufacturer directly. Keep your proof of purchase for any warranty claims.

© 2023 chuanguan. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question