

[Manuals.plus](#) /

› [DL-pro](#) /

› DL-pro Aquastop Safety Inlet Hose 2.19m for Dishwashers Instruction Manual

DL-pro Aquastop Safety Inlet Hose

DL-pro Aquastop Safety Inlet Hose Instruction Manual

INTRODUCTION

This manual provides essential information for the installation, operation, and maintenance of your DL-pro Aquastop Safety Inlet Hose. This hose is designed to prevent water damage by automatically shutting off the water supply in case of an internal leak. Please read these instructions carefully before installation and retain them for future reference.



Image: The DL-pro Aquastop Safety Inlet Hose, illustrating its connection points to a water tap and a dishwasher. Key specifications like 3/4 inch connection and 2.19m length are highlighted.

SETUP AND INSTALLATION

The DL-pro Aquastop Safety Inlet Hose is a replacement part for dishwashers. Installation typically involves replacing an existing inlet hose. Always ensure the main water supply is turned off and the appliance is disconnected from power before beginning installation.

1. **Preparation:** Turn off the main water supply to your dishwasher. Disconnect the dishwasher from the electrical outlet.
2. **Remove Old Hose:** Carefully disconnect the old inlet hose from both the water tap and the dishwasher's water inlet valve. Be prepared for residual water to drain.
3. **Connect to Water Tap:** Attach the 3/4 inch screw connection of the new DL-pro Aquastop hose to your water tap. Ensure the connection is hand-tightened, then use a wrench to tighten it an additional quarter turn. Do not overtighten.
4. **Connect to Dishwasher:** Connect the other end of the Aquastop hose to the water inlet valve on your dishwasher. This connection also requires careful tightening to prevent leaks.

5. **Electrical Connection:** The Aquastop unit includes an electrical connection. This must be properly connected to the dishwasher's internal wiring as per your dishwasher's specific service manual. If you are unsure, consult a qualified technician.
6. **Check for Leaks:** Slowly turn on the main water supply and visually inspect all connections for any signs of leakage.
7. **Restore Power:** Once all connections are secure and leak-free, reconnect the dishwasher to the electrical outlet.

For detailed instructions on accessing your dishwasher's internal components or specific wiring, refer to your appliance's original service manual.



Image: A detailed view of the DL-pro Aquastop Safety Inlet Hose, highlighting the electrical wiring and the water inlet valve for connection to the appliance.

OPERATION

The DL-pro Aquastop Safety Inlet Hose operates automatically. Once correctly installed and connected to the water and electrical supply, it continuously monitors for internal leaks within the hose. In the event of a leak, the Aquastop

mechanism will automatically shut off the water supply to prevent flooding. No manual intervention is required for its safety function during normal operation.

MAINTENANCE

To ensure the longevity and proper functioning of your Aquastop safety inlet hose, consider the following maintenance guidelines:

- **Regular Inspection:** Periodically inspect the entire length of the hose for any visible signs of wear, kinks, cracks, or damage. Check connections for any drips or moisture.
- **Filter Cleaning:** Some water inlet valves or taps may have a filter screen. If your dishwasher experiences reduced water flow, check and clean this filter as per your dishwasher's manual.
- **Avoid Kinks:** Ensure the hose is not bent or kinked, as this can restrict water flow or damage the hose over time.
- **Winterization (if applicable):** If your appliance is in an area subject to freezing temperatures, ensure the water supply to the hose is drained and disconnected to prevent damage from freezing water.

TROUBLESHOOTING

If you encounter issues with your dishwasher's water supply after installing the Aquastop hose, consider the following:

- **No Water Supply:**
 - Ensure the water tap connected to the hose is fully open.
 - Check for any kinks or blockages in the hose.
 - Verify that the electrical connection to the Aquastop unit is secure and receiving power.
- **Dishwasher Error Code (e.g., E02):** Some dishwashers display error codes related to water inlet issues. Consult your dishwasher's manual for the specific meaning of the code. If the code indicates a water supply problem, follow the steps above.
- **Aquastop Triggered (No Water, but tap is open):** If the Aquastop unit has activated and shut off the water, it indicates a detected leak within the hose. In this scenario, the hose cannot be reset and must be replaced.
- **Leakage at Connections:** If you observe water leaking from the connections, turn off the water supply immediately. Re-tighten the connections, ensuring the rubber seals are correctly seated and not damaged. If leakage persists, the seals or hose may be faulty and require replacement.

SPECIFICATIONS

Feature	Detail
Total Length	2.19 meters
Connection Screw	3/4 inch
Material	Polypropylene (PP)
Maximum Pressure	10 Bar
Electrical Rating (Type 100390)	5A, 220-240V ~ 50-60 Hz, 6VA
Electrical Rating (Type 1ES-L)	220-240V ~ 50-60Hz, 8VA

Feature	Detail
Color	Grey/Red/White
Specific Product Use	Used in dishwashers, washing machines, and dryers

COMPATIBILITY

This DL-pro Aquastop Safety Inlet Hose is compatible with a wide range of dishwashers from various manufacturers. Key compatible brands and original part numbers include:

- **Arçelik, Arctic, Altus, Beko, Blomberg:** Replaces part numbers such as 1885090400 (and its predecessors 1885090100, 1760360200, 1760360100).
- **Bauknecht, Ignis, Philips, Whirlpool, Ikea:** Replaces part numbers such as 481253029201 (and its predecessors 482000004937, 481253029416, 481253029014).
- **Indesit, Ariston, Hotpoint, Scholtès:** Replaces part numbers such as C00588407 (and its predecessors C00557377, C00409026, C00405613).
- **Amica:** Replaces part numbers such as 1032070, 1009009.
- **Fagor:** Replaces part numbers such as AS0039193.

A comprehensive list of compatible appliance models and brands is provided in the images below. Please compare the model numbers of your appliance with the lists to ensure compatibility. If you are uncertain about compatibility, please contact DL-pro customer service.

Ersatzteil passend für folgende Geräte:

7612120253	7629031642	7646420253	7666431642	7683737342
7612220253	7629043942	7646643942	7666451645	7684383342
7612382942	7629143942	7646743942	7666639042	7684483342
7612482900	7629243942	7646843942	7667848342	7684983353
7612482942	7630441655	7647181642	7667941642	7685183342
7612582942	7630641655	7647281642	7668041642	7685853945
7612681642	7631053971	7647982042	7668543942	7685983942
7612737342	7631433845	7650137342	7669210242	7687231642
7612781642	7632131642	7651270253	7670388342	7687331655
7612881642	7632633945	7651281645	7670431642	7687431642
7613189242	7632920242	7651341653	7672144153	7687531645
7613284242	7633587342	7651441653	7672541642	7687631671
7613287342	7633687342	7651631642	7673031642	7687731642
7613384242	7633981642	7652143942	7673243971	7687931653
7613420200	7634081642	7653383342	7673943953	7688331645
7613487342	7634181642	7654143942	7674234942	7688753945
7613745042	7634281642	7654243942	7674933942	7689053845
7614789200	7634381642	7654333942	7675033942	7689242645
7614789242	7634481642	7654733900	7675133942	7690734142
7615287342	7637843842	7655243953	7675443342	7690750355
7615738345	7638283745	7656343942	7675643942	7691083942
7617451645	7638383745	7656553945	7675983942	7691981653
7617551671	7638735042	7656681653	7676081642	7692081653

7617738345	7638835042	7656781653	7676331671	7692181653
7618051645	7638858345	7656881653	7676431642	7692281653
7618253945	7639135042	7657353945	7676831642	7692381653
7618441642	7639235042	7657433942	7676931671	7692481653
7619038345	7639542642	7657588345	7677333942	7693383942
7619783945	7639641042	7657688345	7678543942	7693647642
7619947642	7640041053	7657788345	7678643942	7694343942
7620647642	7640241053	7657930342	7678743942	7695051671
7620951671	7641370242	7658543942	7678788342	7695243945
7621351645	7642032042	7658844942	7678843942	7696333942
7622443953	7642131042	7659343942	7679588342	7696633942
7624353945	7642237642	7659353945	7679631655	7696683945
7624387342	7642637642	7659381642	7679731655	7697253945
7624444955	7642641042	7659483845	7680231645	7697453945
7624553945	7642731642	7659542642	7680588342	7697485042
7625431645	7643441645	7660453945	7680844142	7697553945
7627331645	7643741653	7661443953	7680944142	7698233945
7627431645	7643841653	7661484953	7681947642	7698353900
7627533945	7645643945	7661584953	7682047642	7698653900
7627831671	7645830345	7663231645	7682643942	7698953945
7627931642	7645930345	7664153945	7682743942	7699136942
7628058345	7646120242	7664633971	7682843942	7699146953
7628231642	7646220242	7664733971	7683343942	7699246942
7628543942	7646237742	7665233942	7683483342	7699336942
7628744953	7646320242	7665347342	7683537342	7699436953

FRAGEN? Wenn Sie nicht sicher sind ob dieser Artikel der passende ist, hilft Ihnen unser kompetenter Kundenservice jederzeit gerne weiter und berät Sie gerne.

Image: Part 1 of the compatibility list, detailing model numbers for various brands.

Ersatzteil passend für folgende Geräte:

7699446942	7603381610	7616184142	7635270442	7650441645
7699536953	7603381642	7616284142	7635270842	7650541645
7699546942	7603387642	7616381642	7635354145	7650741642
7699636942	7603481600	7616481642	7635847642	7650831642
7699651645	7603481642	7616581642	7636047653	7650841642
7699736942	7604543942	7616681642	7636244142	7650941642
7699751645	7604643942	7616781642	7637147642	7651041642
7699836953	7604743942	7617253945	7637247642	7651541642
7699851655	7604781600	7622553945	7638033853	7651643942
7699936942	7604781610	7622644142	7639381642	7652733942
BLANCO	7604781642	7623153945	7639481642	7653043942
7614249042	7604787642	7623947642	7639835042	7653143942
7618949042	7604843942	7624687642	7640635042	7653233945
7619049042	7604881600	7624787642	7643141642	7653243942
7619149042	7604881642	7624887642	7643331645	7653333945
7687889042	7604943942	7624987642	7643431645	7653643942

7687989042	7604981600	7625087642	7643631642	7653743942
7688089042	7604981610	7625147645	7644743942	7653943942
7688189042	7604981642	7625187642	7645141642	7654043942
7688289042	7604987642	7625283042	7645283342	7654183345
Blomberg	7605043942	7625383042	7645343845	7654443953
7600443942	7605081600	7625483042	7645383342	7654533942
7600543942	7605081642	7625583042	7645443942	7654543953
7601084100	7605143942	7628133845	7645483342	7654743942
7601153845	7605443971	7628347645	7645543942	7654843945
7602153845	7605543945	7628447645	7645782045	7656744142
7602681600	7605643942	7628843853	7645882045	7657981642
7602681610	7607484100	7629943942	7645982045	7658081645
7602681642	7607584100	7630187642	7645986945	7658181645
7602687642	7607684100	7630287642	7646284142	7658281642
7602781600	7607884100	7630387642	7646488142	7658381642
7602781610	7607984100	7630743945	7646543942	7658481642
7602781642	7608543942	7631741642	7646588142	7658581645
7602787642	7609581610	7632483342	7646733942	7658681645
7602881600	7609581620	7632583345	7647770442	7659187645
7602881642	7609581630	7632683342	7647770842	7659781642
7602943942	7613841642	7632783342	7647843942	7660741642
7603043942	7614347642	7632841642	7647943942	7660837642
7603081600	7614747645	7633144942	7648143945	7661537642
7603081610	7614943942	7633244942	7648243945	7661637642
7603081642	7615383342	7634335042	7648343945	7661837642
7603087642	7615483342	7634343942	7648943942	7661937642
7603181600	7615583342	7634435042	7649143945	7661987645
7603181610	7615684842	7634835042	7649243945	7662037642
7603181642	7615884142	7634954145	7649343942	7662087645
7603281600	7615984142	7635043942	7650041645	7662137645
7603281642	7616043942	7635170442	7650141645	7662187645
7603381600	7616084142	7635170842	7650241642	7662287645

FRAGEN? Wenn Sie nicht sicher sind ob dieser Artikel der passende ist, hilft Ihnen unser kompetenter Kundenservice jederzeit gerne weiter und berät Sie gerne.

Image: Part 2 of the compatibility list, showing additional brands and model numbers.

Ersatzteil passend für folgende Geräte:

7662337645	7684631642	7696246942	7603783742	7611883700
7662537645	7684731642	7696346942	7603883700	7611883742
7662637642	7684744142	7696583942	7603883742	7611983700
7663241645	7684844142	7696646942	7603983700	7611983742
7663643945	7684934145	7697131642	7603983742	7612083700
7663841653	7684944142	7698133945	7604083700	7612083742
7664044142	7685044142	7699533942	7604083742	7614283742
7665731642	7685144142	7699633942	7604183700	7614383742

7665831642	7685331642	Brandt	7604183742	7617741042
7666257645	7685431642	7652187345	7604283700	7618131042
7666443353	7685534142	Cylinda	7604283742	7618231042
7666531642	7685634142	7611244145	7604383700	7618331042
7666543353	7685643942	7611344142	7604383742	7618431042
7667741642	7686644153	7611444142	7604483700	7622051045
7668141642	7686744153	7612154145	7604483742	7622151045
7670033942	7688144942	7612954145	7604583700	7622251045
7670631642	7688244942	7614534145	7604583742	7622651045
7670831642	7689084953	7622044142	7604683700	7622851045
7671634142	7689184953	7622144142	7604683742	7630031042
7671947642	7689284953	7665364145	7605183700	7630131045
7671986942	7689384953	7665464145	7605183742	7630731042
7672086942	7689484953	7667264145	7605283700	7630831045
7672186942	7689533945	7672134142	7605383700	7630931045
7672286942	7689633945	7672234142	7605383742	7632741642
7672386942	7689687642	7672334142	7605483700	7633131042
7672486942	7690270442	De Dietrich	7605583700	7636541042
7672586942	7691444142	7651687345	7605583742	7636641042
7672686945	7691531642	7651787345	7605683700	7636841042
7672786945	7691631642	7651887345	7605683742	7640441042
7672834142	7692031645	7651987345	7605783700	7640541042
7672886945	7692131642	7659583845	7605841042	7641941042
7674048345	7692233945	DEFY	7605883700	7642041042
7674176942	7692333945	7621849042	7605883742	7642741042
7674186942	7692433945	7674949042	7605983700	7642841042
7675741642	7692533942	7695849042	7606083700	7642881042
7676983942	7692587642	7695949042	7606083742	7642941042
7678431642	7692633942	Ecron	7606183700	7642981042
7678533942	7693541642	7668082442	7606183742	7643081042
7678731642	7694431645	ElektraBregenz	7606341042	7643181042
7678831642	7694444142	7602041042	7606441042	7643281042
7679831642	7694531645	7602141042	7606541042	7643381042
7682933945	7694544142	7602241042	7606741042	7643481042
7683933945	7694631645	7602341042	7606841071	7643581042
7684033942	7694643942	7603583700	7609683700	7643681042
7684133942	7694747642	7603583742	7609683742	7643781042
7684231642	7694843942	7603683700	7611141042	7643881042
7684331642	7695341642	7603683742	7611783700	7643981042
7684433942	7695441642	7603783700	7611783742	7644081042

FRAGEN? Wenn Sie nicht sicher sind ob dieser Artikel der passende ist, hilft Ihnen unser kompetenter Kundenservice jederzeit gerne weiter und berät Sie gerne.

Image: Part 3 of the compatibility list, with more brands and their corresponding model numbers.

Ersatzteil passend für folgende Geräte:

7644181042 6299342000 7688884142 7635648345 7698043042

7644481045	6299342100	7688984142	7635748345	7698143042
7644581045	6299342200	7690534145	7680348345	7698243042
7644681045	6299342300	7690834142	7680448345	7698343045
7644781045	6299342400	7690934142	7682148342	7698443045
7644881045	6299342500	7690942042	7682248342	7698543045
7664553971	854563001640	7691034145	7686988342	7698643045
7665531042	854563001641	7691042042	7687288345	privileg
7671241042	854563001642	7691134142	7687388345	6282816000
7672431042	854563001643	7691142042	Helkama	7629281642
7679281042	854563001644	7691234145	7688584342	SanGiorgio
7680281042	854564001640	7691242045	7688684353	7636882045
7680381042	854564001641	7691334142	IGNIS	7636982042
7684641042	854564001642	GRUNDIG	6298318000	7637082042
7685031042	854564001643	7603131645	6298318100	7637182042
7688731042	854564001644	7603231645	6298318200	7657142053
7695831042	854586401000	7606143845	6298318300	7658342053
7696431042	854586401010	7614854171	854585501700	7692742053
7696746942	854586501000	7615938342	854585501710	7692842053
7696831045	GLEM	7616038342	KENWOOD	Siera
7696931045	7667483945	7616331642	7630885042	7632881442
7697681042	7667582053	7616638342	7637345042	Thor
7699031042	7667682053	7618831642	7637445042	7602089000
Elin	7667783942	7619538342	7637545042	7602089042
6238437000	7669983942	7620251645	7637645042	7609389000
6242837100	7683083945	7620554171	7669345042	7609389042
6242837200	Gram	7620654171	7669445042	Whirlpool
6257837000	7622244142	7621451645	7671385042	6299311000
6282837100	7622344142	7625031642	7677435042	6299311100
6291837100	7626844142	7626431642	7677535042	6299311200
Euromaid	7626944145	7626531642	7677635042	7609942645
7650539042	7627044145	7626731642	7677735042	7630042045
7652039042	7627244142	7628120842	7688485042	7648983945
7686339042	7627344142	7633053945	7691885042	7649383945
Fisher&Paykel	7649934142	7633753045	7699845042	7649483945
7684539042	7654834145	7636153845	KUPPERSBERG	7670941645
7688049042	7655284142	7640153845	7604248345	7678183955
7692246942	7655384142	7660052945	7614848342	7678283955
Foster	7655484142	7663543971	7615048345	7678383955
7681032042	7676383842	7663853945	Leisure	7696983945
7681132045	7680684142	7665331642	7609011145	7697083845
Functionica	7680784142	7665431642	7637283842	7697241645
6298342000	7680984142	7685353845	7639683842	7697341655
6298342100	7683644145	7696953945	7681983842	7697441655
6298342200	7683744145	Hansa	Maytag	7697543955
6298342300	7683944153	7635348342	7610883800	851106122030
6298342400	7684044153	7635448345	7610883842	851107401000
6298342500	7688784142	7635548345	Morris	851107710020

FRAGEN? Wenn Sie nicht sicher sind ob dieser Artikel der passende ist, hilft Ihnen unser kompetenter Kundenservice jederzeit gerne weiter und berät Sie gerne.

Image: Part 4 of the compatibility list, providing further compatible models.

Ersatzteil passend für folgende Geräte:

Amica	7663482642	7652610242	7697143945	7603748345
7608441642	7663582642	7653110142	854820001000	7603848345
7608641671	7663882645	7664945042	854820001010	7603948345
7608741645	7664082645	7670610171	854820010000	7604638345
7608841642	7664182645	7673110153	854820101000	7605283945
7608941642	7664282645	7673410242	854820201000	7605320242
7609041642	7664382645	7674343442	854820201002	7605434171
7609141645	7665281645	7677770142	854820401010	7605638345
7627382642	7668132645	7678110142	854823516000	7606120242
7627482642	7668232645	7679870142	854830701000	7606220242
7627582642	7668332645	7679910142	854830701010	7606731042
7627682642	7671281642	7680110242	854830716000	7606783971
7627982642	7674681642	7680310142	854830716010	7606832042
7628082642	7683442642	7681710153	854830801000	7606884242
7628182642	7683542642	7681810142	854831016000	7606984242
7628282642	7683841642	7682210171	854831016001	7607083300
7628382642	7685282642	7682310142	854831016010	7607083342
7637941645	7685382645	7683210153	Beko	7607143900
7638041645	7688381645	7684520142	6257824300	7607183300
7638141642	7690442642	7686070242	6259816000	7607183342
7638241642	7690542642	7688010242	6261842200	7607543942
7638341642	Arcelik	7688110242	6262842200	7607583945
7638442645	6252701000	7688210242	6263826000	7607643942
7638542645	7604210171	7689720142	6281837000	7607843942
7638642642	7611520142	7692885042	6281842100	7607943942
7638742642	7613520100	7692985042	6282837000	7608043942
7640842642	7616710142	7693085042	6283837000	7608081600
7640942642	7618020100	Atlas	6284837000	7608143942
7641042642	7619110142	7614084100	6291876000	7608584200
7641142645	7619210142	7614084142	6294842200	7608584242
7641242642	7623070142	7614584100	6295833000	7608787300
7641342642	7628020842	7614584142	6295842200	7608787342
7641442645	7631010800	7675144153	7600331671	7608887300
7641542645	7633045042	7675484153	7600531671	7608887342
7641842642	7636010253	Bauknecht	7600683945	7609331645
7644981642	7636110253	7629642045	7600748345	7609343942
7653481642	7637235042	7629842045	7600848345	7609443945
7653581642	7637335042	7630242045	7600948345	7609543945
7653681642	7638870142	7631542045	7601048342	7609551655
7656481645	7639020142	7654933945	7601281671	7609783300
7656581642	7641510242	7655883945	7601381671	7609783342
7662882642	7645320142	7655983955	7601658345	7609951645
7662982642	7645620142	7680483945	7602583945	7610051645
7663082642	7645720153	7685883945	7602643942	7610153945
7663182642	7645820142	7691484945	7603358345	7611381642
7663282642	7646020142	7691583955	7603448342	7611481642
7663382642	7650170142	7691683945	7603458345	7611581642

/663286942
7663382642

/650470142
7652310142

/691683945
7693243945

/603458345
7603658345

/611081042
7611843942

FRAGEN? Wenn Sie nicht sicher sind ob dieser Artikel der passende ist, hilft Ihnen unser kompetenter Kundenservice jederzeit gerne weiter und berät Sie gerne.

Image: Part 5 of the compatibility list, completing the extensive list of compatible appliances.

SUPPORT AND WARRANTY

DL-pro is committed to providing high-quality replacement parts. While specific warranty details are not provided in this document, DL-pro products are designed for durability and reliability. If you have questions regarding installation, compatibility, or require assistance with your DL-pro Aquastop Safety Inlet Hose, please contact DL-pro customer service. They are available to help ensure you find the correct part and resolve any issues.

© 2026 DL-pro. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question