

[Manuals.plus](#) /

› [Ikea](#) /

› Ikea Renberget Desk Chair User Manual

Ikea Renberget

Ikea Renberget Desk Chair User Manual

Model: Renberget | Brand: Ikea

1. INTRODUCTION

This user manual provides essential information for the assembly, operation, maintenance, and troubleshooting of your Ikea Renberget Desk Chair. Please read this manual thoroughly before assembling and using the chair to ensure proper function and longevity.



Figure 1: The Ikea Renberget Desk Chair, showcasing its black upholstery and ergonomic design.

2. SETUP AND ASSEMBLY

The Ikea Renberget Desk Chair requires assembly. Please ensure all components are present before beginning. Refer to

the separate assembly instructions included in the product packaging for detailed, step-by-step guidance. Typically, assembly involves attaching the chair back to the seat, securing the armrests, mounting the gas lift cylinder, and attaching the five-star base with wheels.

- Unpack all components and verify against the parts list.
- Assemble the base by inserting the casters into the five-star leg frame.
- Insert the gas lift cylinder into the center of the assembled base.
- Attach the seat mechanism to the underside of the seat cushion.
- Connect the seat and backrest components as per the specific instructions.
- Carefully place the assembled seat onto the gas lift cylinder.

It is recommended to have a second person assist with assembly for stability and ease.



Figure 2: View of the chair's underside mechanism, showing the adjustment levers and gas lift attachment point.

3. OPERATING INSTRUCTIONS

The Renberget Desk Chair is designed for comfort and adjustability. Familiarize yourself with its features for optimal use.

3.1 Height Adjustment

To adjust the seat height, locate the lever on the right side, beneath the seat. While seated, pull the lever upwards to lower the seat. To raise the seat, stand up slightly and pull the lever upwards; the seat will rise automatically. Release the lever at your desired height.

3.2 Swivel Function

The chair features a 360-degree swivel function, allowing for easy rotation without moving the base. This is a standard feature and operates automatically when pressure is applied to the seat.



Figure 3: Detail of the chair's armrest and the height adjustment lever located beneath the seat.

4. MAINTENANCE AND CARE

Regular maintenance will help prolong the life and appearance of your desk chair.

- **Cleaning:** Wipe clean with a damp cloth. For more stubborn stains, use a mild soap solution. Do not use abrasive cleaners or solvents.
- **Inspection:** Periodically check all screws and connections to ensure they are tight. Retighten if necessary.
- **Casters:** Clean the casters regularly to prevent dust and hair from accumulating, which can hinder smooth movement.
- **Avoid Overloading:** Do not exceed the recommended weight capacity of the chair.



Figure 4: Close-up view of the chair's five-star base and durable casters, designed for smooth movement.

5. TROUBLESHOOTING

Here are some common issues and their potential solutions:

- **Chair Squeaks:**

Check all screws and bolts for tightness. Apply a small amount of silicone spray or lubricant to moving parts, especially where metal components meet.

- **Difficulty Adjusting Height:**

Ensure the height adjustment lever is fully engaged. If the gas lift cylinder is not responding, it may need replacement. Contact customer support for assistance.

- **Casters Not Rolling Smoothly:**

Inspect casters for accumulated debris (hair, lint, dust). Clean them thoroughly. If damaged, casters can often be replaced.

- **Chair Feels Unstable:**

Verify that all assembly connections are secure and tight. Ensure the chair is on a flat, even surface.

6. SPECIFICATIONS

Attribute	Detail
Brand	Ikea
Model	Renberget
Color	Black

Special Feature	Swivel
Style	Adjustable
Assembly Type	Require Assembly
Item Weight	3 kg 250 g
Item Dimensions (LxWxH)	50 x 150 x 100 Millimeters
Age Range (Description)	Adult

7. WARRANTY AND SUPPORT

For information regarding warranty coverage, returns, or additional support, please refer to the warranty card included with your purchase or visit the official Ikea support website. You can typically find support resources, FAQs, and contact information for customer service there.
Official Ikea Website: www.ikea.com

© 2024 Ikea. All rights reserved. This manual is for informational purposes only.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

