

- Manuals.plus /
- › Bruni /
 - › Bruni Screen Protector for Krups Intuition Preference EA872 - Instruction Manual

Bruni Bruni Basics-Clear 4061187861149

Bruni Screen Protector for Krups Intuition Preference EA872 - Instruction Manual

Model: Bruni Basics-Clear 4061187861149

- Introduction
- Safety Information
- Setup & Installation Specifications
- Usage Support
- Maintenance
- Troubleshooting

1. INTRODUCTION

This manual provides detailed instructions for the installation, usage, and maintenance of your Bruni Screen Protector, specifically designed for the Krups Intuition Preference EA872 coffee machine display. This protective film is engineered to safeguard your device's screen from scratches, impacts, and daily wear while maintaining optimal touch sensitivity and display clarity.



Figure 1: Bruni Screen Protector product overview, showing the packaging, the clear film, and the compatible Krups Intuition Preference EA872 coffee machine.

Key Features:

- Accurately developed and compatible with Krups Intuition Preference (EA872).
- Made of scratch-resistant, highly transparent PET material.
- Easy, bubble-free application, removable and repositionable.
- Optimal edge adhesion with no slipping once applied.
- Optimized for touch displays, ensuring unadulterated screen content and usability.
- Manufactured in Germany.

2. SAFETY INFORMATION

Please read and understand the following safety precautions before handling or installing the screen protector:

- Keep the product out of reach of children and pets to prevent accidental ingestion or injury.
- Avoid bending or creasing the film excessively before application, as this may cause permanent damage.
- Do not use sharp objects directly on the screen protector, as this may damage the film and potentially the device screen underneath.
- Dispose of packaging materials responsibly and according to local regulations.

3. SETUP & INSTALLATION

Proper installation is key to achieving the best results and ensuring the longevity of your screen protector. Follow these steps carefully:

3.1. Package Contents

Before you begin, ensure all components are present in the package:

- Bruni Screen Protector (2X)
- Mounting tool (squeegee)
- Microfiber cleaning cloth
- Installation instructions (this manual)

Lieferumfang

Displayschutzfolie



Montagewerkzeug



Mikrofaser Tuch



Montageanleitung

Figure 2: Illustration of the package contents, showing the screen protector film, mounting tool, microfiber cloth, and instruction manual.

3.2. Preparation

1. Choose a clean, dust-free environment for installation. Avoid windy areas or places with excessive dust.
2. Wash your hands thoroughly to remove any oils or dirt.
3. Turn off your Krups Intuition Preference EA872 coffee machine and unplug it from the power source.
4. Using the provided microfiber cloth, carefully clean the display surface of your device. Ensure there are no dust particles, smudges, or fingerprints. You may use a screen cleaning solution if necessary, but ensure the screen is completely dry before proceeding.

3.3. Application Steps

The screen protector is designed for super easy assembly in just a few steps:

1. Carefully peel back a small portion of the protective layer (usually marked with a "1" tab) from one end of the screen protector. Avoid touching the adhesive side.

2. Align the exposed adhesive edge of the screen protector with one edge of your device's display. Take your time to ensure precise alignment with the screen's contours and any cutouts.
3. Slowly and steadily lower the rest of the screen protector onto the display, gradually peeling off the remaining protective layer (marked "1") as you go. Use the provided squeegee or a credit card wrapped in the microfiber cloth to gently push out any air bubbles towards the edges as you apply the film.
4. Once the film is fully applied, use the squeegee to firmly press down on the entire surface, ensuring optimal adhesion and removing any remaining small bubbles. Work from the center outwards.
5. Finally, carefully peel off the top protective layer (usually marked with a "2" tab). Your screen protector is now installed.



SUPER EINFACHE MONTAGE

In nur 3 Schritten. Eine Anleitung liegt dem Lieferumfang bei.

Figure 3: A close-up image demonstrating the process of applying the screen protector, showing a hand peeling off the protective film.

Note: Small bubbles may disappear on their own within 24-48 hours as the adhesive fully cures.

4. USAGE

The Bruni Screen Protector is designed to seamlessly integrate with your Krups Intuition Preference EA872, providing protection without compromising functionality.

4.1. Touch Sensitivity

The film is optimized for touch displays, ensuring lightning-fast, highly sensitive, and precise touch response. You should experience no impairment of usability with the protector film applied.



Figure 4: An image depicting a finger interacting with a screen, highlighting the fast and sensitive touch response provided by the screen protector.

4.2. Display Clarity

The crystal clear protective film ensures an unadulterated display of the screen contents, preserving the original colors and brightness of your device's screen without any color attenuation.

Echte Farben

Klare Schutzfolie, keine Farbabschwächung



Figure 5: A visual representation of a screen displaying vivid colors, indicating that the screen protector maintains true color reproduction.

4.3. Protection

The screen protector provides robust protection against scratches and minor impacts, helping to keep your device's display in pristine condition.

Kratzfester Displayschutz



Figure 6: An image showing a key attempting to scratch the screen protector, illustrating its scratch-resistant display protection.

5. MAINTENANCE

To keep your Brun Technology Screen Protector clean and effective, follow these simple maintenance guidelines:

- Use the provided microfiber cloth or a similar soft, lint-free cloth to gently wipe the screen protector.
- For stubborn smudges or fingerprints, slightly dampen the cloth with water or a mild, alcohol-free screen cleaner. Do not spray cleaner directly onto the screen.
- Avoid using abrasive materials, harsh chemicals, or solvents, as these can damage the film's surface.
- Regular cleaning will help maintain the clarity and responsiveness of your screen.

6. TROUBLESHOOTING

If you encounter any issues during or after installation, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Bubbles under the film	Dust particles trapped, or insufficient squeegee pressure during application.	For small bubbles, wait 24-48 hours for them to dissipate naturally. For larger bubbles, gently lift the nearest edge of the film and reapply, using the squeegee to push the air out. If caused by dust, carefully lift the film, use a dust-absorber sticker (not included) to remove the dust, then reapply.
Film not adhering properly at edges	Dust under the edges, or improper initial alignment.	Ensure the screen is thoroughly clean before application. Press firmly along the edges with the squeegee. If severe, you may need to remove and reapply, or use a fresh film.
Reduced touch sensitivity	Improper installation, or a faulty film (rare).	Ensure the film is applied smoothly without large air gaps. Verify that the film is indeed designed for touch screens. If issues persist, contact customer support.

7. SPECIFICATIONS

Attribute	Detail
Product Name	Screen Protector compatible with Krups Intuition Preference EA872 Protector Film
Brand	Bruni
Model Number	Bruni Basics-Clear 4061187861149
Compatible Devices	Krups Intuition Preference EA872
Material	Polyethylenterephthalat (PET)
Item Hardness	4H
Color	Basics-Clear
Product Dimensions	4.53 x 2.99 x 0.5 inches (packaging) / 4.5"L x 3"W (film)
Item Weight	0.317 ounces
Number of Items	2 (films)
Manufacturer	atFoliX GmbH
Country of Origin	Germany

8. SUPPORT & WARRANTY

For further assistance or inquiries regarding your Bruni Screen Protector, please contact the manufacturer or seller

directly.

8.1. Manufacturer Information

Manufacturer: atFoliX GmbH
Country of Origin: Germany

8.2. Warranty Information

Specific warranty details may vary. Please refer to the product packaging or contact the seller, atFoliX Germany, for information regarding warranty coverage and return policies. Amazon's return policy for this product is typically 30 days for refund/replacement.
Seller: [atFoliX Germany](#)

© 2024 Bruni. All rights reserved. Information subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question