

Sluban M38-B0925

Sluban Space-Saturn Expedition Rocket M38-B0925 Instruction Manual

Model: M38-B0925

INTRODUCTION

This instruction manual provides detailed guidance for assembling and maintaining your Sluban Space-Saturn Expedition Rocket building set, model M38-B0925. Please read all instructions carefully before beginning assembly to ensure a correct and enjoyable building experience. This set contains 468 pieces designed for children aged 6 years and up.

SAFETY INFORMATION

- **Choking Hazard:** Small parts. Not for children under 3 years.
- Adult supervision is recommended during assembly, especially for younger children.
- Keep all packaging materials away from children to prevent suffocation.
- Inspect all pieces for damage before assembly. Do not use broken or damaged parts.

PARTS LIST

Your Sluban Space-Saturn Expedition Rocket set includes 468 building pieces and a full-color instruction booklet. Before starting assembly, carefully unpack all components and verify that all pieces are present by comparing them with the parts list provided in the included instruction booklet. If any pieces are missing or damaged, please refer to the "Support" section.




Image: Exploded view of the rocket's main sections and included figures.

SETUP AND ASSEMBLY

Follow the step-by-step instructions provided in the dedicated full-color instruction booklet included in your package. The booklet contains detailed diagrams for each assembly stage.

- Preparation:** Clear a well-lit, flat surface for assembly. Organize your building pieces by color and type to facilitate easier identification.
- Follow Booklet:** Refer to the included full-color instruction booklet for precise, step-by-step assembly diagrams. Each step illustrates which pieces to use and where to place them.
- Modular Construction:** The rocket is designed with modular sections. Assemble each section individually as instructed before connecting them.
- Figures and Accessories:** Assemble the astronaut figures and the satellite accessory as shown in the booklet. These can be placed within or alongside the rocket.
- Verification:** After completing each major section, double-check that all pieces are securely attached and that the structure is stable.



Image: The assembled Sluban Space-Saturn Expedition Rocket with accessories.

OPERATING THE MODEL

The Sluban Space-Saturn Expedition Rocket is a static display model and a toy for imaginative play. It does not contain electronic components or moving parts that require power.

- **Display:** Place the assembled rocket on a stable, flat surface for display.
- **Play:** The rocket and astronaut figures are designed for creative play. Ensure gentle handling to prevent pieces from detaching.
- **Modular Features:** Some sections of the rocket may be designed to detach or open, allowing for interior access or reconfiguration. Refer to the instruction booklet for specific interactive features.

MAINTENANCE

Proper care will help maintain the appearance and integrity of your building set.

- **Cleaning:** To clean the model, gently wipe it with a soft, dry cloth. For stubborn dust, a slightly damp cloth can be used, followed by immediate drying. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** Store the model in a cool, dry place away from direct sunlight to prevent discoloration or material degradation.
- **Handling:** Handle the assembled model with care to avoid accidental disassembly.

TROUBLESHOOTING

- **Missing Pieces:** If you discover any missing pieces during assembly, please contact Sluban customer support (refer to the "Support" section). Provide the model number (M38-B0925) and a description of the missing part.
- **Difficulty Assembling:** Ensure you are following the instruction booklet precisely. Sometimes, pieces may require a firm push to connect properly. If a piece does not fit, double-check that you are using the correct part and orientation.

- **Model Instability:** If the assembled model feels unstable, review the last few assembly steps in the instruction booklet to ensure all connections are secure.

SPECIFICATIONS

Brand	Sluban
Model Name	Space-Saturn Expedition Rocket
Model Number	M38-B0925
Number of Pieces	468
Material	Plastic
Recommended Age	6 years and up
Product Dimensions (L x W x H)	12.68 x 3.94 x 3.94 inches (32.2 x 10 x 10 cm)
Item Weight	1.94 pounds (0.88 Kilograms)

WARRANTY AND SUPPORT

Sluban products are manufactured to high-quality standards. For information regarding warranty, missing parts, or technical support, please refer to the contact information provided in the original product packaging or visit the official Sluban website. Please have your model number (M38-B0925) ready when contacting support.

You can also visit the [Sluban Store on Amazon](#) for more product information.