

VGR V-178

VGR V-178 Hair Trimmer User Manual

Model: V-178 | Brand: VGR

1. INTRODUCTION

This manual provides comprehensive instructions for the safe and effective use of your VGR V-178 rechargeable cordless hair trimmer. Please read all instructions carefully before first use and retain this manual for future reference.

2. SAFETY INSTRUCTIONS

To reduce the risk of electric shock, injury, or fire, always follow these basic safety precautions:

- Do not immerse the trimmer or charging base in water or other liquids.
- Keep the appliance away from water sources when charging.
- Do not use the trimmer if it is damaged, or if the charging cable or plug is damaged.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Only use attachments supplied by the manufacturer.
- Do not open the appliance casing. There are no user-serviceable parts inside.
- Ensure your hands are dry when handling the plug or operating the trimmer.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- VGR V-178 Hair Trimmer
- Charging Base

- USB Charging Cable
- Cleaning Brush
- Lubricating Oil Bottle
- Multiple Guide Combs (e.g., 1mm, 2mm, 3mm)



Image: VGR V-178 Hair Trimmer with its complete set of accessories, including the charging cable, cleaning brush, oil, and various guide combs.

4. PRODUCT FEATURES

- **LED Display:** Shows battery percentage for convenient power monitoring.
- **Long Runtime:** Up to 120 minutes of cordless operation on a full charge.
- **Fast Charge:** Equipped with a 600 mAH Li-ion battery for quick recharging.
- **Stainless Steel Blades:** Durable and precise for efficient trimming.

- **Cordless Operation:** Provides flexibility and ease of use without being tethered to an outlet.
- **Rechargeable:** Convenient charging via the included USB cable and charging base.

VGR[®]
V O Y A G E R



Image: A close-up view of the VGR V-178 trimmer's LED display, indicating the current battery charge level.



Image: A detailed shot of the VGR V-178 trimmer's stainless steel blade, designed for precision cutting.

5. SETUP

5.1 Charging the Trimmer

1. Before first use, fully charge the trimmer for approximately 2 hours.
2. Connect the USB charging cable to the charging base and plug the other end into a compatible USB power adapter (not included) or a USB port.
3. Place the trimmer onto the charging base. The LED display will show the charging progress.
4. Once fully charged, the LED display will indicate 100%. Disconnect the trimmer from the charger.



Image: The rear view of the VGR V-178 trimmer, highlighting the charging port located on its base.

5.2 Attaching Guide Combs

- Ensure the trimmer is turned off before attaching or detaching guide combs.
- Align the desired guide comb with the trimmer blade and push it firmly until it clicks into place.
- To remove, gently pull the comb away from the blade.

6. OPERATING INSTRUCTIONS

6.1 Basic Operation

1. Press the power button to turn the trimmer on. The LED display will illuminate.
2. Select the appropriate guide comb for your desired hair length.
3. Hold the trimmer with the blade flat against the skin and move it slowly against the direction of hair growth.
4. After use, press the power button to turn the trimmer off.

6.2 Trimming Tips

- For best results, use the trimmer on clean, dry hair.
- Start with a longer guide comb and gradually reduce the length if needed.
- Stretch the skin taut in the area you are trimming for a smoother cut.
- Regularly clean the blades during use to prevent hair buildup.

7. MAINTENANCE

7.1 Cleaning the Blades

1. Ensure the trimmer is turned off and unplugged from the charging base.
2. Use the provided cleaning brush to remove loose hairs from the blades.
3. The blades can be rinsed under running water. Ensure the trimmer body does not get wet if it is not waterproof. Dry thoroughly before reassembly or storage.

7.2 Oiling the Blades

- After cleaning and drying, apply 1-2 drops of the lubricating oil (or a suitable light machine oil) to the blades.
- Turn the trimmer on for a few seconds to allow the oil to distribute evenly.
- Wipe off any excess oil with a soft cloth. Regular oiling maintains blade performance and longevity.

7.3 Storage

- Store the trimmer in a cool, dry place, away from direct sunlight and moisture.
- Keep out of reach of children.

8. TROUBLESHOOTING

- **Trimmer not turning on:** Ensure the battery is charged. If not, place it on the charging base.
- **Poor trimming performance:** Clean the blades thoroughly and apply lubricating oil. Ensure the guide comb is correctly attached.
- **Trimmer not charging:** Check if the USB cable and adapter are properly connected. Ensure the trimmer is correctly seated on the charging base.

9. SPECIFICATIONS

Feature	Specification
Model Name	VGR - V178
Power Source	Battery Powered
Battery Type	Li-ion (600 mAH)
Runtime	Up to 120 minutes
Blade Material	Stainless Steel
Recommended Uses	Beard, Hair clipper

Special Feature	Portable, Rechargeable, LED Display
Item Weight	430 g
Manufacturer	Ningbo VGR Electric Appliance Co., Ltd., Yiwu Gemei Electric Appliance Co. Ltd

10. WARRANTY AND SUPPORT

Manufacturer Warranty Description: 1 Year Warranty only if you purchase from seller "VGR INDIA". The warranty is against defects in materials and workmanship for a period of 12 Months from the date of original purchase (Invoice) and does not apply to intentional or unintentional damage by the user. Initiating a warranty claim is pretty simple and straight forward. You can contact us on WARRANTY@VGRINDIA.CO.IN with clear description of the problem, associated pictures and copy of original invoice. Once the claim has been verified, the company will, at its own discretion either repair or if a repair is not possible then exchange the product. In either of the cases, the customers will need to bear the cost of transporting the product to us and we will bear the cost of transporting back, if there is a need.

Importer Contact Information: VGR INDIA MUMBAI - 401104 INDIA

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question