

Cellet Worldwide Universal Power Adapter

Cellet Worldwide Universal Power Adapter Instruction Manual

Model: Worldwide Universal Power Adapter

Brand: Cellet

1. INTRODUCTION

This manual provides essential instructions for the safe and effective use of your Cellet Worldwide Universal Power Adapter. This adapter is designed to facilitate power connections for your electronic devices, such as the Fuji FinePix F20, in various international regions. Please read this manual thoroughly before use to ensure proper operation and safety.



The image displays the Cellet Worldwide Universal Power Adapter from two angles. One view shows the adapter with US-style flat prongs extended, while the other shows it with European-style round prongs extended. The adapter is white with green accents on the release buttons and features a universal outlet on the front, along with 'TRAVEL UNIVERSAL ADAPTOR' and 'SURGE PROTECTOR' labels.

2. IMPORTANT SAFETY INFORMATION

- This device is a travel adapter, not a voltage converter. It does not convert voltage from 110V to 220V or vice versa. Ensure your electronic device (e.g., charger for Fuji FinePix F20) is compatible with the local voltage supply (100V-240V) before plugging it into this adapter. Failure to do so may damage your device.
- Do not use this adapter with high-power appliances that exceed its maximum rated power.
- Keep out of reach of children.
- Do not expose to liquids or extreme temperatures.
- Always ensure the adapter is securely plugged into the wall outlet and your device is securely plugged into the adapter.
- Use the safety lock mechanism to secure the prongs in position.

SAFETY SWITCH LOCK/UNLOCK



A close-up view of the Cellet Worldwide Universal Power Adapter highlights the green safety switch. The switch is labeled 'UNLOCK' and 'LOCK' with an arrow indicating its sliding motion. This mechanism secures the adapter's prongs in their extended or retracted positions, preventing accidental retraction during use.

3. SETUP AND OPERATION

3.1 Extending the Prongs

1. Identify the required plug type for your destination (US, EU, UK, AUS/NZ).
2. Locate the corresponding slider or button on the adapter.
3. Slide or press the button to extend the correct prongs. For example, slide the 'US' button for US-style prongs.
4. Ensure the prongs are fully extended and locked into place using the safety switch (if applicable).

3.2 Connecting Your Device

1. Plug your device's power cord or charger into the universal outlet on the front of the adapter.
2. Ensure your device's charger supports the local voltage.
3. Insert the adapter into the wall outlet.



This image displays four separate panels illustrating the different plug configurations available on the universal power adapter. Each panel shows the adapter with a specific set of prongs extended: US (two flat parallel prongs), Europe (two round prongs), AUS/NZ (two angled flat prongs), and UK (three rectangular prongs). The image demonstrates the mechanism for extending each plug type.

Use with any Original USB Charger



The image shows the Cellet Worldwide Universal Power Adapter plugged into a standard US wall outlet. A smartphone is connected to the adapter, and the phone is visible on a desk, indicating it is being charged. This illustrates a typical use case for the adapter.

4. COMPATIBILITY

This universal power adapter is designed to work with a wide range of electronic devices that require an AC power source, including digital cameras like the Fuji FinePix F20, smartphones, tablets, laptops, and other small electronics.

It supports outlets in over 150 countries, covering major regions such as the USA, UK, EU, China, Australia, and New Zealand.

Important Note:

This adapter does not convert voltage. Your device's power supply must be rated for the local voltage (e.g., 100-240V) for safe operation. Always check your device's power specifications before use.

COMPATIBILITY

*Requires your original Charger

**No USB Port



Nintendo



Carmera



MP3



Phone



Tablet




Laptop



PC

This image illustrates the broad compatibility of the Cellet Worldwide Universal Power Adapter. The adapter is centrally placed, surrounded by icons and images of various electronic devices it can power, including a Nintendo Switch, a camera (like the Fuji FinePix F20), an MP3 player, a smartphone, a tablet, a laptop, and a desktop PC. Text indicates that it requires your original charger and has no USB port.

WORLDWIDE ALL IN ONE UNIVERSAL POWER ADAPTER



A world map visually represents the global compatibility of the universal power adapter. Different regions are color-coded to indicate support for US (orange), Europe (green), UK (red), and AUS/NZ (grey) plug types. This map helps users identify where the adapter can be used.

5. MAINTENANCE

- Clean the adapter with a dry, soft cloth. Do not use liquid cleaners.
- Store in a cool, dry place when not in use.
- Do not attempt to disassemble or repair the adapter. Contact customer support if issues arise.
- Regularly inspect the adapter for any signs of damage, such as frayed wires or cracked casing. Discontinue use if damage is found.

6. TROUBLESHOOTING

6.1 Device Not Charging

- Ensure the adapter is fully plugged into the wall outlet.
- Verify that your device's charger is securely plugged into the adapter.
- Check if the local voltage is compatible with your device's charger. This adapter does not convert voltage.

- Confirm that the safety lock on the adapter is engaged, holding the prongs firmly in place.

6.2 Adapter Feels Loose in Outlet

- Ensure the correct prongs for the region are fully extended and locked.
- Some older or worn outlets may not provide a snug fit. Exercise caution.

6.3 Adapter Overheating

- Immediately unplug the adapter and the connected device.
- Ensure the connected device's power requirements do not exceed the adapter's maximum rating.
- Allow the adapter to cool down before attempting to use it again. If overheating persists, discontinue use.

7. PRODUCT SPECIFICATIONS

- **Model:** Worldwide Universal Power Adapter
- **Brand:** Cellet
- **Input Voltage:** 100V-240V AC (Pass-through, no conversion)
- **Output:** Universal AC Socket
- **Plug Types:** US, EU, UK, AUS/NZ
- **Color:** White
- **Item Weight:** 4 ounces (approximately 113 grams)
- **UPC:** 694611002715
- **ASIN:** B095NGXLFL
- **Certifications:** UL, CE

WorldWide All-in-One Power Adapter



This image features the Cellet Worldwide Universal Power Adapter alongside its retail packaging. The packaging prominently displays icons for US, UK, AUS/NZ, and Europe plug types, reinforcing the adapter's global compatibility. The adapter itself is shown with its universal outlet and various plug configurations.

8. WARRANTY AND SUPPORT

For warranty information or technical support, please contact your retailer or the manufacturer, Cellet. Refer to the product packaging or the retailer's website for specific contact details.