

[Manuals.plus](#) /

› [TISSCARE](#) /

› TISSCARE Shiatsu Foot Massager Machine with Remote and Heat Instruction Manual

TISSCARE B095NXNS4H

TISSCARE Shiatsu Foot Massager Machine with Remote and Heat

Instruction Manual

IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using the TISSCARE Shiatsu Foot Massager Machine. Retain this manual for future reference.

- **Electrical Safety:** Always unplug the massager from the electrical outlet immediately after use and before cleaning. Do not use while bathing or in a shower. Do not place or store the appliance where it can fall or be pulled into a tub or sink.
- **Medical Conditions:** Consult your physician before using this massager if you have a pacemaker, are pregnant, suffer from diabetes, phlebitis, thrombosis, or are at an increased risk of developing blood clots.
- **Supervision:** Close supervision is necessary when this appliance is used by, on, or near children, invalids, or disabled persons.
- **Heat Function:** The heat function is designed to provide soothing warmth. Individuals sensitive to heat should use with caution. Do not use the heat function on areas with poor circulation or insensitivity to temperature.
- **Avoid Overuse:** Do not use the massager for more than 30 minutes at a time. Excessive use may lead to overheating and shorten the product's lifespan.
- **Proper Use:** Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.

PRODUCT OVERVIEW

The TISSCARE Shiatsu Foot Massager Machine is designed to provide deep kneading massage and soothing heat therapy for your feet and calves. It aims to relieve tension, promote blood circulation, and alleviate discomfort associated with various foot conditions.

Key Features:

- **Heat Therapy:** Built-in heating element for soothing warmth.
- **Deep Kneading Massage:** Targets tension and pain in feet and legs.
- **Promotes Circulation:** Helps improve blood flow.
- **Pain Relief:** May alleviate discomfort from plantar fasciitis and neuropathy.
- **Portable Design:** Lightweight and easy to move.



Figure 1: Front view of the TISSCARE Shiatsu Foot Massager Machine.

PACKAGE CONTENTS

Verify that all items are present in the package:

- TISSCARE Shiatsu Foot Massager Machine
- Remote Control
- Power Adapter
- Instruction Manual (this document)

SETUP

1. **Placement:** Place the foot massager on a flat, stable surface. Ensure there is enough space around the unit for proper ventilation.
2. **Power Connection:** Insert the power adapter into the DC input port located on the back or side of the massager. Plug the other end of the power adapter into a standard electrical outlet (AC 100-240V, 50/60Hz).
3. **Initial Check:** Before first use, inspect the power cord and the unit for any visible damage. Do not use if damaged.

OPERATING INSTRUCTIONS

The TISSCARE Shiatsu Foot Massager can be operated using the control panel on the unit or the included remote control.

Control Panel:



Figure 2: Control panel on the foot massager unit.

1. **Power On/Off:** Press the **Power Button** to turn the unit on. Press again to turn off.
2. **Mode Selection:** Use the **Mode Button** to cycle through different massage programs (e.g., Shiatsu,

Kneading, Air Compression).

3. **Intensity Adjustment:** Press the **Intensity Buttons** (+/-) to increase or decrease the massage strength.
4. **Heat Function:** Press the **Heat Button** to activate or deactivate the soothing heat function. An indicator light will typically show when heat is active.
5. **Timer:** Some models include a timer function. Use the **Timer Button** to set the desired massage duration.

Remote Control:



Figure 3: Remote control for the foot massager.

The remote control duplicates the functions of the control panel, allowing for convenient operation. Ensure the remote has working batteries (if applicable) and is pointed towards the massager's receiver.

Using the Massager:



Figure 4: Feet positioned inside the massager for use.

Sit comfortably and place your feet into the designated footrests of the massager. Select your desired massage mode, intensity, and heat setting. Relax and enjoy the massage. The massager will typically shut off automatically after the set timer duration.

MAINTENANCE AND CARE

Cleaning:

- Always unplug the unit before cleaning.
- Wipe the exterior of the massager with a soft, damp cloth. Do not use abrasive cleaners, solvents, or harsh detergents.
- Do not immerse the massager in water or any other liquid.
- If the fabric lining is removable, follow specific washing instructions provided with the product. Otherwise, spot clean as needed.

Storage:

- Store the massager in a cool, dry place when not in use.

- Avoid placing heavy objects on top of the massager.
- Keep the power cord neatly coiled and avoid wrapping it tightly around the unit.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Massager does not turn on.	Power cord not properly connected. No power from outlet.	Ensure power cord is securely plugged into both the unit and the wall outlet. Test the outlet with another device.
No heat or weak heat.	Heat function not activated. Heat takes time to warm up.	Press the Heat button to activate. Allow 5-10 minutes for the heat to reach its optimal temperature.
Massage feels too weak or too strong.	Intensity setting is incorrect.	Adjust the intensity using the +/- buttons on the control panel or remote.
Remote control not working.	Batteries are dead or incorrectly inserted. Obstruction between remote and unit.	Replace batteries or ensure correct polarity. Remove any objects blocking the signal path.

SPECIFICATIONS

- **Model:** B095NXNS4H
- **Brand:** TISSCARE
- **Power Source:** Corded Electric
- **Item Weight:** 1.49 Kilograms (3.28 Pounds)
- **Package Dimensions:** 11.54 x 10 x 4.33 inches
- **Special Feature:** Heat
- **Color:** Black
- **Manufacturer:** TISSCARE

WARRANTY AND SUPPORT

TISSCARE products are manufactured to high-quality standards. For information regarding warranty coverage, product support, or service inquiries, please refer to the warranty card included with your purchase or contact TISSCARE customer service directly. Contact details can typically be found on the official TISSCARE website or on the product packaging.