

[Manuals.plus](#) /

› [DORTALA](#) /

› DORTALA 2 Piece Wicker Sectional Armless Chairs User Manual

DORTALA B095PCMH8C

DORTALA 2 Piece Wicker Sectional Armless Chairs User Manual

Model: B095PCMH8C

1. INTRODUCTION

Thank you for choosing the DORTALA 2 Piece Wicker Sectional Armless Chairs. This manual provides essential information for the safe assembly, operation, and maintenance of your new outdoor furniture. Please read it thoroughly before use and retain it for future reference.

This set includes two versatile armless chairs designed to enhance your outdoor living space, offering comfort and flexibility for various arrangements.



Image: The DORTALA 2 Piece Wicker Sectional Armless Chairs, featuring red cushions, placed on a patio surrounded by lush greenery.

2. SAFETY INFORMATION

Please observe the following safety precautions to ensure safe use and longevity of your product:

- **Direct Sunlight Exposure:** Avoid prolonged exposure to direct sunlight to prevent the steel frame from overheating, which could cause burns upon contact.
- **Children and Pets:** Supervise children and pets around the furniture to prevent suffocation risks from loose cushions or small parts.
- **Weight Capacity:** Do not exceed the maximum weight capacity of 710 lbs (322.05 kg) for the sofa set. Each single armless chair has a maximum weight capacity of 396 lbs.
- **Stable Surface:** Always place the furniture on a flat, stable surface to prevent tipping.
- **Sharp Objects:** Keep sharp objects away from the rattan and cushions to avoid damage.

3. PACKAGE CONTENTS

Before assembly, please verify that all components listed below are present in your package:

- 2 x Armless Chairs
- 2 x Seat Cushions
- 2 x Back Cushions
- 1 x Instruction Manual (this document)
- Necessary Hardware (bolts, washers, wrench)

If any parts are missing or damaged, please contact DORTALA customer service immediately.

4. SETUP AND ASSEMBLY

Assembly of the DORTALA Wicker Sectional Armless Chairs is required. Follow the instructions carefully for a straightforward setup process.

4.1 Assembly Steps

1. Unpack all components and place them on a clean, soft surface to prevent scratches.
2. Identify the main frame components for each armless chair.
3. Attach the frame sections using the provided hardware. Ensure all bolts are finger-tightened initially.
4. Once all sections are aligned, fully tighten all bolts with the included wrench. Do not overtighten.
5. Place the seat cushions and back cushions onto the assembled chairs.

The armless design allows for flexible arrangement. You can use the chairs individually or combine them with other compatible DORTALA furniture to create a larger seating arrangement.


**1****Tightly Hand-Woven Rattan****2****Aluminum Sturdy Feet**

Image: An illustration demonstrating the modularity of the armless chairs, showing how two chairs can be combined with a coffee table and other chairs to form a complete patio sofa set.

5. OPERATING INSTRUCTIONS

The DORTALA 2 Piece Wicker Sectional Armless Chairs are designed for comfortable outdoor seating. Their modular nature allows for various configurations to suit your space and needs.

5.1 Usage

- **Comfort:** The chairs feature thick and soft seat and back cushions for optimal comfort. The ergonomic design conforms to your body curve.
- **Versatility:** Use the two armless chairs together as a small sofa, or separate them to provide individual seating. They can also be integrated into a larger sectional sofa arrangement.
- **Application:** These chairs are suitable for various outdoor settings including patios, decks, terraces, backyards, porches, gardens, lawns, balconies, apartments, and poolside areas. They can also be used indoors.



Image: Visual representation of the chairs' wide application, showing them suitable for patio, poolside, garden, and indoor environments.

6. MAINTENANCE

Proper care and maintenance will extend the life and appearance of your DORTALA Wicker Sectional Armless Chairs.

6.1 Cleaning

- **PE Rattan:** The weather-resistant PE rattan requires low maintenance. To clean, simply wipe off dirt and debris with a damp cloth. For stubborn stains, a mild soap solution can be used, followed by rinsing with clean water and air drying.
- **Cushions:** The seat and back cushions feature a detachable design with zippers, allowing for easy removal of covers for cleaning. Machine wash cushion covers on a gentle cycle with cold water and mild detergent, or hand wash. Air dry only; do not tumble dry or bleach.
- **Frame:** Wipe the alloy steel frame with a damp cloth. Avoid abrasive cleaners that could damage the finish.

Thickened Seat & Back Cushion



Image: Detailed view of the cushion features, highlighting the zippered cover for easy rinsing and the high-resilience foam filling.

6.2 Storage

During harsh weather conditions or prolonged periods of non-use, it is recommended to store the cushions indoors or cover the entire set with a protective outdoor furniture cover to prevent damage and prolong its lifespan.

7. TROUBLESHOOTING

If you encounter any issues with your DORTALA Wicker Sectional Armless Chairs, please refer to the following common troubleshooting tips:

- **Wobbling Chairs:** Ensure all assembly bolts are securely tightened. Check that the chairs are placed on a level surface.
- **Cushion Discomfort:** Verify that cushions are correctly positioned and not compressed unevenly. Fluff cushions regularly to maintain their shape and resilience.
- **Rattan Damage:** For minor fraying, carefully trim loose strands. For significant damage, contact customer support for advice.

If the problem persists, please contact DORTALA customer support for further assistance.

8. SPECIFICATIONS

Detailed specifications for the DORTALA 2 Piece Wicker Sectional Armless Chairs:

Feature	Specification
Brand	DORTALA
Model Number	B095PCMH8C
Color	Red
Product Dimensions (L x W x H)	29.5"D x 25.5"W x 25.5"H (per chair)
Seat Height	14.5 Inches
Item Weight	42 Pounds (total for 2 chairs)
Weight Limit	710 lbs (322.05 kg) for the set; 396 lbs per single chair
Material Type	Alloy Steel (frame), Polyethylene Rattan, Polyester (upholstery), Foam (fill)
Indoor/Outdoor Usage	Outdoor
Assembly Required	Yes
Product Care Instructions	Damp cloth for rattan and frame; removable cushion covers for washing
UPC	685764555852



Image: Dimensional drawing of the armless chair, indicating its height, depth, and width, as well as the combined width of two chairs.

9. WARRANTY AND SUPPORT

DORTALA is committed to providing quality products. While specific warranty details are not included in this manual, please retain your proof of purchase for any warranty claims.

For product support, missing parts, or any inquiries, please contact DORTALA customer service through the retailer where you purchased the product or visit the official DORTALA website for contact information.

You can also visit the [DORTALA Store on Amazon](#) for more information and support resources.

© 2024 DORTALA. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question