

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Metz](#) /

› [Metz MTC6000 Series 42-inch Full HD Smart TV User Manual](#)

Metz MTC6000

Metz MTC6000 Series 42-inch Full HD Smart TV User Manual

Model: MTC6000 | Version: 2022

1. SAFETY INFORMATION

Please read all safety instructions carefully before using your Metz MTC6000 Series Smart TV. Keep this manual for future reference.

- Do not expose the TV to rain or moisture.
- Ensure proper ventilation around the TV.
- Only use attachments/accessories specified by the manufacturer.
- Unplug the TV during lightning storms or when unused for long periods.

2. PACKAGE CONTENTS

Verify that all items are present in the packaging:

- Metz MTC6000 Series 42-inch Full HD Smart TV
- Remote Control
- Power Cable
- User Manual (this document)
- TV Stand Components (if applicable)

3. SETUP

3.1 Unpacking

Carefully remove the TV from its packaging. It is recommended to retain the original packaging for potential future transport or service needs.

3.2 Stand Installation

If you intend to place the TV on a surface, attach the provided stand according to the instructions below. Ensure the TV is placed on a stable, level surface.



Image: Front view of the Metz MTC6000 Series Smart TV on its stand.

3.3 Wall Mounting

For wall mounting, use a VESA-compatible wall mount (not included). Refer to the back panel image for VESA mounting points. Always consult a professional for wall mounting to ensure safety and proper installation.



Image: Rear view of the TV, highlighting the VESA mounting holes and various input/output ports.

3.4 Connecting Devices

Connect your external devices to the TV using the appropriate ports:

- **HDMI:** For Blu-ray players, game consoles, set-top boxes.
- **USB:** For external storage devices (USB drives) to play media.
- **Antenna (DVB-T2):** Connect a terrestrial antenna for digital TV channels.
- **Satellite (DVB-S2):** Connect a satellite dish for satellite TV channels.
- **Power Cable:** Connect the power cable to the TV and then to a wall outlet.

3.5 Initial Setup

After connecting the power cable, turn on the TV. The initial setup wizard will guide you through:

1. Language selection.
2. Network connection (Wi-Fi or Ethernet).
3. Google Account sign-in (optional, but recommended for full Android TV features).
4. Channel scanning for DVB-T2/S2.

4. OPERATING THE TV

4.1 Remote Control Functions

Use the provided remote control to navigate the TV interface. Common buttons include Power, Volume Up/Down, Channel Up/Down, Navigation (arrows, OK), Home, Back, and App-specific buttons.

4.2 Android TV Interface

The Metz MTC6000 Series runs on Android 9.0, providing access to a wide range of applications and features.

- **Google Play Store:** Download and install your favorite apps, games, and streaming services.
- **Pre-installed Apps:** Access popular services like Netflix and YouTube directly from the home screen.
- **Google Assistant:** Use voice commands to control your TV, search for content, and get information. Press the Google Assistant button on your remote and speak into the microphone.
- **Chromecast Built-in:** Cast photos, videos, and music from your smartphone, tablet, or computer directly to your TV screen.

4.3 Channel Tuning

To access digital terrestrial (DVB-T2) or satellite (DVB-S2) channels, ensure your antenna or satellite dish is properly connected. Navigate to the TV settings menu and select 'Channel Scan' to automatically find available channels.

4.4 Media Playback via USB

Insert a USB storage device into the TV's USB port. The TV will typically detect the device and prompt you to open a media player application to browse and play compatible video, audio, or image files.

Your browser does not support the video tag.

Video: This video demonstrates key features of the Metz MTC6000 Series Smart TV, including its Android TV interface, access to streaming services like Netflix and YouTube, Google Assistant voice control, Chromecast built-in functionality, and internal storage capacity.

5. MAINTENANCE

5.1 Cleaning the TV

To clean the screen, gently wipe it with a soft, lint-free cloth. For stubborn marks, slightly dampen the cloth with water or a screen-cleaning solution. Avoid harsh chemicals. Clean the casing with a soft, dry cloth.

5.2 Software Updates

Your TV may receive software updates to improve performance and add new features. You can usually check for updates in the TV's settings menu under 'About' or 'System Updates'. Ensure your TV is connected to the internet for updates.

6. TROUBLESHOOTING

If you encounter issues with your TV, refer to the following common solutions:

- **No Power:** Check if the power cable is securely connected to both the TV and the wall outlet. Try a different outlet.
- **No Picture/Sound:** Ensure the correct input source is selected. Check all cable connections (HDMI, antenna). Verify volume settings.
- **Remote Control Not Working:** Replace the batteries. Ensure there are no obstructions between the remote and the TV's IR sensor.
- **Network Connection Issues:** Restart your Wi-Fi router. Check the TV's network settings to ensure it's connected to the correct network.
- **Apps Not Loading:** Ensure a stable internet connection. Try restarting the TV. Clear the app's cache in the TV settings.

For persistent issues, consult the Metz support website or contact customer service.

7. SPECIFICATIONS

Detailed technical specifications for the Metz MTC6000 Series 42-inch Full HD Smart TV:

Feature	Specification
Screen Size	42 Pollici (106 cm)
Brand	Metz
Screen Technology	LED
Resolution	1080p (Full HD)
Refresh Rate	60 Hz
Special Feature	Flat Screen
Included Components	Remote control, power cable, user manual
Connectivity Technology	Bluetooth (BT), Wi-Fi
Aspect Ratio	16:9
Product Dimensions (DxWxH)	8.6P x 95.3I x 54.6H cm
Operating System	Android 9.0

Feature	Specification
Digital Tuner	DVB-C/T2/S2, HEVC MAIN10
Audio	Dolby Digital

For more details on energy consumption, please refer to the energy label:



ENERG



METZ 42MTC6000Z



41 kWh/1000h




Image: Energy efficiency label for the Metz MTC6000 Series 42-inch TV, showing energy class F and consumption of 41 kWh/1000h. A QR code is visible for further information.

Additional energy information can be found at: <https://eprel.ec.europa.eu/qr/40624100>

8. WARRANTY AND SUPPORT

Metz products come with a standard manufacturer's warranty. Please refer to the warranty card included with your product or visit the official Metz website for detailed warranty terms and conditions.

For technical support, service requests, or further assistance, please visit the Metz support page or contact their customer service department. Contact information can typically be found on the Metz official website or in the product packaging.