



Manuals.plus /

› Lizipai /

› Lizipai Mini 3-Digit Combination Lock (Model LK-200-2) User Manual

## Lizipai LK-200-2

# Lizipai Mini 3-Digit Combination Lock (Model LK-200-2) User Manual

## 1. INTRODUCTION

---

This manual provides essential instructions for the proper setup, operation, and maintenance of your Lizipai Mini 3-Digit Combination Lock, Model LK-200-2. Please read this guide thoroughly before using the product to ensure optimal performance and security.

## 2. SAFETY INFORMATION

---

- Ensure the lock is securely installed before relying on it for security.
- Do not force the lock mechanism if it resists. This may cause damage.
- Keep the combination confidential and store it in a safe, memorable location.
- This lock is designed for general security and is not intended for high-security applications where extreme force or specialized tools might be used.

## 3. PACKAGE CONTENTS

---

Verify that all components are present in your package:

- Lizipai Mini 3-Digit Combination Lock (Quantity: 2)
- Mounting Brackets (Quantity: 2 sets)
- Retaining Clips (Quantity: 2)



Image 3.1: Contents of the Lizipai Mini 3-Digit Combination Lock package, showing two locks, mounting brackets, and retaining clips.

#### 4. PRODUCT OVERVIEW

The Lizipai Mini 3-Digit Combination Lock is a compact and portable security solution. It features a three-digit resettable combination mechanism and is constructed from durable metal and ABS plastic. Its design allows for versatile application in various settings, such as small cabinets, drawers, or cash boxes.



Image 4.1: The compact size of the Lizipai Mini 3-Digit Combination Lock, shown held in a hand for scale.



Image 4.2: Front view of the lock, highlighting the three-digit dials and the reset knob, along with the included mounting components.



Image 4.3: Rear view of the lock, illustrating the internal locking mechanism and the attachment points for installation.

## 5. SETUP: SETTING YOUR COMBINATION

The factory default combination for your Lizipai Mini 3-Digit Combination Lock is **0-0-0**. Follow these steps to set your personal combination:

1. Ensure the lock is currently set to the default combination (0-0-0) or your previously set combination, and is in the unlocked position.
2. Locate the reset knob on the side or back of the lock.
3. Using a small pointed object (like a pen tip), press and hold the reset knob.
4. While holding the reset knob, rotate the three-digit dials to your desired new combination.
5. Release the reset knob. Your new combination is now set.
6. Scramble the dials to lock the mechanism and test your new combination to ensure it opens correctly.

Video 5.1: Demonstration of the Lizipai Mini 3-Digit Combination Lock, including its components and likely showing the combination setting process. This video is provided by the seller, shui+.

## 6. OPERATING INSTRUCTIONS

## 6.1. Locking the Device

1. Ensure the item you wish to secure is properly positioned for the lock.
2. Set the dials to your correct combination to allow the locking mechanism to retract.
3. Engage the lock into the desired position (e.g., close the cabinet door and align the lock).
4. Scramble the three-digit dials to a random sequence. The lock is now secured.

## 6.2. Unlocking the Device

1. Rotate the three-digit dials to your personal combination.
2. Once the correct combination is aligned, the lock mechanism will release, allowing you to open the secured item.



Image 6.1: The Lizipai Mini 3-Digit Combination Lock shown installed on a cash box, demonstrating a typical application.

## 7. MAINTENANCE

- **Cleaning:** Wipe the lock surface with a soft, dry cloth. Avoid abrasive cleaners or solvents.
- **Lubrication:** If the dials become stiff, a small amount of graphite lubricant can be applied to the moving parts. Do not use oil-based lubricants as they can attract dust.
- **Storage:** Store the lock in a dry environment when not in use to prevent corrosion.

## 8. TROUBLESHOOTING

- **Lock will not open:**
  - Ensure the correct combination is entered. Double-check each digit.
  - Verify that the dials are perfectly aligned with the indicator marks.

- If the dials are stiff, try gently wiggling them while entering the combination.
- **Cannot set new combination:**
  - Make sure the lock is set to the current correct combination before attempting to reset.
  - Ensure the reset knob is fully pressed in and held while changing the numbers.
- **Lock feels loose or damaged:**
  - Inspect for visible damage. If severely damaged, replace the lock.
  - Ensure all mounting components are securely fastened.

## 9. SPECIFICATIONS

Feature	Detail
Brand	Lizipai
Model Number	LK-200-2
Lock Type	3-Digit Combination Lock
Material	Acrylonitrile Butadiene Styrene, Metal, Plastic
Color	Black
Item Dimensions (L x W x H)	2.5 x 2 x 1.99 inches (63.5 x 50.8 x 50.5 mm)
Item Weight	2.39 ounces (0.07 Kilograms)
Special Features	Portable, Compact

## 10. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact your retailer. Keep your purchase receipt as proof of purchase.