

[Manuals.plus](#) /

› [PARTPHONER](#) /

› PARTPHONER 3-Light Brushed Nickel Bathroom Vanity Light Fixture User Manual (Model: 73197f9f-890f-4490-bd19-c2a7a720cfd4)

PARTPHONER 73197f9f-890f-4490-bd19-c2a7a720cfd4

PARTPHONER Bathroom Vanity Light Fixture User Manual

Model: 73197f9f-890f-4490-bd19-c2a7a720cfd4

INTRODUCTION

This manual provides detailed instructions for the safe installation, operation, and maintenance of your PARTPHONER 3-Light Brushed Nickel Bathroom Vanity Light Fixture. This modern fixture features three glass shades and is designed to provide ample illumination for your bathroom vanity area. Please read these instructions thoroughly before beginning installation and retain them for future reference.

SAFETY INFORMATION

- **Electrical Safety:** Always turn off the main power supply at the circuit breaker or fuse box before installing, cleaning, or servicing the fixture. Failure to do so may result in electric shock, injury, or death.
- **Qualified Electrician:** If you are unsure about the installation process, consult a qualified electrician.
- **Grounding:** Ensure the fixture is properly grounded to avoid potential electrical hazards.
- **Bulb Requirements:** Use only E26 base bulbs with a maximum wattage of 60W per bulb. Do not exceed the recommended wattage. Bulbs are not included.
- **Handling:** Handle glass shades with care to prevent breakage.
- **Indoor Use Only:** This fixture is designed for indoor use in dry locations. It is not water-resistant.

PACKAGE CONTENTS

Verify that all components are present before beginning installation.

- Light Fixture Assembly (Brushed Nickel, 3-Light)
- Glass Shades (3 pieces)
- Mounting Hardware (Crossbar, mounting screws, wire nuts)
- Instruction Manual



Image: The complete PARTPHONER 3-Light Brushed Nickel Bathroom Vanity Light Fixture with three frosted glass shades.



Image: Detailed views of the white frosted glass shade and the brushed nickel finish of the fixture.

SPECIFICATIONS

Brand	PARTPHONER
Model Number	73197f9f-890f-4490-bd19-c2a7a720cfd4
Color/Finish	Brushed Nickel
Material	Metal, Glass
Product Dimensions	23.6" L x 7.28" W x 8.85" H (60cm L x 18.5cm W x 22.5cm H)
Number of Lights	3
Bulb Base	E26
Max Wattage per Bulb	60W
Voltage	110 Volts
Installation Type	Hardware-mounted
Indoor/Outdoor Usage	Indoor

Water Resistance Level

Not Water Resistant




Image: Detailed dimensions of the light fixture, showing length, width, and height measurements.

SETUP AND INSTALLATION

Tools Required (Not Included): Screwdriver, wire strippers, electrical tape, safety glasses, ladder.

1. **Turn Off Power:** Before starting, ensure the power to the junction box is turned off at the circuit breaker.
2. **Prepare Mounting Plate:** Attach the mounting crossbar to the junction box using the provided screws. Ensure it is securely fastened.
3. **Wire Connections:**
 - Connect the fixture's black wire (live) to the black wire from the junction box using a wire nut.
 - Connect the fixture's white wire (neutral) to the white wire from the junction box using a wire nut.
 - Connect the fixture's ground wire (bare copper or green) to the ground wire from the junction box (bare copper or green) and to the mounting crossbar's ground screw.
 - Ensure all wire connections are secure and covered with wire nuts and electrical tape if necessary.
4. **Mount Fixture:** Carefully align the fixture with the mounting crossbar and secure it with the provided mounting screws.
5. **Install Glass Shades:** Gently attach each glass shade to the fixture.
6. **Install Bulbs:** Screw in three E26 base bulbs (max 60W each) into the sockets. Do not overtighten.

7. **Restore Power:** Turn the power back on at the circuit breaker.




Image: Visual representation of the fixture's features, including the white frosted glass, brushed nickel finish, and the flexibility to mount it facing upwards or downwards.

The fixture can be mounted with the lights facing up or down, depending on your preference and lighting needs.

OPERATING INSTRUCTIONS

Once installed and powered, the PARTPHONER Bathroom Vanity Light Fixture operates via a standard wall switch connected to the circuit. Simply toggle the wall switch to turn the light on or off.



Image: A bathroom scene illustrating the light fixture in both the "Switch off" (dark) and "Switch on" (illuminated) states, demonstrating its functionality.

MAINTENANCE

- **Cleaning:** Ensure the power is off before cleaning. Wipe the fixture with a soft, dry cloth. Do not use abrasive cleaners or solvents, as they may damage the finish.
- **Glass Shades:** The glass shades can be carefully removed and washed with mild soap and water, then thoroughly dried before reattaching.
- **Bulb Replacement:** Turn off power before replacing bulbs. Allow old bulbs to cool before removal. Replace with E26 base bulbs, maximum 60W.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Light does not turn on.	◦ Power is off at the circuit breaker. ◦ Loose wire connections. ◦ Defective bulb. ◦ Faulty wall switch.	◦ Check the circuit breaker and ensure power is on. ◦ Turn off power, then check and secure all wire connections. ◦ Replace the bulb with a new, working one. ◦ Consult a qualified electrician to inspect the switch.
Light flickers.	◦ Loose bulb. ◦ Incorrect bulb type/wattage. ◦ Loose wire connection.	◦ Tighten the bulb. ◦ Ensure bulbs meet specifications (E26, max 60W). ◦ Turn off power, then check and secure wire connections.

WARRANTY AND SUPPORT

PARTPHONER is committed to providing high-quality products. For any questions, concerns, or support regarding your light fixture, please contact PARTPHONER customer service. Please refer to your purchase documentation for specific warranty details and contact information. You can visit the official PARTPHONER store for more information:[PARTPHONER Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B095SFPL82>

More documents and user manuals: <https://manuals.plus/>