



Manuals.plus /

› Ninco /

› Ninco Bulldog+ Large Monster Truck Remote Controlled User Manual

Ninco NH93176

Ninco Bulldog+ Remote Controlled Monster Truck User Manual

Model: NH93176

1. INTRODUCTION

The Ninco Bulldog+ is a 1/18 scale remote-controlled monster truck designed for robust play. It features a large rotating capacity, a 2.4 GHz transmitter for interference-free group play, suspension on all four wheels, and a highly durable body construction. This manual provides essential information for the safe and effective use of your new remote-controlled vehicle.

Key Features:

- 1/18 scale RC monster truck with robust body.
- Suspension on all 4 wheels for enhanced performance.
- 2.4 GHz remote control technology for interference-free operation.
- Designed for ages 6 and up.

2. SAFETY INFORMATION

WARNING:

Not recommended for children under 3 years of age due to small parts which may present a choking hazard. Adult supervision is recommended during operation. Keep fingers, hair, and loose clothing away from the wheels and moving parts of the vehicle. Do not operate the vehicle near people, pets, or obstacles. Always use fresh batteries and dispose of old batteries responsibly.

3. WHAT'S IN THE BOX

Upon opening the product packaging, please verify that all components are present and undamaged:

- 1 x Ninco Bulldog+ Remote Controlled Monster Truck
- 1 x 2.4 GHz Remote Control Transmitter



Image: The Ninco Bulldog+ Monster Truck and its remote control, displayed within the product's retail packaging.

4. SETUP

Battery Installation

The Ninco Bulldog+ requires batteries for both the vehicle and the remote control. Batteries are not included and must be purchased separately.

1. **Vehicle Batteries:** Locate the battery compartment on the underside of the monster truck. Open the compartment cover. Insert 5 x AA batteries, ensuring correct polarity (+/-). Close the compartment cover securely.
2. **Remote Control Batteries:** Locate the battery compartment on the back of the remote control. Open the compartment cover. Insert 3 x AA batteries, ensuring correct polarity (+/-). Close the compartment cover securely.



Image: The black 2.4 GHz remote control for the Ninco Bulldog+ Monster Truck, showing its ergonomic design and control wheel.

5. OPERATING INSTRUCTIONS

Once batteries are installed in both the vehicle and the remote control, you are ready to operate your Ninco Bulldog+.

Remote Control Operation:

- **Power On:** Turn on the power switch on both the vehicle and the remote control. The remote control and vehicle should automatically pair using the 2.4 GHz frequency.
- **Forward/Reverse:** Use the trigger on the remote control to move the truck forward (pull) or backward (push).
- **Steering:** Use the steering wheel on the remote control to turn the truck left or right.
- **Interference-Free Play:** The 2.4 GHz technology allows multiple Ninco RC vehicles to be operated simultaneously without signal interference.



Image: The Ninco Bulldog+ Monster Truck, showcasing its aggressive front design with a shark-like mouth graphic and robust wheels.

6. MAINTENANCE

Proper maintenance will extend the life and performance of your Ninco Bulldog+.

- **Cleaning:** After use, gently wipe the vehicle with a dry, soft cloth to remove dirt and dust. Do not use water or chemical cleaners, as this can damage electronic components.
- **Storage:** Store the vehicle and remote control in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** Always remove batteries from both the vehicle and the remote control when not in use for extended periods to prevent leakage and damage.
- **Inspection:** Periodically check for loose screws, damaged wires, or worn parts. Do not attempt to repair complex internal components; contact customer support if necessary.

7. TROUBLESHOOTING

If you encounter issues with your Ninco Bulldog+, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Vehicle does not respond to remote control.	Batteries are low or incorrectly installed. Vehicle or remote control is not powered on. Not paired correctly.	Replace batteries in both vehicle and remote. Ensure both are switched ON. Turn both off and on again to re-establish connection.
Vehicle moves slowly or erratically.	Low batteries. Obstruction in wheels or drivetrain.	Replace batteries. Check wheels and axles for debris and clear any obstructions.
Short operating range.	Low batteries in remote or vehicle. Environmental interference.	Replace batteries. Move to an open area away from other electronic devices or large metal structures.
Vehicle makes unusual noises.	Debris in gears or motor. Damaged internal components.	Turn off and inspect for visible debris. If noise persists, discontinue use and contact customer support.

8. SPECIFICATIONS

Feature	Detail
Product Dimensions	10.43 x 6.3 x 4.33 inches (26.5 x 16 x 11 cm)
Item Weight	1.52 pounds (0.69 kg)
Model Number	NH93176
Recommended Age	6 years and up
Vehicle Battery Requirement	5 x AA batteries (not included)
Remote Control Battery Requirement	3 x AA batteries (not included)
Radio Frequency	2.4 GHz
Manufacturer	FJNinco

9. WARRANTY AND SUPPORT

Ninco is committed to providing high-quality products. For information regarding warranty coverage,

technical support, or replacement parts, please contact the manufacturer directly. Keep your purchase receipt as proof of purchase.

Manufacturer: FJNinco