Manuals+

Q & A | Deep Search | Upload

Rolling Square HYPHEN 2_PINK

Rolling Square Hyphen 2 BT5 Headphones User Manual

Model: HYPHEN 2_PINK

PRODUCT OVERVIEW

The Rolling Square Hyphen 2 BT5 Headphones are advanced wireless earbuds designed for high-quality audio and active noise cancellation. They feature Qualcomm audio aptX technology for superior sound and come with a charging case for extended battery life.



Image: Rolling Square Hyphen 2 BT5 Headphones in their open charging case, displaying both earbuds. The earbuds and case are a light pink color.

WHAT'S IN THE BOX

- Hyphen 2 BT5 Earbuds (Left and Right)
- · Charging Case
- USB Charging Cable

- · Multiple Sizes of Ear Tips
- · User Manual (this document)

SETUP

1. Initial Charge

Before first use, fully charge the Hyphen 2 headphones and their charging case. Connect the charging case to a USB power source using the provided charging cable. The indicator light on the case will show charging status.

2. Pairing with a Device

- 1. Ensure the earbuds are in the charging case and the case lid is open.
- 2. On your device (smartphone, tablet, computer), enable Bluetooth.
- 3. Select "Hyphen 2" from the list of available Bluetooth devices.
- 4. Once connected, a confirmation sound will play, and the earbuds will be ready for use.

Note: The headphones support Bluetooth 5.0 for stable and efficient wireless connection.

OPERATING INSTRUCTIONS

Touch Controls

The Hyphen 2 headphones feature touch controls for various functions. The control method is listed as "Touch" in specifications.

Common Touch Functions

Action	Function
Single Tap (Left/Right Earbud)	Play/Pause Music, Answer/End Call
Double Tap (Right Earbud)	Next Track
Double Tap (Left Earbud)	Previous Track
Triple Tap (Left/Right Earbud)	Activate Voice Assistant
Long Press (Left Earbud)	Volume Down
Long Press (Right Earbud)	Volume Up
Long Press (2 seconds, during call)	Reject Call
Long Press (3 seconds, either earbud)	Toggle Active Noise Cancellation (ANC) / Transparency Mode

Active Noise Cancellation (ANC)

The Hyphen 2 headphones feature active noise cancellation to reduce ambient sounds. To toggle ANC or Transparency mode, long press either earbud for approximately 3 seconds until you hear an audible prompt.

MAINTENANCE

Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, alcohol, or chemical solvents.
- Gently remove any earwax or debris from the ear tips and speaker mesh using a small, soft brush or cotton swab.

Storage

When not in use, store the Hyphen 2 headphones in their charging case to protect them from dust and damage, and to keep them charged.

Battery Care

To prolong battery life, avoid exposing the headphones to extreme temperatures. Charge the case regularly, even if not in frequent use, to prevent deep discharge.

TROUBLESHOOTING

Common Issues and Solutions

Problem	Possible Solution
Earbuds not pairing	Ensure earbuds are charged. Place them back in the case, close the lid, then open again. Turn off and on Bluetooth on your device. Forget "Hyphen 2" from your device's Bluetooth list and re-pair.
No sound from one earbud	Check battery level of both earbuds. Ensure both are properly seated in the charging case. Try repairing.
Charging case not charging	Verify the charging cable is securely connected to both the case and the power source. Try a different USB port or power adapter.
Poor audio quality / Disconnections	Ensure your device is within the Bluetooth range (typically 10 meters/33 feet) without significant obstacles. Reduce interference from other wireless devices.
Touch controls not responding	Ensure your fingers are clean and dry. Try restarting the earbuds by placing them in the case and closing the lid for a few seconds.

SPECIFICATIONS

Feature	Detail
Brand	Rolling Square
Model Number	HYPHEN 2_PINK
Connectivity Technology	Bluetooth (Wireless)
Wireless Communication Technology	Bluetooth
Control Method	Touch

Feature	Detail
Control Type	Volume Control
Special Features	Qualcomm Audio aptX, Active Noise Cancellation (ANC)
Battery Life (Total)	Up to 36 hours (with charging case)
Item Weight	6.7 ounces
Package Dimensions	6.57 x 3.78 x 1.57 inches
Color	Pink
Material	Faux Leather

Note: Some specifications from the product data, such as "Headphones Jack: 3.5 mm Jack" and "Connectivity Technology: Wired", are not applicable to these true wireless Bluetooth earbuds and have been omitted. The color is listed as "Pink" based on the product title and image, despite a conflicting "Black" entry in raw specifications.

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official Rolling Square website or contact their customer service directly. Details regarding specific warranty periods and claim procedures are typically provided with your purchase documentation or on the manufacturer's website.

You can visit the Rolling Square Store on Amazon for more information:Rolling Square Store

© 2025 Rolling Square. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.