Dreyoo 9339049513730

Dreyoo Universal Rotisserie Grill Kit Instruction Manual

Model: 9339049513730 | Brand: Dreyoo

Introduction

This manual provides essential instructions for the safe and efficient use of your Dreyoo Universal Rotisserie Grill Kit. Please read all instructions carefully before assembly and operation. Proper installation and maintenance will ensure optimal performance and longevity of your rotisserie kit.

Safety Information

- Always ensure the rotisserie motor is unplugged before assembly, disassembly, or cleaning.
- Do not immerse the motor in water or expose it to excessive moisture. The motor features a waterproof switch, but the unit is not designed for submersion.
- Keep children and pets away from the grill area during operation.
- Use heat-resistant gloves when handling hot components.
- Ensure the spit rod and forks are securely fastened to prevent food from falling during rotation.
- Verify that your grill has appropriate installation holes (approximately 5mm diameter, 40-60cm center distance) or a grilling mesh for securing the spit rod bracket.
- The motor is rated for 120V 4W. Do not use with incompatible power sources.

Package Contents

Your Dreyoo Universal Rotisserie Grill Kit includes the following components:

- 1 x 120V 4W Electric Motor with waterproof ON/OFF switch
- 2 x 14-inch Skewers (can be spliced to form a 28-inch spit rod)
- 2 x 4-Prong Meat Forks
- 1 x Shaft
- 14 x Fixing Screws
- 1 x Motor Holder
- 2 x Spit Rod Supports (with 5 adjustable slots)




Image: All components of the Dreyoo Universal Rotisserie Grill Kit, including the motor, spit rod, meat forks, and mounting hardware.

Setup and Installation

Follow these steps to assemble and install your rotisserie kit:

1. **Attach Motor Bracket:** Set the motor bracket connector outside your grill. Secure it using the provided fixing screws.
2. **Insert Motor:** Slide the 120V 4W electric motor into the motor holder. Ensure it is firmly seated.
3. **Assemble Mounting Brackets:** Connect the spit rod support brackets together and secure them to the opposite side of the grill from the motor, aligning with the grill's existing holes or using a grilling mesh for support. The support has 5 slots for length adjustment.
4. **Assemble Spit Rods:** Connect the two 14-inch skewers using the shaft to form a single 28-inch spit rod.
5. **Attach Meat Forks:** Slide the 4-prong meat forks onto the spit rod. Position them to securely hold your food item. Use fixing screws to tighten the forks in place.
6. **Place Spit Rod:** Carefully place the assembled spit rod with food onto the motor and the opposite support bracket. Ensure the spit rod is properly engaged with the motor's drive mechanism.




Image: Visual guide illustrating the six steps for assembling the rotisserie kit on a grill.



Image: Detail of the motor's waterproof ON/OFF switch and UL certification, highlighting safety features.

Operating Instructions

Once the rotisserie kit is installed and food is secured:

1. **Prepare Food:** Skewer your desired food item (e.g., whole chicken, roast, vegetables) onto the spit rod, ensuring it is balanced. Secure it firmly with the meat forks. The kit supports up to 20 lbs of food.
2. **Position on Grill:** Place the spit rod assembly onto the grill, ensuring the motor end is properly engaged and the other end rests securely in the support bracket.
3. **Connect Power:** Plug the motor into a standard 120V electrical outlet.
4. **Start Rotation:** Flip the waterproof ON/OFF switch on the motor to the 'ON' position. The motor will begin rotating the spit rod at 2-3 RPM, ensuring even cooking.
5. **Monitor Cooking:** Monitor your food as it cooks. Adjust grill temperature as needed.
6. **Stop Rotation:** Once cooking is complete, flip the ON/OFF switch to 'OFF' and unplug the motor.

7. **Remove Food:** Carefully remove the spit rod with cooked food from the grill using heat-resistant gloves.



Image: The rotisserie kit actively rotating a chicken and other items on a grill, demonstrating even cooking.



Image: A large roast rotating on the rotisserie spit rod, illustrating its capacity for heavier items.



Image: A whole duck rotating on the rotisserie, showing the ease of use and even browning.

Maintenance

- **Cleaning:** After each use, allow all components to cool completely. Disassemble the spit rod and forks. Wash stainless steel components with warm, soapy water and a non-abrasive sponge. Rinse thoroughly and dry immediately to prevent water spots and corrosion.
- **Motor Care:** Wipe the motor housing with a damp cloth. Do not use abrasive cleaners or immerse the motor in water. Ensure the motor is completely dry before storage.
- **Storage:** Store all components in a clean, dry place when not in use. The screw splicing design of the roasting rods allows for compact storage.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Motor does not turn on.	Not plugged in; power switch off; power outage; faulty motor.	Ensure motor is securely plugged into a live 120V outlet. Check the ON/OFF switch. Verify power to the outlet. If issues persist, contact support.
Spit rod is not rotating evenly or skips.	Food is unbalanced; food too heavy; spit rod not properly engaged with motor; motor issue.	Ensure food is centered and balanced on the spit rod. Do not exceed the 20 lbs weight limit. Verify the spit rod is correctly seated in the motor drive. If skipping continues with balanced, lighter loads, contact support.
Food is not cooking evenly.	Uneven heat distribution in grill; food not balanced; rotation issue.	Check grill's heat distribution. Ensure food is balanced on the spit rod. Verify the rotisserie is rotating smoothly.

Specifications

- **Brand:** Dreyoo
- **Model Number:** 9339049513730
- **Material:** Food Grade 304 Stainless Steel
- **Motor:** 120V, 4W Electric Motor
- **Rotation Speed:** 2-3 RPM
- **Spit Rod Length:** 28 inches (assembled from two 14-inch skewers)
- **Spit Rod Type:** Quadrilateral, 1/2 inch
- **Weight Capacity:** Up to 20 lbs of food
- **Special Features:** UL Certified, Waterproof ON/OFF Switch, 5-slot adjustable spit rod holder
- **Assembly Required:** Yes
- **Item Weight:** 3.35 Pounds

Warranty and Support

For any questions, concerns, or warranty inquiries regarding your Dreyoo Universal Rotisserie Grill Kit, please contact Dreyoo customer support through the retailer where the product was purchased. Please have your model number (9339049513730) and purchase information available.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question