Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

De'Longhi 0132106242

De'Longhi Dedica Metallics 785.BG Coffee Machine User Manual

Model: 0132106242

1. Introduction

Thank you for choosing the De'Longhi Dedica Metallics 785.BG Coffee Machine. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read it thoroughly before first use and keep it for future reference.

This compact yet powerful espresso machine is designed to deliver rich, authentic espresso and perfectly frothed milk for your favorite coffee beverages, enhancing your kitchen with its unique and iconic design.

2. Safety Information

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and/or injury to persons.

- Read all instructions carefully before use.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock, and personal injury, do not immerse cord, plugs, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or personal injury.

- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to “off”, then remove plug from wall outlet.
- Do not use appliance for other than intended use.

3. Package Contents

Please check that all items are present and in good condition:

- De'Longhi Dedica Metallics 785.BG Coffee Machine
- Portafilter
- Filter Baskets (single, double, E.S.E. pod)
- Tamper
- Milk Frothing Jug
- Measuring Spoon
- Descaling Solution (sample)
- User Manual

4. Product Overview

Familiarize yourself with the main components of your coffee machine:



Figure 4.1: The De'Longhi Dedica Metallics 785.BG Coffee Machine shown with its included accessories, including a milk frothing jug and a tamper. This image highlights the compact design and the elegant multi-color finish.



Figure 4.2: A close-up view of the espresso extraction process, showing rich coffee flowing into a glass cup. This demonstrates the machine's ability to produce high-quality espresso.



Figure 4.3: The coffee machine with its My Latte Art steam wand actively frothing milk in a stainless steel jug. This illustrates the manual milk frothing capability for creating micro-foam.



Figure 4.4: A visual representation of the machine's dual capabilities, showing a rich espresso shot on one side and a perfectly layered milk-based coffee with micro-foam on the other. This highlights the versatility for different coffee types.

5. Setup

1. **Unpacking:** Carefully remove the machine and all accessories from the packaging. Remove any protective films or stickers.
2. **Initial Cleaning:** Wash the water tank, portafilter, and filter baskets with warm water and mild detergent. Rinse thoroughly.
3. **Fill Water Tank:** Fill the water tank with fresh, cold drinking water up to the MAX level. Place the tank back into the machine.
4. **First Use Cycle:** Before making coffee, perform a first-use cycle to rinse the internal circuits. Place a container under the coffee spout and steam wand. Turn on the machine. Once the machine is ready, dispense water through the coffee spout until the tank is empty. Repeat this process for the steam wand. This primes the system and removes any manufacturing residues.
5. **Pre-heating:** Allow the machine to pre-heat for at least 20-30 minutes for optimal performance, especially for espresso extraction.

6. Operating Instructions

6.1 Making Espresso

1. **Prepare the Portafilter:** Insert the desired filter basket (single or double shot) into the portafilter.
2. **Add Ground Coffee:** Fill the filter basket with finely ground espresso coffee. Use the measuring spoon for accurate dosing.
3. **Tamp the Coffee:** Use the tamper to press the coffee grounds firmly and evenly. Ensure a level surface.
4. **Attach Portafilter:** Insert the portafilter into the group head and turn it to the right until it is securely locked.
5. **Place Cup:** Place one or two pre-heated espresso cups under the portafilter spouts. The drip tray can be removed for taller cups.
6. **Brew Espresso:** Press the single or double espresso button. The machine will automatically dispense the correct amount of coffee.

6.2 Frothing Milk with My Latte Art Steam Wand

The My Latte Art steam wand allows for manual milk frothing to create perfect micro-foam for lattes and cappuccinos.

1. **Fill Milk Jug:** Fill the milk frothing jug with cold milk (dairy or non-dairy) up to the recommended level.
2. **Activate Steam:** Turn the steam knob to the steam position. Wait for the steam indicator light to illuminate steadily, indicating the machine has reached the optimal temperature for steaming.
3. **Purge Steam Wand:** Briefly open the steam knob to release any condensed water from the wand into an empty container. Close the knob.
4. **Froth Milk:** Immerse the tip of the steam wand just below the surface of the milk. Slowly open the steam knob. Move the jug up and down slightly to incorporate air and create micro-foam. Once the desired texture and temperature are reached, close the steam knob.
5. **Clean Steam Wand:** Immediately wipe the steam wand with a damp cloth to remove any milk residue. Briefly open the steam knob again to clear any milk from inside the wand.

7. Cleaning and Maintenance

Regular cleaning and maintenance ensure the longevity and optimal performance of your coffee machine.

- **Daily Cleaning:**
  - Empty and rinse the drip tray and coffee grounds container daily.
  - Wipe down the exterior of the machine with a soft, damp cloth.
  - Clean the steam wand immediately after each use.
- **Portafilter and Filter Baskets:** Rinse after each use. Periodically clean with a brush to remove coffee residues.
- **Water Tank:** Rinse the water tank regularly.
- **Descaling:** The machine will indicate when descaling is required. Use a suitable descaling solution (e.g., De'Longhi EcoDecalk) and follow the instructions provided with the descaler. Descaling is crucial for maintaining machine performance and coffee quality, especially in areas with hard water.

8. Troubleshooting

If you encounter issues with your coffee machine, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
No coffee dispenses	Water tank empty; clogged filter; machine not primed.	Fill water tank; clean filter basket; perform first use cycle.
Coffee is too weak/watery	Coffee grounds too coarse; insufficient coffee; tamping too light.	Use finer grind; increase coffee amount; tamp more firmly.
Coffee is too strong/bitter	Coffee grounds too fine; too much coffee; tamping too hard.	Use coarser grind; decrease coffee amount; tamp lighter.
Steam wand not producing steam	Steam wand clogged; machine not at steam temperature.	Clean steam wand; wait for steam indicator light.
Machine leaks water	Water tank not seated correctly; seals worn.	Re-seat water tank; contact customer support for seal replacement.
Descaling light on	Machine requires descaling.	Perform descaling cycle as per instructions.

If the problem persists after trying these solutions, please contact De'Longhi customer support.

9. Specifications

Feature	Detail
Brand	De'Longhi
Model Number	0132106242
Color	Multi-color
Product Dimensions	5.87 x 12.99 x 12.01 cm
Item Weight	4.2 Kilograms
Capacity	1 Liters
Power / Wattage	1350 watts
Voltage	220 Volts
Material	Stainless Steel
Auto Shutoff	Yes
Noise Level	44 dB
Special Features	Milk Frother
Filter Type	Reusable

Feature	Detail
Style	Modern
Specific Uses For Product	Espresso

10. Warranty and Support

Your De'Longhi Dedica Metallics 785.BG Coffee Machine comes with a manufacturer's warranty. Please refer to the warranty card included in your product packaging for detailed information regarding warranty terms, conditions, and duration.

For technical support, service, or to order spare parts and accessories, please visit the official De'Longhi website or contact their customer service department. Contact information can typically be found in the warranty documentation or on the De'Longhi official website.

Online Resources:

- Official De'Longhi Website: www.delonghi.com
- Product Support Page: (Refer to the official website for specific product support pages)

© 2024 De'Longhi. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B095XD6DYD

More documents and user manuals: **https://manuals.plus/**