Music Sound BTHEADBMSVIBEDK

Music Sound VIBED Bluetooth Headphones User Manual

Model: BTHEADBMSVIBEDK | Brand: Music Sound

1. Introduction

The Music Sound VIBED Bluetooth Headphones are designed for wireless audio playback and hands-free calling. They feature rotating and foldable earcups for portability, an adjustable padded headband for comfort, and integrated controls for managing music and calls. This manual provides instructions for the proper use and maintenance of your headphones.



Image 1.1: Music Sound VIBED Bluetooth Headphones.

2. Setup

2.1 Charging the Headphones

Before first use, fully charge the headphones. Connect the supplied USB-C cable to the charging port on the headphones and the other end to a compatible USB power source (e.g., computer USB port, USB wall adapter). The charging indicator light will show the charging status and turn off or change color when fully charged.

2.2 Bluetooth Pairing

1. Ensure the headphones are turned off.
2. Press and hold the power button until the indicator light flashes, indicating pairing mode.
3. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
4. Select "Music Sound VIBED" from the list of found devices.
5. Once connected, the indicator light will stop flashing and remain solid or turn off, depending on the model.

3. Operating Instructions

3.1 Power On/Off

- **To Power On:** Press and hold the power button for approximately 3 seconds until the indicator light illuminates.
- **To Power Off:** Press and hold the power button for approximately 5 seconds until the indicator light turns off.

3.2 Music Playback

The headphones feature integrated controls on the earcup for easy management of your music.




Image 3.1: Earcup with integrated keypad controls.

- **Play/Pause:** Press the multi-function button once.
- **Volume Up:** Press the '+' button.
- **Volume Down:** Press the '-' button.
- **Next Track:** Press and hold the '+' button.

- **Previous Track:** Press and hold the '-' button.

3.3 Call Management

With the built-in microphone, you can manage calls directly from your headphones.

- **Answer/End Call:** Press the multi-function button once.
- **Reject Call:** Press and hold the multi-function button for 2 seconds.

3.4 Foldable and Rotating Earcups

The earcups can be rotated and folded inward for compact storage and portability.



Image 3.2: Headphones with rotating and foldable earcups.

4. Maintenance

4.1 Cleaning

Wipe the headphones with a soft, dry cloth. Do not use abrasive cleaners or solvents. Avoid getting moisture into any openings.

4.2 Storage

When not in use, store the headphones in a cool, dry place. Utilize the foldable design to minimize space and protect the earcups from damage.

5. Troubleshooting

- **Headphones not turning on:** Ensure the headphones are fully charged.
- **Cannot pair with device:** Make sure Bluetooth is enabled on your device and the headphones are in pairing mode. Move the headphones closer to your device.
- **No sound:** Check the volume level on both the headphones and your connected device. Ensure the headphones are properly paired.
- **Poor sound quality:** Ensure there are no obstructions between the headphones and your device. Try moving closer to your device.
- **Short battery life:** Ensure the headphones are fully charged before each use. Battery life can vary based on volume levels and usage. The headphones offer up to 35 hours of playback time on a full charge.



Image 5.1: Headphones highlighting 35 hours of music playback.

6. Specifications

Feature	Detail
Brand	Music Sound
Model Name	BTHEADBMSVIBEDK
Connectivity Technology	Bluetooth, Wireless
Wireless Communication Technology	Bluetooth
Form Factor	On-Ear
Ear Placement	Over-Ear
Color	Black
Material	Fabric
Specific Product Uses	Music, Calls
Compatible Devices	Mobile Phone
Cable Function	Detachable (USB-C for charging)
Water Resistance Level	Waterproof (Note: This may refer to splash resistance, not full submersion)
Control Method	Tactile (Buttons)
Number of Items	1
Special Features	Rechargeable Battery, Volume Control, Microphone Included
Battery Composition	Lithium-ion
Rechargeable Battery	Yes
Included Components	USB-C Cable, Instructions, Bluetooth Headphones
Manufacturer	CellularLine S.p.A.
Country of Origin	China
Age Range (Description)	Adult

7. Warranty Information

Warranty information for the Music Sound VIBED Bluetooth Headphones is not explicitly provided in the available product data. Please refer to the product packaging or the manufacturer's official website for detailed warranty terms and conditions.

8. Support

For further assistance, technical support, or product inquiries, please visit the official Music Sound website or contact their customer service department. Contact details are typically available on the manufacturer's website or product packaging.

© 2026 Music Sound. All rights reserved.