

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Camiysn](#) /

› [Camiysn Typewriter Style Mechanical Gaming Keyboard User Manual](#)

Camiysn CPKJXFBPINK527

Camiysn Typewriter Style Mechanical Gaming Keyboard User Manual

Model: CPKJXFBPINK527

INTRODUCTION

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your Camiysn Typewriter Style Mechanical Gaming Keyboard. Please read this manual thoroughly before using the product to ensure proper function and longevity.

The Camiysn Typewriter Style Mechanical Gaming Keyboard features a retro design with round keycaps, blue mechanical switches for tactile and audible feedback, and white backlighting. It is designed for both office and gaming use, offering broad compatibility and durable construction.

PACKAGE CONTENTS

- Camiysn Typewriter Style Mechanical Gaming Keyboard
- Detachable Magnetic Wrist Rest
- User Manual (this document)

SETUP

1. **Unpacking:** Carefully remove the keyboard and all accessories from the packaging.
2. **Connect the Keyboard:** The keyboard connects via a USB cable. Plug the USB connector into an available USB port on your computer (Windows PC, Mac, Linux, etc.). The keyboard is plug-and-play and does not require additional driver installation.
3. **Attach Wrist Rest (Optional):** Align the detachable magnetic wrist rest with the front edge of the keyboard. The magnets will secure it in place.



Image: The Camiysn keyboard with its detachable magnetic wrist rest attached, illustrating how the two components fit together for ergonomic support.

OPERATING INSTRUCTIONS

Backlight Control

The keyboard features multiple white backlight modes. Use the following key combinations to adjust the backlighting:

- **Change Light Mode:** Press **Fn** + **Ins**
- **Increase Brightness:** Press **Fn** + **↑** (Up Arrow)
- **Decrease Brightness:** Press **Fn** + **↓** (Down Arrow)
- **Increase Backlight Speed:** Press **Fn** + **←** (Left Arrow)
- **Decrease Backlight Speed:** Press **Fn** + **→** (Right Arrow)




Image: Diagram illustrating the function key combinations for controlling the keyboard's backlighting, including brightness and speed adjustments.

Multimedia Keys

Access various multimedia functions using the **Fn** key in combination with the F-keys:

Key Combination	Function
Fn + F1	Media Player
Fn + F2	Volume Decrease
Fn + F3	Volume Increase
Fn + F4	Mute
Fn + F5	Halt
Fn + F6	Last Song
Fn + F7	Play/Suspend
Fn + F8	Next Song
Fn + F9	E-mail
Fn + F10	Homepage
Fn + F11	My Computer
Fn + F12	Calculator



Image: A visual representation of the Camiysn keyboard highlighting the multimedia functions accessible via the Fn key combinations.

Anti-Ghosting

The keyboard features 26 anti-ghosting keys, ensuring that multiple simultaneous key presses are registered accurately, which is beneficial for gaming and fast typing.



Image: An overhead view of the Camiysn keyboard, with several keys highlighted to demonstrate the anti-ghosting capability, allowing multiple key presses to register simultaneously.

WASD and Arrow Key Exchange

To exchange the functionality of the WASD keys with the Arrow keys, press **Fn** + **W**.



Image: A diagram showing the Camiysn keyboard and the Fn+W key combination used to swap the functions of the WASD keys with the arrow keys.

Maintenance

- **Cleaning:** Use a soft, dry cloth to wipe the keyboard surface. For deeper cleaning, use compressed air to remove dust and debris from between the keycaps. Avoid using liquid cleaners directly on the keyboard.
- **Keycap Removal:** Keycaps can be carefully removed for cleaning or replacement. Use a keycap puller (not included) or gently pry them off from the edges. Reinstall by pressing them firmly onto the switch stem.
- **Storage:** Store the keyboard in a cool, dry place away from direct sunlight and extreme temperatures when not in use for extended periods.




Image: An exploded view of a keycap and its underlying blue mechanical switch, demonstrating the structure and how keycaps can be removed for maintenance.

Troubleshooting

Keyboard not responding:

- Ensure the USB cable is securely plugged into both the keyboard and the computer.
- Try plugging the keyboard into a different USB port on your computer.
- Test the keyboard on another computer to rule out system-specific issues.

Backlight not working or stuck:

- Use **Fn** + **↑** (Up Arrow) to increase brightness.
- Cycle through light modes using **Fn** + **Ins**.
- Perform a keyboard reset: Press and hold **Fn** + **Esc** simultaneously, then press **F1**, **F3**, **F5** in sequence. The backlight should turn off and then back on to indicate a successful reset.

Windows key not working:

- The Windows key might be locked. Check the indicator light (often labeled "Win Lock" or similar).
- To unlock the Windows key, press **Fn** + **W-L** (or **Fn** + **Win** depending on the specific model's keycap labeling). The indicator light should turn off.
- Some systems may interpret **Ctrl** + **Esc** as the Windows key function.

SPECIFICATIONS

Feature	Detail
Model Number	CPKJXFBPINK527
Brand	Camiysn
Switch Type	Blue Mechanical Switches (Clicky)
Keycaps	Round, Two-color Injection Molding
Backlighting	White Backlit, Multiple Modes
Connectivity	Wired USB
Anti-Ghosting	26 Keys
Compatibility	Windows 2000/7/8/10/XP, Vista, Linux, Mac, Gaming Consoles
Product Dimensions	17.09 x 4.93 x 1.34 inches (43.4 x 12.5 x 3.4 cm)
Item Weight	2.12 pounds (0.96 kg)
Special Features	Typewriter style, Detachable magnetic wrist rest, Adjustable rear feet

FULL SIZE KEYBOARD

retro typewriter style with round keycaps and clicky clack



Image: An overhead view of the Camiysn keyboard with measurements indicating its full size and dimensions, including the wrist rest.

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official Camiysn website or contact their customer service directly. Keep your purchase receipt as proof of purchase for warranty claims.

Manufacturer: Camiysn

Date First Available: May 27, 2021



For further assistance, you may visit the [Camiysn Store on Amazon](#).

Related Documents - CPKJXFBPINK527



[Camiysn SKY 87 Game Keyboard User Guide](#)

User guide for the Camiysn SKY 87 Game Keyboard, detailing its features, specifications, operation instructions, and warranty information. Learn how to use your gaming keyboard effectively.

	<p>Camiysn STAR100 Wired Mechanical Gaming Keyboard User Guide</p> <p>Comprehensive user guide for the Camiysn STAR100 wired mechanical gaming keyboard, detailing features, specifications, operation instructions, and warranty information.</p>
	<p>Camiysn GK980 Membrane Keyboard User Guide</p> <p>Comprehensive user guide for the Camiysn GK980 Membrane Keyboard, detailing features, multimedia functions, backlight modes, specifications, product instructions, and warranty information.</p>
	<p>Camiysn SKY98 Mechanical Keyboard User Guide & Specifications</p> <p>Comprehensive user guide for the Camiysn SKY98 Compact 80% Mechanical Keyboard. Includes warranty, product specifications, shortcut keys, multimedia functions, operation instructions, and precautions.</p>
	<p>Camiysn SKY 87 Game Keyboard User Guide</p> <p>User guide for the Camiysn SKY 87 Game Keyboard, detailing its features, specifications, operation instructions, and warranty information. Learn how to use your gaming keyboard effectively.</p>
	<p>Camiysn STAR100 Wired Mechanical Gaming Keyboard User Guide</p> <p>Comprehensive user guide for the Camiysn STAR100 wired mechanical gaming keyboard, detailing features, specifications, operation instructions, and warranty information.</p>